

# LANDSCAPE WALL | 6-IN X 16-IN WALL BLOCK

## INSTALLATION INSTRUCTIONS



1. Prepare Wall Location

At wall location, dig shallow trench for wall base (see Typical Wall Section). Place granular leveling pad material. Compact and level the base pad. Place and level the first course units. If grade changes along base of wall, create stepped leveling pad as required. Always start wall at lowest elevation, working to highest. Complete base course before proceeding with additional courses.

Backfill first course units with clean granular fill material (i.e. crushed stone/gravel). DO NOT USE PEA GRAVEL! Compact with hand tamper or appropriate mechanical compactor. Backfill and compact behind each course before installing additional courses.



2. Place & Compact Backfill



Starting at straight wall area, place units centered over joint of units below to form a running bond pattern. Build through curves in similar manner.

Capping: If using a cored unit, complete your wall with the appropriate cap\* unit. Use exterior grade construction adhesive on the top surface of the last course before applying cap units. Backfill and compact to finish grade.

#### Remove Edges


To remove outside lugs or edges of retaining lip, hold unit securely or place at angle on ground. Strike the lug firmly with a hammer. Always wear safety glasses to protect eyes from chips.




.....

### **Building Curves**

Curves as small as 3' in radius can be built with 6-in x 16-in Wall Block. Convex & concave course bonding will adjust sideways. If stack bond occurs, remove rear interlock lip as shown or cut units accordingly to get back to running bond.





#### Typical Wall Section

Use clean granular backfill such as gravel or crushed stone for drainage and to prevent soil from leaching through the wall. A commercial filter fabric (stocked by most garden supply stores) may be used when existing site soils are used for backfill.

.....



