

HZ234700TX

Harvey Mixed Tone Bar Cabinet

Assembly Instructions



Southern
ENTERPRISES


For assistance with assembly, contact:
Southern Enterprises Inc.

Customer Service 1-800-633-5096

service@seidal.com

www.seidal.com













PO#:13403

































Harvey Mixed Tone Bar Cabinet





Parts List

Please check packaging for all parts and hardware before discarding. Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated. Call customer service if hardware is missing. Before beginning assembly, carefully study the diagrams below and sort your hardware according to the pictures. Using the incorrect hardware will cause damage.

A.  Top Panel	B.  Bottom Panel	C.  Left Side Panel
D.  Right Side Panel	E.  Vertical Panel	F.  Fixed Shelf
G.  Wine Rack Vertical Panel	H.  Wine Rack Shelf Panel	I.  Left Door
J.  Right Door	K.  Drawer Front	L.  Drawer Back

M.  Drawer Bottom Panel Quantity of 1	N.  Left Drawer Side Panel Quantity of 1	O.  Right Drawer Side Panel Quantity of 1
P.  Back Panel Quantity of 1	Q.  Metal Frame Quantity of 2	R.  Metal Rail Quantity of 4
1.  Cam Bolt Quantity of 28	2.  Cam Lock Quantity of 24	3.  Cam Lock (for Drawer) Quantity of 4
4.  Wood Dowel Dia 8 x 30mm Quantity of 28	5.  Magnet Quantity of 2	6.  Flat Head Screw Dia 1/8" x 5/8"L (for Magnet and Bracket) Quantity of 12
7.  Magnet Plate Quantity of 2	8.  Screw Dia 1/8" x 1"L (for Drawer) Quantity of 4	9.  Screw Dia 1/8" x 1/2"L (for Hinge) Quantity of 22

<p>10. Quantity of 4</p>  <p>Leg's Leveler</p>	<p>11. Quantity of 4</p>  <p>Round Head Bolt</p>	<p>12. Quantity of 4</p>  <p>T-Nut</p>
<p>13. Quantity of 32</p>  <p>Round Head Screw Dia 1/8" x 1/2"L (for Back Panel)</p>	<p>14. Quantity of 20</p>  <p>Flat Washer</p>	<p>15. Quantity of 20</p>  <p>Spring Washer</p>
<p>16. Quantity of 16</p>  <p>Short Blot Ø1/4" x 1/2"L</p>	<p>17. Quantity of 4</p>  <p>Long Blot Ø1/4" x 1-1/2"L</p>	<p>18. Quantity of 1</p>  <p>Allen Wrench</p>
<p>19. Quantity of 14</p>  <p>Flat Head Screw Dia 1/8" x 1/2"L (for Male Slide & Magnet Plate)</p>	<p>20. Quantity of 1</p>  <p>Left Female Slide</p>	<p>21. Quantity of 1</p>  <p>Left Male Slide</p>
<p>22. Quantity of 1</p>  <p>Right Female Slide</p>	<p>23. Quantity of 1</p>  <p>Right Male Slide</p>	<p>24. Quantity of 4</p>  <p>Screw Dia 1/8" x 1-1/2"L</p>

25.  Anchor Quantity of 4	26.  Bracket Quantity of 4	27.  Plastic Strap Quantity of 2
Care and Cleaning Instructions: Before using, wipe with a clean, dry cloth. Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.		For replacement parts or questions, please call customer service at 1-800-633-5096.
Assembly Tool Required No.2 Phillips Screwdriver (Not Included)		

Tool List: 3/16" drill bit, drill, tape measure and pencil.

Harvey Mixed Tone Bar Cabinet

Assembly Instructions




Figure 1

Screw with fingers to help align screws before using screwdriver.

Attach Magnets **(5)** to bottom of Top Panel **(A)** using Flat Head Screws **(6)**.

Tighten Flat Head Screws **(6)** with Phillips screwdriver.




Figure 2

Screw with fingers to help align screws before using screwdriver.

Attach Right Female Slide **(22)** to Right Side Panel **(D)** with Flat Head Screws **(19)**.

Tighten Flat Head Screws **(19)** with Phillips screwdriver.

Tip: Make sure to attach Flat Head Screws **(19)** in same hole on Right Female Slide **(22)** as shown on inset.

If you have correctly attached one screw, every other screw should align with holes on Right Female Slide **(22)**.




Figure 3


Screw with fingers to help align screws before using screwdriver.

Attach Left Female Slide **(20)** to Vertical Panel **(E)** with Flat Head Screws **(19)**.

Tighten Flat Head Screws **(19)** with Phillips screwdriver.

Tip: Make sure to attach Flat Head Screws **(19)** in same hole on Left Female Slide **(20)** as shown on inset.

If you have correctly attached one screw, every other screw should align with holes on Left Female Slide **(20)**.



"Please do not over tighten cambolts. Please stop when you feel tight"




Figure 4

Screw with fingers to help align cam bolts before using screwdriver.

Insert Cam Locks **(2)** and Wood Dowels **(4)** into holes on Fixed Shelves **(F)**.

Screw Cam Bolts **(1)** into holes on Vertical Panel **(E)** and Right Side Panel **(D)**.

Attach Vertical Panel **(E)** and Right Side Panel **(D)** to Fixed Shelves **(F)** by inserting Wood Dowels **(4)** and Cam Bolts **(1)** into corresponding holes until panels meet.

Tighten by rotating Cam Locks **(2)** clockwise with Phillips screwdriver.




Figure 5

Screw with fingers to help align cam bolts before using screwdriver.

Insert Cam Locks **(2)** into holes on Fixed Shelf **(F)**.

Screw Cam Bolts **(1)** and insert Wood Dowels **(4)** into holes on assembled unit from Figure 4 and Left Side Panel **(C)**.

Attach assembled unit from Figure 4 and Left Side Panel **(C)** to Fixed Shelf **(F)** by inserting Wood Dowels **(4)** and Cam Bolts **(1)** into corresponding holes until panels and assembled unit meet.

Tighten by rotating Cam Locks **(2)** clockwise with Phillips screwdriver.




Figure 6

Screw with fingers to help align cam bolts before using screwdriver.

Insert Cam Locks **(2)** into holes on assembled unit.

Screw Cam Bolts **(1)** and insert Wood Dowels **(4)** into holes on Top Panel **(A)**.

Attach Top Panel **(A)** to assembled unit by inserting Wood Dowels **(4)** and Cam Bolts **(1)** into corresponding holes until panels and assembled unit meet.

Tighten by rotating Cam Locks **(2)** clockwise with Phillips screwdriver.




Figure 7

Screw with fingers to help align cam bolts before using screwdriver.

Insert Cam Locks **(2)** into holes on bottom of assembled unit.

Screw Cam Bolts **(1)** and insert Wood Dowels **(4)** into holes on Bottom Panel **(B)**.

Insert T-Nuts **(12)** into holes on Side Panels **(C)** and **(D)**.

Attach Bottom Panel **(B)** to assembled unit by inserting Wood Dowels **(4)** and Cam Bolts **(1)** into corresponding holes until panels meet.

Tighten by rotating Cam Locks **(2)** clockwise with Phillips screwdriver.

Insert Bolts **(11)** through bottom of Bottom Panel **(B)** and into T-Nuts **(12)**. Tighten Bolts **(11)** with Phillips screwdriver.





Figure 8

Screw with fingers to help align bolts.

Attach Metal Frame **(Q)** to Metal Rails **(R)** with Short Bolts **(16)**, Spring Washers **(15)** and Flat Washers **(14)** as shown.


Do not fully tighten until Figure 11 is complete.



Screw with fingers to help align bolts.

Attach second Metal Frame (**Q**) to assembled unit with Short Bolts (**16**), Spring Washers (**15**) and Flat Washers (**14**) as shown.

Figure 9



Attach Leg's Levelers (**10**) to assembled metal frame by hand.

Figure 10




Figure 11

Connect assembled metal frame to assembled unit from Figure 7 with Long Bolts **(17)**, Spring Washers **(15)** and Flat Washers **(14)** as shown.

Tighten Long Bolts **(17)** with Allen Wrench **(18)**.

Check and tighten all Bolts with Allen Wrench **(18)**.

Stand the Bar Cabinet right side up.




Figure 12

Insert Wine Rack Vertical Panels **(G)** into Wine Rack Shelf Panels **(H)** together as shown.




Figure 13

Insert assembled wine rack into the unit as shown.




Figure 14

Screw with fingers to help align screws before using screwdriver.

Attach Back Panel (**P**) to backside of assembled unit with Round Head Screws (**13**).

Tighten Screw (**13**) with a Phillips screwdriver.

Tip: Make sure the arrow on Back Panel (**P**) is pointing up.




Figure 15

Attach Left Drawer Side (**N**) and Right Drawer Side (**O**) to Drawer Back Panel (**L**). Make sure to line up grooves on panels (**N**, **O**, and **L**). Secure panels (**N**, **O**, and **L**) with medium Screws (**8**). Insert Drawer Bottom Panel (**M**) into corresponding grooves of Drawer Back Panel (**L**), Left Drawer Side (**N**) and Right Drawer Side (**O**). Insert Cam Locks (**3**) into corresponding holes on Left Drawer Side (**N**) and Right Drawer Side (**O**).

Screw Cam Bolts (**1**) into holes on backside of Drawer Front (**K**). Attach Drawer Front (**K**) to assembled drawer box by inserting Cam Bolts (**1**) into corresponding holes until Drawer Front (**K**) and assembled drawer box meet.

Tighten by rotating Cam Locks (**3**) clockwise with Phillips screwdriver.




Figure 16

Attach Left Male Slide (**21**) and Right Male Slide (**23**) with Flat Head Screws (**19**) to assembled drawer.

Tighten Flat Head Screws (**19**) with Phillips screwdriver.




Figure 17

Insert drawer into the unit.

Please check to make sure the drawer glides smoothly on the slides.




Figure 18

Attach Left Door **(I)** and Right Door **(J)** onto assembled unit using Hinges and Screws **(9)**.

Tighten Screws **(9)** with Phillips screwdriver.

Attach Metal Plates **(7)** on inside of door frame using Flat Head Screws **(19)**

Tighten Flat Head Screws **(19)** with Phillips screwdriver.




Figure 19

Push doors on the corner corresponding to the magnet to open, push again to close.




Figure 20

Attach Brackets **(26)** to back panel using Screws **(6)**.

Tighten Screws **(6)** using Philips screwdriver.

Mark two desired locations on wall and drill two 3/16" holes.

Insert Plastic Anchors **(25)** into two holes on wall as shown. Use a hammer to insert plastic anchors until they are flush with wall.

Then, attach Brackets **(26)** onto wall using Screws **(24)**.

Tighten Screws **(24)** using Philips screwdriver.




Figure 21

Move this item close to the wall Brackets **(26)** and tie in all Brackets **(26)** together with Plastic Straps **(27)** as shown in diagram.

Anti-tipping hardware must be used for this product to avoid tipping and injury.




Figure 22

Tip: If the Bar Cabinet is not level, please adjust the Leg's Levelers **(10)** by hand as shown.




Figure 23

Now your Harvey Mixed Tone Bar Cabinet is ready for use.

Parts Replacement Form

Customer Information

Name _____

Address _____

City/State/Zip Code _____

Phone Number _____

Please indicate where you purchased this item: Store/Website/Catalog

Please indicate color/size/style number:

Style No	Parts Letter	Parts Description	Quantity Needed
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

For product issues, please contact Southern Enterprises at 800-633-5096 (toll-free) / 972-869-0111 (Dallas) Mon-Fri 9am – 4pm CST, or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Customer Service 1-800-633-5096
service@seidal.com
Southern Enterprises, Inc.
600 Freeport Parkway, Suite 200
Coppell, Texas 75019