












10 X 20 PREMIUM PARTY CANOPY

Model #26763

Please read instructions completely before assembly



Description	Qty.	Part #	
 54.5" Swedged Rafter Poles	8	10091	
 76" Swedged Leg Poles	8	10043	
 77" Cross Poles 1 1/2"	9	10044	
	(Top Bend, shallow bend)		
	3-Way Frame Connectors	2	10046
	4-Way Frame Connectors	2	10048
	(Side Bend, sharp bend)		
	3-Way Frame Connectors	4	10045
	4-Way Frame Connectors	4	10047
 Cover	1	12020	
 Bungee Cords	40	10066	
 Short Pins w/rings 2 1/4"	8	10051	
 Long Pins w/rings 2 7/8"	8	10052	
 Foot Plates	8	10050	

ATTENTION:
BOLTS ARE NOT
NEEDED OR
INCLUDED FOR EVERY
CONNECTION BUT
MAY BE
PURCHASED BY CALL-
ING THE
NUMBER BELOW

**FOR MISSING ,
REPLACEMENT PARTS
OR
QUESTIONS
PLEASE CONTACT**

**CUSTOMER SERVICE:
1-800-524-9970**



150 Callender Road
Watertown, CT 06795

ATTENTION: PINS



8-2 1/4" Pins secure legs to side bends.
8-2 7/8" Pins secure feet plates to legs.

Pins are for legs and feet
only, and are NOT needed
for any other part of the
frame.

3/3/06


1. FRAME ASSEMBLY

Assembly is easiest if you layout all parts as shown in the area you intend to erect the shelter. Keep all non pipe parts on a tarp or box top.




2. CONNECT PIPES

Start with the center, then assemble each side.




3. PLACE COVER

Place cover over frame so that the grommetted portion is face down, this allows the valance to wrap around and cover the frame eaves.





4. ATTACHING LEGS

Insert both middle legs on one side of the frame, swaged end up, then the end legs on that same side. Repeat for the other side. Now you can secure the legs to the side bend connectors and secure the cover with bungee cords. **Note: Reference the diagram.**







5. SECURING LEGS

8 Short Pins are used to secure legs to side bend connectors.



6. SECURING COVER


Working inside, beneath the cover, begin with the corners. Insert the cord of the bungee-ball through the grommet and around the Cross Pole, then around the ball. By doing this from the inside it will hide the bungee-ball and give a cleaner look. When all 4 corners are secured, work from side to side to get an even fit.



To secure the valance corners wrap the upper hook and loop tie just below the elbow. Do the same for the lower hook and loop tie. Note: this will keep the valance from rolling up but still allow for movement.

7. ATTACHING & SECURING BASE FEET

Insert Base Foot Plates onto bottom of legs, be sure to line up the pre-drilled hole in the leg with the pre-drilled hole in the base foot. Insert PIN all the way through leg and foot, to other side, secure with ring.



CARE & CLEANING INFORMATION

DO NOT expose top or walls to open fire or flame. **DO NOT** use barbecue grills or smokers underneath canopy. **DO NOT** use harsh abrasives, bleach or cleansers. Cover and walls can be easily cleaned with mild soap and water. Periodically check stakes or anchors to ensure stability of unit, especially following exposure to high winds or heavy rain. **NOT** meant to hold snow load, brush snow off top with a broom or mop.

IMPORTANT: PLEASE READ CAREFULLY: ShelterLogic has no control over the elements such as wind, snow or heavy rain, we cannot be responsible for damage caused by the canopy or to the canopy. We suggest you contact your insurance carrier for information just as you would for any other outside structure. **This is a Temporary Structure and is not recommended as a permanent structure.** Safety glasses must be worn when securing bungees.

Improper Anchoring, Strong Winds, Snow or Ice: ShelterLogic does not guarantee these canopies in snow or ice under any circumstances. Canopies are designed to offer protection from damage caused by sun, light rain, tree sap, birds, and are not designed to hold the loads that accompany snow or ice. Any canopy that is not anchored securely or properly will fly away. We will not be responsible for any canopy that blows away. proper anchoring is your responsibility. We offer several anchoring kits, call customer service for more information or to place an order. Your canopy's cover can be quickly removed if needed when you know that a strong or severe weather front is approaching.

CAUTION! WARNING!

Bungee cords are under extreme tension. Please use caution when applying as they may snap out of your hand and cause injury. The use of safety goggles may help to prevent injury.