


Thank you for your purchase!



Glass Top Computer Desk with Pullout Keyboard

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Online Assembly Instructions: <http://ftp.flashfurniture.com/AssemblyInstructions/NAN-JN-2824S-GG.pdf>

Customer Service Email: CustomerExperience@belnick.com | Phone: 866-552-2810

NAN-JN-2824S-GG / NAN-JN-2824S-BK-GG / NAN-JN-2824S-WH-WH-GG

Have a Question/Concern?

Quality products and first-class customer service are the cornerstone of long-lasting consumer relationships. We strive toward excellence in all we do and want you to be completely satisfied with your purchase.

Please contact our exceptional Customer Experience Agents at the email address or phone number shown below to assist you with any product questions or issues before requesting a return.

We look forward to serving you in a friendly, efficient manner to resolve any issues you may have.

Customer Service Email: CustomerExperience@belnick.com

Customer Service Phone: 866-552-2810

Our Warranty Statement



This warranty covers manufacturing defects associated with your new product. The product is warranted from the original purchase date and to the original purchaser for normal usage, according to the below-referenced specifications and limitations.















- Non-moving metal parts are warranted for 5 years.
- Component parts including pneumatic cylinder, control mechanism, base and casters are warranted for 2 years.
- All other items are warranted for 1 year.

Normal usage means use in compliance with the restrictions and weight limits specified for the product. In the absence of product-specific restrictions and weight limits, normal usage means use for no more than forty hours per week by persons weighing 250 lbs. or less. Coverage terminates if the product is sold or otherwise transferred. Repairs made by parties other than Belnick also void this warranty.

This warranty will not cover: (1) labor, freight, or damage from misuse, abuse, negligence, alteration, assembly, installation, attachments, accident, vandalism, acts of nature or any other event beyond the control of Belnick; (2) tearing, scratching, scuffing, or blemishing of leather or fabric; (3) cosmetic damage that may result from normal usage; (4) damage attributable to use by persons exceeding specified weight limits or commercial use exceeding forty hours per week; or (5) rust or other damage caused by exposure to moisture. The user assumes all risk of injury resulting from use of this product. Liability for incidental or consequential damage is excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Attach Keyboard Glides (Parts 8 Left and 8 Right) to the Keyboard Arms (Parts I Left and I Right) using dome head screw (Part 5)



①		6PCs M6X55						
②		4PCs M6X35						
③		12PCs M6X12						
④		4PCs M4X14						
⑤		4PCs M4X14						
⑥	 Bolt and Cap Assembly	2PCs						
⑦		4PCs M6X21						
⑧	 Left Right	1SET						
<table><tr><th>Tool Required</th><th>Tool Included</th></tr><tr><td>Phillips Screwdriver</td><td>Allen key</td></tr><tr><td></td><td></td></tr></table>			Tool Required	Tool Included	Phillips Screwdriver	Allen key		
Tool Required	Tool Included							
Phillips Screwdriver	Allen key							
								

1 STEP 1: Cross the Left Leg (Part B) and Right Leg (Part C) and insert Bolt & Cap Assembly (Part 6). Attach Lower Leg Braces (Part D) to bottom of legs using (4) M6x12 bolts (Part 3). Set the Upper Leg Braces (Part A) on top of crossed legs (do not attach).

NOTE: Be sure back legs are aligned by looking for small hole near the bottom

2 STEP 2A: Attach Upper Leg Braces (Part A) to Front Bar (Part F) and Back Bar (Part E) with dimpled holes facing down using (4) M6x55 Bolts (Part 1). Attach Keyboard Arms (Part I Left & I Right) to Front and Back Bars using (4) M6x35 Bolts (Part 2).

STEP 2B: Attach Lower Brace (Part G) to back legs using (2) M6x55 Bolts (Part 1). Attach Back Frame Braces (Part H) to Lower Bar (Part G) and Back Bar (Part E) using (4) M6x12 Bolts (Part 3).

3 STEP 3: Attach Keyboard Tray (Part K) to Keyboard Arms (Parts I Left & I Right) USING (4) M4X14 Screws (Part 4).

4 STEP 4: Place Glass Desk Top (Part J) on top of front and back bars E & F. From the bottom of bars E & F (dimpled holes) screw (4) M6x21 Bolt s(Part 7) into the silver disks.