




















Multifunctional storage

Assembly Instructions















X5

Components


-  ① X1
-  ② X1
-  ③ X1
-  ④ X1
-  ⑤ X4
-  ⑥ X3
-  ⑦ X5
-  ⑧ X5
-  ⑨ X5
-  ⑩ X5
-  ⑪ X5
-  ⑫ X5
-  ⑬ X5
-  ⑭ X5
-  ⑮ X5
-  ⑯ X5

Screws & Tools


(A)		X57+1
(B)	 Ø15 x 9mm	X57+1
(C)	 Ø8 x 30mm	X28+1
(D)	 Ø6 x 30mm	X10+1
(E)	 Ø3.5 x 35mm	X25+1
(F)	 Ø3.5 x 12mm	X40+1
(G)		X1sets
(H)	 300MM	X5sets
(I)		X10
(J)		X2
(K)	 M4X8mm	X10
(L)	 Ø 3.5 x 12MM	X30+1
(M)		
(N)		

Check all the components & screws before assembly.
Do not install in case part is missing,contact us to get.
Send email with your question to support@idealhouse.vip
We will resend within 24 hours


How to use the cam lock system




1.Screw cam bolt into panel




2.Push cam into panel - arrow feature on cam top points to panel edge



3.Align cam bolt(s) with cam(s) and insert all the way into cross-bored hole(s)







3.Rotate cam(s) clockwise 190°-230° to lock panels together



5.Panels should be tight against each other and connection should be rigid


Insert the wood dowel [C] at least half way by tapping lightly with a rubber mallet ,IF NECESSARY.




- Unit must be placed on a level surface or leveled with included hardware (when applicable).
- Do not sit or stand on or allow children to climb,sit or stand on the assembled product.
- For safety reasons,it is imperative that this unit be mounted to the wall.
- Do not use without installing the tip restraint.
- Unit can tip over causing severe injury or death.
- Do not exceed the recommended weight limits.
- Evenly distribute the weight on each level and always keep the heavier loads on the bottom.
- Before cutting,drilling or hammering into any wall or floor surface,verify the location of electrical, plumbing and gas lines.Cutting may cause serious injury.

Ready to assemble the dresser

Before installation, observe each structure of the drawer dresser dresser. The drawer dresser consists of two main parts. You will assemble the chest first, and then install the five drawers. finally, look at the finished look, and contrast list of part, imagine how to install it faster, hope this will help you.





We recommend using a power drill to assemble.




Step 1





-Attach ① to ⑬ & ⑭ & ⑮ & ⑯



Tighten ① clockwise until all of their threads are engaged.






Warm Tips:
① should be screw to the small holes.



Step 2


- Attach ③ to ④
- Attach ⑬&⑮ to ③ as below shown
- Attach ⑭&⑯ to ④ as below shown
- Screw ① to lock the ③&④ as below shown





Warm Tips: Make sure the 4 large pre-drilled hole are on the upside
③&④holes should be in the same side.

Step 3

- Attach (A) to ③&④






Tighten (A) clockwise until all of their threads are engaged.





Step 4

-Install the drawer slides (H) on the left right side panel③&④.
When building it make sure to take note of the drawer slides is the one with a flat end.





Make sure the 4 large pre-drilled hole are on the upside.




(F)should be locked in the
Second hole against the pulley.


Step 5



- Screw(C)to④as below shown
- Attach⑤&②to④as below shown
- Screw(B)to lock the②&⑤as below shown





The two boards fit vertically,
place(B) and match their holes
with (A) then tighten (B) clockwise.




Step 6

- Screw(C)to③as below shown
- Attach⑤&②to③as below shown
- Screw(B)to lock the②&⑤as below shown





The two boards fit vertically, place(B) and match their holes with (A) then tighten (B) clockwise.




Step 7

- Screw(A)to①as below shown






Tighten (A) clockwise until all of their threads are engaged.




Step 8

- Screw(C)to③&④as below shown
- Attach top panel①to side boards③&④as below shown
- Screw(B)to lock the③&④as below shown






The two boards fit vertically, place (B) and match their holes with (A) then tighten (B) clockwise.



Step 9



- Screw(F)to Back panel①as below shown
- Stick(J)to①&⑥,use(G)locked



- Warm Tips:**
- ① It is recommended to put the product upside down when is talling the back plane.
 - ② It is recommended to attach the back panel⑥at the top panel①first






Step 10

- Attach⑧&⑨&⑪to⑩as below shown
- Stick(E)to⑨&⑩,use(G)locked
- Stick(E)to⑪&⑩,use(G)locked







Step 11

- Screw(A)to⑦as below shown
- Attach⑦&⑫to⑧&⑨&⑩&⑪as below shown
- Screw(B)to attach⑧&⑨&⑪



Step 12




-Screw(I)&(K)to⑦as below shown



X5

Step 13

-Install the drawer slides(H)on the drawer side panels⑧&⑨as below shown





The roller is facing
back ward



X5

Repeat the previous step to install the remaining drawers

Step 14




Step 15



The furniture must permanently be fixed to the wall using the provided anti-tipping device to prevent it from tipping over.

- Mark the drill positions on the wall with a pencil.
- Drill a small hole on the marked positions.
- Insert a wall anchor into the drilled hole.
- Fix the anti-tipping strap to the wall using the provided screws.



Tools required (not included): phillips screwdriver, stud finder, tape measure, pencil, power drill and 3/16" drill bit.

Now, follow the instructions printed on the plastic bag containing the tipping restraint hardware to attach the tip-over restraints to the unit and the wall..

NOTE: The tipping restraint hardware included is for wooden stud wall construction.

it must be attached to a wall stud. depending upon your wall construction, different anchor hardware maybe required. please contact your local hardware store for assistance. young children can be seriously injured by tipping furniture. you must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. the tipping restraints are intended only as a deterrent, they are not a substitute for proper adult supervision. the tipping restraints are not earthquake restraints. if you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.