USER'S GUIDE

PACKAGE COMPONENTS		
TACKAGE COMIT CHERTO		
A	Tent Body	
B	Rain Fly	
•	Awning Poles*2	
D	Tent Poles*4	
(3	Fiberglass Poles*2	
•	Stakes*14	G-
e	Guy Ropes*8	A.



It is recommended 2 adults work together to assemble the tent, ensuring a smooth and safe setup process.

- Please contact us if any accessories are missing.
- Please refer to the installation video on our product page to help you complete the installation process.
- If you have any questions, feel free to contact customer service.
- Amazon Contact: Log in to your Amazon account > select "Your Orders" > find the order ID > click "Contact Seller".

Disassembly Installation

- Leaving space to allow air to escape when repacking.
- Store all poles and stakes in their corresponding bags to prevent possible tearing or damage to fabric.

Warning

- Keep all flame and heat sources away from the tent fabric.
- To prevent carbon monoxide from entering the vehicle and the tent. DO NOT run the engine, cook inside the tent, or use a gas heater in the tent.
- Carbon monoxide is dangerous to your health.
- The engine must be turned off, and the exhaust must be fully cooled before installing and using the tent.

Caution

- Never run the engine while the tent is installed.
- Do not refuel lanterns, stoves, or heaters inside the tent.
- Do not cook inside the tent.
- Do not store flammable liquids inside the tent.
- Never allow the vehicle engine to run while you are inside the tent.
- Do not install the tent when the outside temperature is below 0°C/32°F, as it may cause damage.
- Do not install the tent when your vehicle is wet, as it may cause damage.

Choosing a Campsite

- Select a level site that is free of rocks, branches, and other hard or sharp objects for tent setup.
- Position the vehicle in the desired campsite. Turn off the engine and apply the parking brake.


How to set up the tent

1. Unfold the tent body (A) and lay it flat on the ground. Pre-assemble the fiberglass poles (B), then thread the fiberglass poles (B) through the pole sleeves, passing them through the center of the tent's roof. After that, insert both ends of the fiberglass poles (B) into the smaller hole of the corner connectors at the diagonally opposite corners.

NOTE: The poles may get stuck in the pole sleeve. Do not force the pole - gently lead it through the pole sleeve.




2. Pre-assemble the 4 tent poles **()** and insert one end of each tent pole **()** into the larger hole of the corner connectors. Then, tilt the pole and place the bottom end into the metal ring at the bottom corner of the tent. Insert the pin on the ring to secure the pole Next, hook the G-hook onto the middle of each tent pole to ensure stable support.



3. Place the rain fly **B** on top of the tent, then tie the four corner ropes inside the cover to the tent poles **D** for fixation. Next, attach the hooks on the rain fly to the metal rings at each of the four bottom corners of the tent.



4. Adjust the connection between the tent and the car's rear (it is recommended to open the trunk during installation), fix the webbing hooks onto the car in the order shown in the diagram, and then tighten the drawstrings.



5. Fix the four stake points at the bottom of the tent using the stakes (). Use two awning poles () to support the vestibule, and secure and tighten the guy ropes.

