


ASSEMBLY INSTRUCTION

SKU CODE: (WF288727-WF288728-WF288729)

This set is included 3 boxes if don't receive full 3 boxes please contact our customer service team



If you have any questions, please feel free to contact us.
Email: lowes.team@qualfurn.net

! SAFETY WARNINGS !

1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk, and lower bunk

Upper bed


Bed Type	Length	Width	Thickness
<i>Twin Standard</i>	<i>74" - 75"</i>	<i>38 1/2"</i>	<i>6" max</i>
<i>Full Standard</i>	<i>74" - 75"</i>	<i>53 "- 54 "</i>	<i>6" max</i>

Lower bed






















Bed Type	Length	Width	Thickness
<i>Twin Standard</i>	<i>74" - 75"</i>	<i>37 1/2"-38 1/2"</i>	<i>8" max</i>
<i>Full Standard</i>	<i>74" - 75"</i>	<i>53 "- 54 "</i>	<i>8" max</i>

2. Replacement parts, including additional guardrails, maybe obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC. 18961 ARENTH AVENUE CITY OF INDUSTRY, CA, 91748) dealers
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunkAlways use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part
11. Use of a night light may provide added safety precaution for a child using the upper bunk..
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited
14. STRANGULATION HAZARD - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes
15. Keep these instruction for future reference
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.














ASSEMBLY INSTRUCTION
























Part List (Box 1-WF288727)

L1  Leg-1pc	L2  Leg-1pc	L3  Leg-1pc
L4  Leg-1pc	L5  Leg-1pc	L6  Leg-1pc
L7  Leg-1pc	L8  Leg-1pc	M1  Horizontal Bars-2pcs
M2  Horizontal Bars-2pcs	M3  Horizontal Bar-1pc	M4  Horizontal Bar-1pc
M5  Horizontal Bar-1pc	M6  Horizontal Bar-1pc	M7  Horizontal Bar-1pc
M8  Horizontal Bar-1pc	M9  Horizontal Bar-1pc	M10  Horizontal Bar-1pc
M11  Horizontal Bars-2pcs	N1  Panels-2pcs	N2  Panels-2pcs












Part List (Box 1-WF288727)

<div>N3</div> <div></div> <div>Panels-4pcs</div>	<div>N4</div> <div></div> <div>Vertical Bars-4pcs</div>	<div>P1</div> <div></div> <div>Back Panels-2pcs</div>
<div>P2</div> <div></div> <div>Top Panel-1pc</div>	<div>P3</div> <div></div> <div>Top Panel-1pc</div>	<div>P4</div> <div></div> <div>Top Panel-1pc</div>
<div>P5</div> <div></div> <div>Top Panel-1pc</div>	<div>P6</div> <div></div> <div>Top Panels-2pcs</div>	<div>P7</div> <div></div> <div>Top Panel-1pc</div>
<div>P8</div> <div></div> <div>Horizontal Bar-1pc</div>	<div>P9</div> <div></div> <div>Front Panel-1pc</div>	<div>P10</div> <div></div> <div>Door-1pc</div>
<div>P11</div> <div></div> <div>Doors-2pcs</div>		












Part List & Hardware List (Box 2-WF288728)

A1  Leg-1pc	A2  Leg-1pc	A3  Leg-1pc
A4  Leg-1pc	A5  Leg-1pc	A6  Leg-1pc
A7  Leg-1pc	A8  Leg-1pc	A9  Leg-1pc
A10  Leg-1pc	C1  Side Rail-1pc	C2  Side Rail-1pc
C3  Side Rail-1pc	C4  Side Rail-1pc	C5  Side Rail-1pc
C6  Side Rail-1pc	C7  Side Rail-1pc	C8  Side Rail-1pc
D1  Guardrails(Front-Left)- 2pcs	D2  Guardrails(Front-Right)- 2pcs	D3  Guardrails(Back-Left)- 2pcs





















Part List & Hardware List (Box 2-WF288728)


D4	 Guardrails(Back-Right)- 2pcs	D5	 Rails- 2pcs	D6	 Rail- 1pc
H2	 Side panel-1pc	H3	 Side panel-1pc	H4	 Back panel-1pc
K1	 Drawer-Front panel-1pc	K2	 Drawer-Back panel-1pc	K3	 Drawer-Side panel-1pc
K4	 Drawer-Side panel-1pc	K6	 Drawer-Support Bottom panel-1pc		

Part List (Box 3-WF288729)

<div>B1</div> <div></div> <div>Wood Bars-2pcs</div>	<div>B2</div> <div></div> <div>Wood Bar-1pc</div>	<div>B3</div> <div></div> <div>Wood Bars-3pcs</div>
<div>B4</div> <div></div> <div>Wood Bars-4pcs</div>	<div>B5</div> <div></div> <div>Wood Bars-2pcs</div>	<div>B6</div> <div></div> <div>Wood Bars-2pcs</div>
<div>E</div> <div></div> <div>Slats-28pcs</div>	<div>H1</div> <div></div> <div>Top panel-1pc</div>	<div>K5</div> <div></div> <div>Drawer-Bottom panel-1pc</div>
<div>F</div> <div></div> <div>Top panel-1pc</div>	<div>G</div> <div></div> <div>Center Frame-1pc</div>	

Hardware List(Box 2-WF288728)

1	 Ø10 x 40 mm Wood dowel 24pcs	2	 Screws 1/4" x80 34pcs	3	 Screws 1/4" x70 16pcs
4	 Ø1/4" x 100 mm Hex-Head bolts 32pcs	5	 Ø1/4" x 13 mm Horizontal-Hole bolts 40pcs	6	 Allen Key 1pc
7	 Ø1/4" x 35 mm Hex-Head bolts 8pcs	8	 Ø1/4" x 15 mm Canopy head though -2cs	9	 M4 x 30 mm Wood Screws 69pcs
10	 Screws 1/4" x30 14pcs	11	 Screws 1/4" x50 6pcs	12	 Ø1/4" x 25 mm Hex-Head bolts 24pcs
13	 Ø1/4" x 60 mm(Đầu 12) Hex-Head bolts 10pcs	14	 Ø8 x 30 mm Wood dowel 8pcs	15	 M4 x 15 mm Wood Screws 14pcs
16	 Ø1/6" x 25 mm Hex-Head bolts 1pcs	17	 Handle Wood 1pcs	18	 Ø12 x 70 mm Wood dowel 4pcs
19	 M3 x 12 mm Wood Screws 18pcs	20	 Pan head Screw M4x15 12pcs		






Assembly Tools Required (Not Included)

STEP1: Following below illustration Assembly Bottom bed's Footboard .

-Using hardware #2 and dowel #1 connect A1,A2 legs with B1 Woodbar

-Using hardware #2 and dowel #1 connect A3,A4 legs with B1 Woodbar

2	1
	
4x2(pcs)	2x2(pcs)



STEP 2: Following below illustration Assembly Bottom bed's Headboard .







-Using hardware #3 connect B3,B4,B6 Woodbar with A8,A9 Legs

-Using hardware #3 connect B3,B4,B6 Woodbar with A7,A10 Legs

3



4x2(pcs)



STEP 3: Following below illustration

-Using hardware #3 connect B3,B4,B5 Woodbar with A5 Leg





-Using hardware #3 connect B2,B4,B5 Woodbar with A6 Leg

3



4(pcs)




LEFT




RIGHT

STEP 4: Following below illustration Using hardware #4, #5 and dowel #1

follow detail view to Assembly Bottom bed's Headboard (Completed on step 2) and Footboard (Completed on step 1) with siderail C3,C4.Look at detail view for more detail




5		4		1	
8(pcs)		8(pcs)		4(pcs)	




Inside Side Rail View

STEP 5: Following below illustration

-Using hardware #3,#7,#8 connect Frame(completed on step 4) withFrame (completed on step 3)

8	7	3
		
1(pcs)	1(pcs)	2(pcs)



STEP 6: Following below illustration:


-Screw 7slats E with Side Rail C3,C4 by using hardward #9.

-Look at detail view for more detail

9







14(pcs)



STEP 7: Following below illustration Using hardware #4, #5 and dowel #1

follow detail view to Assembly Bottom bed's Headboard (Completed on step 2) and Footboard (Completed on step 1) with siderail C1,C2.Look at detail view for more detail

4	1
	
8(pcs)	4(pcs)
	5
	
	8(pcs)




Inside Side Rail View

STEP 8: Following below illustration

-Using hardware #3,#7,#8 connect Frame(completed on step 7) withFrame (completed on step 3)

8	7	3
1(pcs)	1(pcs)	2(pcs)



STEP 9: Following below illustration:


-Screw 7slats E with Side Rail C1,C2 by using hardware #9.

-Look at detail view for more detail

9



14(pcs)




STEP 10: Following below illustration:

- Using hardware #10 connect Side Rails C7,C8 and Guardrails D3(x2),D4(x2) with Rails D5(x2),D6
- Look at detail view for more detail

10









12(pcs)



STEP 11: Following below illustration:

-Using hardward #4,#5,#10 and dowel #1 connect Frame (Completed on step 9) and Frame (Completed on step 6) with Frame (Completed on step 10) ,Side Rail C5,C5 and Guardrails D1(x2),D2(x2) .
Look at detail view for more detail

4	1
	
16(pcs)	12(pcs)
5	10
	
16pcs	2(pcs)



Detail 1


STEP 12: Following below illustration

-Using hardware #11 connect Frame(completed on step 11) with G Frame

11



4(pcs)




STEP 13: Following below illustration

-Using hardware #12 connect Frame(completed on step 12) with Panel F

12







8(pcs)



STEP 14-1: Following below illustration:


-Using hardward #5,#13 and dowel #14 to connect H2,H3 panels with H1 panel




13	14
	
4(pcs)	4(pcs)
	5
	
	4pcs

STEP 14-2: Following below illustration:

-Using hardward #15 to connect Frame(completed on step 14-1) with Back panel H4



15

3(pcs)

STEP 15: Following below illustration:

-Using hardward #5,#13 to connect Frame (completed on step 13) with Frame (completed on step 14-2)

5





4pcs


13



4(pcs)



STEP 16-1:



17




1(pcs)

16



1(pcs)

STEP 16-2:




9



2(pcs)

STEP 16-3:




9




3(pcs)

STEP 17: Push 1 drawer into it position



STEP 18: Following below illustration

- Using hardware #2 to Assembly M1,M2,M4 Woodbar with Legs L1,L3
- Using hardware #2 to Assembly M1,M2,M3 Woodbar with Legs L2,L4
- Look at detail view for more detail



STEP 19: Following below illustration


- Using hardward #2 to Assembly N4,M5,M8,M9,M11 Woodbar and N2,N3(x2) panels with Legs L7,L8
- Using hardward #2a to Assembly N4,M6,M7,M10,M11 Woodbar and N2,N3(x2) panels with Legs L5,L6
- Look at detail view for more detail

2




16(pcs)

(LEFT)





(RIGHT)





STEP 20: Following below illustration

-Using hardward #9 and Dowel #18 to Assembly Frames(completed on step 18) and N4 woodbar,N1 Panel with Frame(completed on step 19)
Look at detail view for more detail

18		9	
4pcs		4x2 pcs	

(LEFT)



(RIGHT)


STEP 21: Following below illustration

-Using hardware #11 to Assembly Frames(completed on step 20)
with P8 wood bar
.Look at detail view for more detail

11



2(pcs)




STEP 22: Following below illustration

-Using hardware #19 to Assembly Hinge with P7(x1),P6(x2) panels
.Look at detail view for more detail

19



18(pcs)



STEP 23: Following below illustration

Using hardware #12 and dowel #14 to Assembly Frames(completed on step 21) with L6 panel, L7 frame(completed on step 14).Look at detail view for more detail

12




4pcs

14



4pcs



STEP 24: Following below illustration


-Using hardward #12 to Assembly Frame(completed on step 23) with P2 panel,P6 Frames(completed on step 22)

Look at detail view for more detail

12



12pcs



STEP 25: Following below illustration


-Using hardward #15 to Assembly Frame(completed on step 24) with P3,P4,P5 panels

-Look at detail view for more detail

15



14 pcs




STEP 26: Following below illustration

- Using hardward #20 to Assembly Frames(completed on step 25) with P1(x2) panels
- Look at detail view for more detail

20



12 pcs




STEP 27: Following below illustration

- Using hardware #7 to Assembly Frame(completed on step 17) with Frame(completed on step 26)
- Look at detail view for more detail

7





6(pcs)



STEP 28: Following below illustration

- Using hardware #13 to Assembly Stair With Bed
- Screw 14 slats E with Side Rail C5,C6,C7,C8 by using hardware #9.
- Look at detail view for more detail



28(pcs)

13



2(pcs)

