










Installation video




1x10



2x10




3x5




4x8




Ax8




Bx4




Cx2




Dx2






1




Using a small hammer, tap the flat side of part #1 (flat side up) so that the circular slot in part #1 is completely inside the hoist hole in part #4 (as shown), and note that the hoist hole in part #4 has the large opening facing up and the small opening facing down.

Install the other lower side frame in the same way, taking care to keep the installation height consistent




2





Using a small hammer, tap the flat surface of part #1 (with the flat surface facing up) so that the circular slot in part #1 is completely inside the hoist hole in part #4 (as shown), and note that the hoist hole in part #4 has the large opening facing up and the small opening facing down.

Install the other lower side frame in the same way, taking care to keep the installation height consistent





3




 **A×8**

4




Using a small hammer, tap the flat side of part #2 (flat side up) so that the circular slot in part #2 is completely inside the hoist hole in part #4 (as shown), and note that the hoist hole in part #4 has the large opening facing up and the small opening facing down.

Install 3, part #2 in the same way.




5






B×4

6




7



Snap part #1 into the hoist holes on the lower part of part #4 and the upper part of part #4 respectively. And tap them flat with a small hammer



8




Snap part #2 into the hoist holes on the lower part of part #4 and the upper part of part #4 respectively. And tap them flat with a small hammer




Install the remaining part #2 (connect in the same manner)

9







 Cx2

10






This step is to connect the cabinet to the wall, if you do not need to ignore it



 Dx2

11



12

