

### **ASSEMBLY INSTRUCTIONS**

## TWIN SIZE - MONTESORI HOUSE BED WITH FENCE


If you have any questions, please feel free to contact us. Email: lowes.team@qualfurn.net



WF294208




#### **ASSEMBLY INSTRUCTIONS**



## **ASSEMBLY INSTRUCTIONS**


1	<b>2</b>	<b>3</b>
Ø10*30mm	Ø6" x 85 mm	Ø6" x 70 mm
Wood dowel (42pcs)	Wood Screws (4pcs)	Wood Screws (18pcs)
4	<b>5</b>	6
Ø6" x 100 mm	Ø6" x 30 mm	(1/4")4.5*58mm
Wood Screws (14pcs)	Wood Screws (2pcs)	Allen Key (1pc)
7	<b>8</b>	
Ø6" x 50 mm	#4*25mm	
Wood Screws (4pcs)	Screw (58pcs)	


ASSEMBLY TOOLS REQUIRED ( N








PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS!











# COMPLETED

