


# ASSEMBLY INSTRUCTIONS

## TWIN HOUSE BUNK BED WITH STAIRCASE



If you have any questions, please feel free to contact us.  
Email: [lowes.team@qualfurn.net](mailto:lowes.team@qualfurn.net)

**WF314662/WF314663**

## SAFETY WARNINGS AND GENERAL NOTES:

Follow the information on the warnings on the bunk bed end structure and on the carton. Do not remove the warning label from the bed. Always use the recommended size mattress on mattress support, or both, to help prevent the likelihood of entrapment or falls.

The top surface of the mattress must be at least 5\*inch (127mm) below the upper edge of the guardrail.

Do not allow children under 6 years of age to use the upper bunk.

Periodically check and ensure the guardrail, ladder and other components are in their proper position, free from damage, and all connectors are tight.

Do not allow horseplay on or under beds.

Always prohibit jumping on the bed.

Prohibit more than one person on upper bunk.

Always use the ladder for entering and leaving the upper bunk.

Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.

Use of a night-light may provide added safety precaution for a child using the upper bunk.

Always use guardrails on both long sides of the upper bunk.

If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.

The use of water or sleep flotation mattresses is prohibited.

**STRANGULATION HAZARD**-Never attach or hang items to any part of the bunk bed that are not designed for use with the bed.

Keep these instructions for future reference.

We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet.

Be certain all staples are out of the box before beginning assembly on the shipping carton.


THIS BED IS DESIGNED TO USE A TWIN MATTRESSES 38 1/2" WIDE X 74"-75" LONG WITH THE TOTAL THICKNESS NOT EXCEEDING 6" FOR UPPER BUNK, FOR THE LOWER FULL-SIZE SHOULD BE 54" WIDE X 74"-75" LONG, WIDE WITH 8" THICKNESS.

**SURFACE OF MATTRESS MUST BE AT LEAST 5" (127MM) BELOW THE UPPER EDGE OF GUARDRAILS.**

Replacement Parts:































Replacement Parts, including additional guardrails, may be obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC. 18961 ARENTH AVENUE, CITY OF INDUSTRY , CA, 91748.) dealers

## Detail View


























# Part List

## WF314662 - Hardware inside
















<b>A</b>  Leg (Left Back) - 1pc	<b>A1</b>  Leg (Left Front) - 1pc	<b>A2</b>  Horizontal bar HB/FB - 3pcs
<b>A3</b>  Divider horizontal bar FB - 1pc	<b>A4</b>  Lower horizontal bar FB - 1pc	<b>A5</b>  Upper horizontal bar FB - 1pc
<b>A6</b>  Side panel FB - 1pc	<b>A7</b>  Vertical bar FB - 1pc	<b>A8</b>  Vertical guard rail FB - 1pc
<b>B</b>  Leg (Right Front) - 1pc	<b>B1</b>  Leg (Right Back) - 1pc	<b>B2</b>  Divider horizontal bar HB - 2pcs
<b>C1</b>  Upper horizontal bar (Left Front/Right Back) - 2pcs	<b>C2</b>  Upper horizontal bar (Left Back/Right Front) - 2pcs	<b>C3</b>  Panel (Front/Back) - 3pcs
<b>D</b>  Long guard rail (Front) - 1pc	<b>D1</b>  Long guard rail (Front) - 1pc	<b>D2</b>  Long guard rail (Back) - 1pc
<b>E</b>  Upper side rail (Front) - 1pc	<b>F</b>  Upper side rail (Back) - 1pc	<b>G</b>  Lower side rail - 2pcs
<b>H</b>  Lower horizontal bar (Back) - 1pc	<b>J</b>  Horizontal bar - 2pcs	<b>J2</b>  Vertical bar - 2pcs
<b>K</b>  Horizontal bar - 2pcs	<b>K1</b>  Vertical bar - 2pcs	<b>L</b>  Vertical bar (Front/Back) - 2pcs
<b>M</b>  Upper slat - 14pcs	<b>Q</b>  Vertical bar (Back) - 1pc	<b>Q1</b>  Vertical bar (Divider) - 1pc

# Part List


WF314663

<b>C</b>  Upper horizontal bar - 1pc	<b>B3</b>  Side panel HB - 1pc	<b>H1</b>  Lower horizontal bar (Front) - 1pc
<b>J1</b>  Side panel (Front) - 1pc	<b>L1</b>  Support panel - 1pc	<b>N</b>  Lower slat - 7pcs
<b>P</b>  Guard rail (Back) - 1pc	<b>Q2</b>  Vertical bar (Front) - 1pc	<b>Q3</b>  Horizontal bar - 3pcs
<b>Q4</b>  Horizontal bar - 3pcs	<b>R</b>  Upper step ladder panel -1pc	<b>R1</b>  Upper center step ladder panel -1pc
<b>R2</b>  Lower center step ladder panel -1pc	<b>R3</b>  Bottom panel -1pc	<b>R4</b>  Upper right side panel - 1pc
<b>R5</b>  Upper left side panel - 1pc	<b>R6</b>  Center right side panel - 1pc	<b>R7</b>  Center left side panel - 1pc
<b>R8</b>  Lower right side panel - 1pc	<b>R9</b>  Lower left side panel - 1pc	<b>S</b>  Support lower panel - 2pcs
<b>T</b>  Front panel - 3pcs	<b>U</b>  Back panel - 1pc	

## Hardware List WF314662


<b>1</b>	 Ø10*40mm Wood dowel (6pcs)	<b>2</b>	 Ø8*30mm Wood dowel (17pcs)	<b>3</b>	 (Ø15)1/4"*100mm Hex-Head bolts (18pcs)
<b>4</b>	 (Ø15)1/4"*80mm Hex-Head bolts (29pcs)	<b>5</b>	 (Ø12)1/4"*60mm Hex-Head bolts (38pcs)	<b>6</b>	 (Ø12)1/4"*40mm Hex-Head bolts (2pcs)
<b>7</b>	 (Ø12)1/4"*30mm Hex-Head bolts (15pcs)	<b>8</b>	 1/4"*15 (9.5mm) Horizontal-Hole bolts(83pcs)	<b>9</b>	 (Ø12)1/4"*65mm Hex-Head bolts (24pcs)
<b>10</b>	 Ø4*30mm Wood screws (42pcs)	<b>11</b>	 Ø3.5*15mm Wood screws (32pcs)	<b>12</b>	 (1/4")4.5*58mm Allen key (1pc)
<b>13</b>	 42*12*1mm Metal magnet (3pcs)	<b>14</b>	 45*17*13mm Door catch (3pcs)	<b>15</b>	 40*18*18*1.6mm Metal bracket (2pcs)



### ASSEMBLY TOOLS REQUIRED ( NOT INCLUDED )




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !

## STEP 1:




<b>4</b>		<b>8</b>	
<b>6PCS</b>		<b>6PCS</b>	






Note: Part 8 will face up with the "x" mark on it, otherwise it cannot be tightened

## STEP 2:




### STEP 3:







<b>4</b>		<b>8</b>	
<b>8PCS</b>		<b>8PCS</b>	

Note: Part 8 will face up with the "x" mark on it, otherwise it cannot be tightened






### STEP 4:






<b>1</b>		<b>3</b>	
<b>6PCS</b>		<b>18PCS</b>	
		<b>8</b>	
		<b>18PCS</b>	







## STEP 5:




4		8	
4PCS		4PCS	
		9	
		4PCS	

## STEP 6:




11		15	
8PCS		2PCS	


## STEP 7:



## STEP 8:



## STEP 9:




9



4PCS

## STEP 10:



7




4PCS

## STEP 11:

9



4PCS




## STEP 12:


7





4PCS






STEP 13:




11	14
	
2PCS	1PC



STEP 14:





11	14
	
2PCS	1PC


STEP 15:






11	14
	
2PCS	1PC


STEP 16:

5		8	
2PCS		2PCS	






STEP 17:

2		5		8	
1PC		4PCS		4PCS	







## STEP 18:

<b>5</b>		<b>8</b>	
<b>2PCS</b>		<b>2PCS</b>	





## STEP 19:

<b>2</b>		<b>5</b>		<b>8</b>	
<b>3PCS</b>		<b>6PCS</b>		<b>6PCS</b>	







STEP 20:

2	
4PCS	




STEP 21:




2		5		8	
4PCS		4PCS		4PCS	





## STEP 22:




## STEP 23:





## STEP 24:

<b>11</b>	<b>13</b>
	
<b>6PCS</b>	<b>3PCS</b>



## STEP 25:

<b>11</b>

<b>12PCS</b>




## STEP 26:

9



6PCS




## STEP 27:


9






6PCS





## STEP 28:




5		7		8	
2PCS		4PCS		2PCS	

## STEP 29:




5	
2PCS	

## STEP 30:



## STEP 31:





## STEP 32:

10



28PCS



**NOTE:** Please make sure the bed slats close to the side rail before locking the screws to avoid breakage. This step is required for both the left and right sides. Moreover, please do not lock the screws of the bed slats at the outermost edge to avoid damaging.

## STEP 33:

2



4PCS

4




8PCS

8



8PCS




## STEP 34:


10



14PCS



**NOTE:** Please make sure the bed slats close to the side rail before locking the screws to avoid breakage. This step is required for both the left and right sides. Moreover, please do not lock the screws of the bed slats at the outermost edge to avoid damaging.



**Make sure to tighten all the screws of the bed.**