




12' x 20' Louver Pergola


Assembly Instructions



Paragon Group USA

Customer Service: (877) 782 4482 Email: cs-outdoors@paragongroupusa.com

Introduction



Thank you for purchasing the 12' x 20' Louver Pergola .

When properly assembled and maintained, this pergola will provide many years of enjoyment!

These instructions include helpful hints and important information needed to safely assemble and properly maintain the pergola. Please read these instructions completely before you begin.

Our patented pergola has been designed for easy assembly. All steps can be completed by a team of four people.

Before Starting Assembly:

CAREFULLY READ ALL THE INSTRUCTIONS BEFORE YOU BEGIN AND FOLLOW THE STEPS IN THE ORDER THEY ARE PRESENTED.

1. Make sure you have all the necessary parts:

Compare the contents of all cartons to the List of Parts. If any parts are missing or damaged, or you have any questions, please contact Customer service (877)782 4482 before beginning assembly.

2. Lay the parts out in separate staging areas:

The List of Parts has the corresponding step number referenced to each part. We recommend that while you go through the list, make staging areas for each step and place the parts necessary for each step in these areas. This will save you time and effort during assembly.

3. Select a Location:

When selecting a location for your pergola, a flat level area is essential and if possible with proper water drainage and easy access to power and water, if necessary.

Choose a sunny, level position away from overhanging trees and power lines and protected from the wind as much as possible. Locate underground pipes or cables before preparing the site or anchoring the pergola.

Note: You may assemble the pergola on a hard level surface and move it to its final location when finished. Make sure that there are no obstacles between the assembly area and the final position.

4. Prepare a Foundation:

After choosing a location, proper preparation of the site is recommended. The site must be level.

If the site is not level, create a base slightly larger than the outside dimensions of the pergola using a perimeter of two by fours filled with either soil, sod or gravel.

Make sure the base is square by measuring the diagonals from both directions and making sure they are equal. The pergola is secured with pegs into holes cast with concrete.

If you decide to have a concrete base, it is best to contact a reliable contractor to make sure it is flat and level. Make sure you have checked with your local authorities regarding any required building permits.

5. Make sure you have the proper tools:

- Tape Measure
- Work Gloves
- Safety goggles
- Phillips Screwdriver
- Spirit Level
- 3/8" masonry drill bit to drill holes for the concrete anchors supplied.
- 2 Small Step Ladders
- Wooden Mallet
- Scissors and knife
- Liquid soap or WD40 Lubricant
- Silicon Gel

NOTE: A cordless drill with Phillips head bit is highly recommended but not essential.

Safety Advice

- The pergola must be positioned and fixed on a flat level surface.
- Dispose of all plastic bags safely. Keep them out of the reach of children.
- Keep children and pets away from the assembly area until the work is completed.
- Always wear shoes, gloves and safety goggles when working.
- Take special care not to touch overhead power lines with the aluminium profiles.
- Do not attempt to assemble the pergola in windy or wet conditions.
- Do not position your pergola in an area exposed to excessive wind.
- If using power tools or a ladder, always follow the manufacturers safety instructions.
- Hot items such as recently used grills, blowtorches etc. must not be stored in the pergola.
- Make sure the pergola complies with local building codes.



ATTENTION:


DO NOT ATTEMPT TO
ASSEMBLE THE
PERGOLA ALONE!

Table of Contents

Introduction.....	2
Table of Contents.....	3
List of Parts.....	4
Step 1 : Assembling the Louvers.....	8
Step 2 : Connecting the Roof Profiles.....	9
Step 3 : Connecting the Roof Profiles.....	10
Step 4 : Building the Basic Roof Frame.....	12
Step 5 : Building the Corner Profiles.....	18
Step 6 : Installing the Louvers.....	20
Step 7 : Installing the Louvers.....	28
Step 8 : Secure the Pergola to a Concrete Floor or Wood Deck.....	30

General Order of Assembly



















- Step 1** : Assembling the Louvers
- Step 2** : Connecting the Roof Profiles
- Step 3** : Connecting the Roof Profiles
- Step 4** : Building the Basic Roof Frame
- Step 5** : Building the Corner Profiles
- Step 6** : Installing the Louvers
- Step 7** : Installing the Louvers
- Step 8** : Secure the Pergola to a Concrete
Floor or Wood Deck



























































List of Parts





The pergola is shipped in eight cartons. These cartons are heavy. Be careful when lifting them. Wear proper safety gear including work shoes, gloves and goggles. The parts are identified by removable stickers. Place all the parts for each step in staging areas, checking that you have all parts as you go. If any parts are missing or damaged, contact customer service before beginning assembly:
Customer Service:(877) 782 4482 Email:cs-outdoors@paragongroupusa.com

No.	Profile	Qty	Step	Box	No.	Profile	Qty	Step	Box
1	 Corner Profile 2190mm	4	5	1	5A	 Roof Profile 1492mm	2	3	3
1A	 Corner Profile 2190mm	2	5	3	6	 Roof Profile 2190mm	1	2	1
2	 Roof Profile 2190mm	2	3	1,3	7	 Roof Profile 1404mm	1	2	2
2A	 Roof Profile 2190mm	1	3	3	8	 Roof Profile 2190mm	1	2	1
3	 Roof Profile 1354mm	2	3	2,3	9	 Roof Profile 1404mm	1	2	2
3A	 Roof Profile 1354mm	1	3	3	10	 Louver 1420mm	156	1	6,7,8
4	 Roof Profile 1472mm	2	3	2	11	 Support Plate	6	5	4
4A	 Roof Profile 1492mm	2	3	3	12	 Support Plate	14	5	4
5	 Roof Profile 1472mm	2	3	2	13	 Roof Profile connector	4	4	4

No.	Profile	Qty	Step	Box	No.	Profile	Qty	Step	Box
14	  Roof Profile connector	6	4	4	24	  Roof profile connector	2	3	5
15	  Louver connector	312	1	4	25	  Roof profile connector	2	3	5
16	  Corner profile cover	2	2	4	26	  Roof Profile connector	2	3	5
17	  Corner profile cover	2	2	4	27	  Roof Profile connector	2	3	5
18	  Roof Profile connector	2	2	5	28	  Louver mount 2019mm	2	4	1
19	  Roof Profile connector	2	2	5	29	  Louver mount 1575mm	2	4	1
20	  Roof Profile connector	6	2,3	5	30	  Louver mount 1994mm	6	4	1,3
20A	  Roof Profile connector	2	2	5	31	  Louver mount 1550mm	6	4	1,3
21	  Roof Profile connector	8	2,3	4	34	  Roof Profile connector	6	3	4
22	  Roof profile connector	2	4	5	35	  Roof Profile connector	2	3	5
23	  Roof profile connector	2	4	5	35A	  Roof Profile connector	1	3	5

No.	Profile	Qty	Step	Box	No.	Profile	Qty	Step	Box
36	 Roof Profile connector	2	3	5	46	 Ring cap	2	3	5
36A	 Roof Profile connector	1	3	5	47	 Screw M4x10mm	636	1,3,6,7	5
37	 Roof Profile connector	4	4	4	48	 Screw 1/4"x12mm	28	1,3,6,7	5
38	 Stopper	2	3	5	49	 Screw 1/4"x15mm	268	2,3,4,5	5
39	 Louver puller	4	6	1,3	50	 Screw 1/4"x13mm	156	6	5
40	 Louver puller	2	6	1,3	51	 Screw 1/4"x25mm	312	4	5
41	 Louver puller	2	6	1,3	52	 Screw 1/4"x70mm	2	7	5
42	 Puller connector	4	7	5	53	 Nut 1/4"	328	3,4,6,7	5
43	 Corner profile cover	2	3	4	54	 Nut 1/4"	318	6,7	5
44	 Controller cover	2	7	5	56	 Plastic washer	156	6	5
45	 Controller	2	3	5	57	 Rivet	2	3	5

No.	Profile	Qty	Step	Box
58	 Rocker	1	7	1
59	 Concrete bolts, washers M8x70mm	24	7	5
60	 Magnetic hex key	1		5

No.	Profile	Qty	Step	Box
61	 Screw 1/4"x50mm	4	3	5
62	 Roof Profile connector	3	3	5

We included extra screws for your convenience.

STEP 1 Assembling the Louvers



Place all the parts on a level surface.
Make sure the pieces are in the correct positions before assembling.
Carefully follow the order of assembly to ensure an easy installation.
Wear proper safety gear including work shoes, gloves and goggles.


1.A

Attach louver connector (15) on louver (10) by screw (47).

Components




Louver(10)
x 156



Louver connector(15)
x 312




Screw(47)
x 624




IMPORTANT:

Make sure all the louver connectors installed in correct direction as shown.

1.B



1.C





STEP 2 Connecting the Roof Profiles 6+7 、 8+9

Components

Roof Profile(6) x 1	Roof Profile(7) x 1	Roof Profile(8) x 1	Roof Profile(9) x 1	Corner profile cover(16) x 2	Corner profile cover(17) x 2
Roof Profile connector(18) x 2	Roof Profile connector(19) x 2	Roof Profile connector(20) x 2	Roof Profile connector(21) x 2	Screw(48) x 8	Screw(49) x 32




2.A

Connect roof profile (6,7) and (8,9) by roof profile connector (21,20) with screw (48) on the TOP and screw (49) on the SIDE and BOTTOM as shown.



2.B

Insert roof profile connector (18,19) into roof profile (6/9) and (7/8), fasten with two screw (49) each as shown. Attach corner profile cover (16/17) on roof profile (6/9) and (7/8) by screw (49) underneath of corner profile cover (16/17).





STEP 3 Connecting the Roof Profiles 2+3 、 4+5

Components

Roof Profile(2) x 2	Roof Profile(2A) x 1	Roof Profile(3) x 2	Roof Profile(3A) x 1	Roof Profile(4) x 2	Roof Profile(4A) x 2	Roof Profile(5) x 2	Roof Profile(5A) x 2
Roof Profile connector(20) x 4	Roof Profile connector(20A) x 2	Roof Profile connector(21) x 6	Roof Profile connector(24) x 2	Roof Profile connector(25) x 2	Roof Profile connector(26) x 2	Roof Profile connector(27) x 2	Roof Profile connector(62) x 3
Roof Profile connector(34) x 6	Roof Profile connector(35) x 2	Roof Profile connector(35A) x 1	Roof Profile connector(36) x 2	Roof Profile connector(36A) x 1	Stopper(38) x 2	Corner Profile cover(43) x 2	Controller(45) x 2
Ring cap(46) x 2	Screw(47) x 4	Screw(48) x 12	Screw(49) x 102	Nut(53) x 4	Rivet(57) x 2	Screw(61) x 4	

3.A


Connect roof profile (4A/5,4/5A) by roof profile connector (21,20) with TWO screw (48) on the top of roof profile connector(21), as shown, we need the 2 empty holes for installing roof profile connector(37) in later step.
Attach 6 screw (49) on the SIDE and BOTTOM of roof profile connector(20) as shown.



Connect roof profile (5A.4A) by roof connector (21.20A) with two screw (48) on the top of roof profile connector (21), exactly as shown, we need the 2 empty holes for installing roof profile connector (37) and corner profile cover (43) in later step.
Attach 4 screw (49) on the side of roof profile connector (21A).


3.B

Insert roof profile connector (24/25) into hollow ends of roof profile (5,4) with two predrilled holes facing inside as shown, and fasten with screw (49).
Insert roof profile connector (26/27) into hollow ends of roof profile (5,4) with two predrilled holes facing upward at the same position of roof profile (5,4) pre-drilled holes as shown and held in place for step 4.A.




3.C

Attach corner profile cover (43) on connector roof profile 4A+5A by 2 screw (49) from underneath.
Connect roof profile (2,2A/3,3A) by roof profile connector (62) with screw (49) on the TOP and screw (49) on the SIDE and BOTTOM as shown.







VIEW FROM INSIDE



3.D


Insert roof profile connector (36/35) into hollow ends of roof profile (2,3) and fasten with two screw (49) on the side and ONE screw (49) at the furthest position of the three pre-drilled holes underneath as shown.
Insert roof profile connector (34) into hollow ends of roof profile (2,3) and fasten with ONE screw (49) at the furthest position of the three pre-drilled holes as shown.



VIEW FROM BELOW

Insert roof profile connector (36A/35A) into hollow ends of roof profile (2A,3A) and fasten with two screw (49) on the side as shown.

Insert roof profile connector (34) into hollow ends of roof profile (2A,3A) and fasten with ONE screw (49) at the furthest position of the three pre-drilled holes as shown.




3.E

Insert controller (45) into roof profile (2), fasten with screw (61) and nut (53) to the side of controller (45) as shown.

Attach ring cap (46) to controller (45) from underneath of roof profile (2) by rivet (57) as shown.

Attach stopper (38) on roof profile (2) by fasten screw (47) exactly as shown.





STEP 4 Bulding the Basic Roof Frame

Components

Roof Profile connector(13)	Roof Profile connector(14)	Roof Profile connector(22)	Roof Profile connector(23)	Louver mount(28)	Louver mount(29)
x 4	x 6	x 2	x 2	x 2	x 2
Louver mount(30)	Louver mount(31)	Roof Profile connector(37)	Screw(49)	Screw(51)	Nut(53)
x 6	x 6	x 4	x 66	x 312	x 312

4.A

Place roof profile set (5+5A+4A+4) as in U format as shown. Connect roof profile set to roof profile set (6+7,8+9) by fasten screw (49) from underneath of corner profile cover (17,16) to roof profile (4+5) as shown.





VIEWS FROM BELOW



VIEWS FROM BELOW



Connect roof profile set (2+3) on middle of roof profile set (5+5A+4A+4) by attaching roof profile connector (37) from underneath of roof profile set by screw (49).




TIP: Place roof profile set (2+3) on smooth surface article to have the same level with roof profile set for easy installation.

4.B

Attach roof profile connector (14) to the end of roof profile (2,2A), fasten with screw (49).
Attach roof profile (2A+3A) on corner profile cover (43) by screw (49) from underneath.




Insert roof profile connector (23,22) into roof profile (7,9), attach roof profile connector (13) to the end of roof profile (7,4) and (9,5) by screw (49) as shown.




4.C

Attach screw (51) on all open hole of louver mount (28,29,30,31) with nut (53) as shown.








IMPORTANT:

Screw (51) head must be vertically installed on louver mount (28,29,30,31).



Insert louver mount (28,29) into roof profile (8+9,6+7) with marked arrow point outward as shown.
Insert louver mount (30,31) into roof profile (3+2,3A+2A) with marked arrow point outward as shown.





ATTENTION:

Louver mounts (28,29,30,31) are marked with arrows that should point to the outside frame.

4.D

Connect roof profile set (4+4A+5A+5) to roof profile frame by fasten screw (49) from underneath of corner profile cover (17,16) as shown.





VIEWS FROM BELOW




VIEWS FROM BELOW

Connect roof profile set (2+3) on middle of roof profile set (4+4A/5+5A) by attaching roof profile connector (37) from underneath of roof profile set by screw (49) as shown.




Attach roof profile connector (14) to the end of roof profile (3,3A), fasten with screw (49).

Attach roof profile (2A+3A) on corner profile cover(43) by screw (49) from underneath.



Insert roof profile connector (23,22) into roof profile (8,6), attach roof profile connector (13) to the end of roof profile (8,4) and (5,6) by screw (49) as shown.

4.E






! Using silicon to seal all the gaps on the gutter inside roof profiles.

STEP 5 Building the Corner Profiles

5.A

Align pre-drilled screw holes in corner profiles(1,1A) with screw holes in support plate(11). Attach support plate(11) to corner profiles(1) as shown, using two screws(49) for each plate.

Components




5.B


Using at least 3 people, lift roof frame. Align pre-drilled screw holes on the top of corner profiles(1) with screw holes on corner profile covers(16,17,43). Insert another three corner profiles(1,1A) as shown, by 2 people.



ATTENTION:




You need at least 4 people to complete this step!





5.C

Attach support plates (12) to the bottom side of roof frame, using four screws (49) each as shown.



VIEWS FROM INSIDE


STEP 6 Installing the Louvers

6.A

Place 5 piece louvers (10) into pre-installed screw (51) beside roof profile (5), fasten with nut (54) on both side of louver (10) as shown.




Components

Louver puller(39) x 4	Louver puller(40) x 2	Louver puller(41) x 2
Screw(48) x 4	Screw(50) x 156	Nut(53) x 4
	Nut(54) x 312	Plastic washer(56) x 156



IMPORTANT:

Make sure ALL Louvers(10) installed at the same direction as shown. Insert one side of the louvers(10) into screw(51) with a slop, then place another end.






PERSPECTIVE VIEW






ATTENTION:

DO NOT OVER TIGHTEN SCREW(54).



6.B

Connect louver pullers(39,40) by screw(48) and nut(53)as shown.
Place plastic washer(56) between louver puller sets(39+40) and louver connectors(15), fasten with screw(50) as shown.
Repeat to assemble louvers(10) on the roof profile frame and connect with louver puller set(39+40),FIVE pieces louvers(10) at a time.
Repeat to finish left side Louvers.





IMPORTANT:

Louver puller(40) hanger must installed at the same side of louver connectors(15).



ATTENTION:

Screw(50) must fastened toward Middle roof profile(2+3/2A+3A).



PERSPECTIVE VIEW




IMPORTANT:

The Hanger of louver puller(40) must installed at the same side of Controller(15).

6.C


Place 5 piece louvers (10) into pre-installed screw (51) beside roof profile (4), fasten with nut (54) on both of louver (10) as shown.



PERSPECTIVE VIEW




IMPORTANT:

Make sure ALL Louvers(10) installed at the same direction as shown. Insert one side of the louvers(10) into screw(51) with a slop, then place another end.





6.D

Connect louver pullers(39,41) by screw(48) and nut(53)as shown. Place plastic washer(56) between louver puller sets(39+41) and louver connectors(15), fasten with screw(50) as shown. Repeat to assemble louvers(10) on the roof profile frame and connect with louver puller set(39+41),FIVE pieces louvers(10) at a time. Repeat to finish left side Louvers.



IMPORTANT:
Louver puller(41) hanger must installed at the same side of louver connectors(15).

ATTENTION:
Screw(50) must fastened toward Middle roof profile(2+3,2A+3A).



PERSPECTIVE VIEW

IMPORTANT:
The Hanger of louver puller(41) must installed at the same side of Controller(15).

6.E Place 5 piece louvers (10) into pre-installed screw (51) beside roof profile (5), fasten with nut (54) on both side of louver (10) as shown.







IMPORTANT: Make sure ALL Louvers(10) installed at the same direction as shown. Insert one side of the louvers(10) into screw(51) with a slop, than place another end.





6.F

Connect louver pullers(39,40) by screw(48) and nut(53)as shown. Place plastic washer(56) between louver puller sets(39+40) and louver connectors(15), fasten with screw(50) as shown. Repeat to assemble louvers(10) on the roof profile frame and connect with louver puller set(39+40),FIVE pieces louvers(10) at a time. Repeat to finish left side Louvers.



IMPORTANT:
Louver puller(40) hanger must installed at the same side of louver connectors(15).

ATTENTION:
Screw(50) must fastened toward Middle roof profile(2+3,2A+3A).




PERSPECTIVE VIEW

IMPORTANT:
The Hanger of louver puller(40) must installed at the same side of Controller(15).

6.G

Place 5 piece louvers (10) into pre-installed screw (51) beside roof profile (4), fasten with nut (54) on both of louver (10) as shown.




PERSPECTIVE VIEW

IMPORTANT:

Make sure ALL Louvers(10) installed at the same direction as shown. Insert one side of the louvers(10) into screw(51) with a slop, then place another end.




ATTENTION:

DO NOT OVER TIGHTEN SCREW(54).



6.H

Connect louver pullers(39,41) by screw(48) and nut(53) as shown. Place plastic washer(56) between louver puller sets(39+41) and louver connectors(15), fasten with screw(50) as shown. Repeat to assemble louvers(10) on the roof profile frame and connect with louver puller set(39+41), FIVE pieces louvers(10) at a time. Repeat to finish left side Louvers.



39



41

IMPORTANT:

Louver puller(41) hanger must installed at the same side of louver connectors(15).

ATTENTION:

Screw(50) must fastened toward Middle roof profile(2+3, 2A+3A).



PERSPECTIVE VIEW

IMPORTANT:


The Hanger of louver puller(41) must installed at the same side of Controller(15).

STEP 7 Installing the Louvers


7.A Assemble one side of two puller connectors (42) to controller (45) with screw (52) assemble TWO nuts (53) at each side of controller (45) and fasten with nuts (54). Connect another side of puller connectors (42) to louver pullers (40,41), fasten with screws (48) and nuts (54). Attach controller cover (44) to the top of controller (45) pre-drilled hole by four screws (47).

Components



Puller connector(42) x 4	Controller cover(44) x 2	Screw(47) x 8	Screw(48) x 4
Screw(52) x 2	Nut(53) x 8	Nut(54) x 6	Rocker(58) x 1



VIEWS FROM TOP





x2




x2

7.B


Using Rocker(58) turning the ring cap(46) clockwise and counter clockwise to open and close the louver roof.



VIEWS FROM BELOW



VIEWS FROM BELOW





VIEWS FROM BELOW

STEP 8 Secure the Pergola to a Concrete Floor or Wood Deck

Concrete Floor:




1. Drill holes approx. 3.00 inches deep and use a mallet to set up.
2. 3/8" masonry drill bit to drill holes for the concrete anchors supplied.
3. Using a concrete drill, drill holes into the concrete floor, corresponding to the holes in support plates (11).
4. Insert concrete bolts (59) into the holes and hammer into place, using a mallet.
5. Fasten concrete bolts with washers and nuts.



Wood Deck:

1. Using an electric wood drill, drill holes into the wood floor, corresponding to the holes in support plates (11).
2. Insert wood screws with washers (not supplied) into the holes and fasten, using an electric screw driver.





Post Detail



12' x 20' Louver Pergola

Assembly Instructions

WARRANTY:

Warranty covers damage due to manufacturing defects only for a period of 5 years on the structure from date of purchase. Warranty does not cover weather inflicted damage and/or damages caused by not following assembly instructions and adhering to warnings in manual. Warranty does not cover user error, negligence, or misuse.

- ⚠ **WARNING:** Cancer and Reproductive Harm-
www.P65Warnings.ca.gov.
- ⚠ **AVERTISSEMENT:** Cancer et Troubles de l' appareil reproducteur-
www.P65Warnings.ca.gov.
- ⚠ **ADVERTENCIA:** Cáncer y Daño Reproductivo-
www.P65Warnings.ca.gov.



Paragon Group USA

Customer Service:(877) 782 4482 Email:cs-outdoors@paragongroupusa.com