2 General Information


2.1 Product Specification

Model	WD800
Daily Production Capacity	800 GPD
Operating Water Temperatures	40-100 °F (5-38 °C)
Operating Water Pressure	15-100 psi (0.1-0.7 MPa)
Power Specifications	110-120 VAC 50/60 Hz
Rated Power	1100 W
pH Parameters	2-11
TDS (Total Dissolved Solids)	< 1800 ppm
Iron	< 0.2 ppm
Turbidity	< 5 NTU
Hardness	< 10 gpg (170 mg/L)
Size (L × W × H)	18.5" × 7.3" × 17.7"


Note: The system will operate with a hardness of over 10 grains, but the membrane life may be shortened. The addition of a water softener may lengthen the membrane life.

Water Pressure: The operating water pressure in your home should be tested over a 24-hour period to attain the maximum pressure. If the incoming water pressure is above 80 psi, a water pressure regulator is required.

2.2 Product Overview and Installation Illustration



- 1) System
- (2) Smart Faucet
- (3) Angle stop valve
- 4) 3/8" White PE tubing
- 5 1/4" Red PE tubing
- 6 Drain connector
- 7 3/8" L-Fitting
- 8 1/4" L-Fitting
- (9) 3/8" Clips
- 1/4" Clips



- (1) Hot valve
- (2) Cold valve
- (3) Angle Stop Valve
- (4) Water inlet tubing
- (5) Pure water outlet tubing
- (6) Drain water outlet tubing
- (7) Drain connector

- (8) System
- (9) Air outlet tubing
- (10) Hot water outlet tubing
- (11) Signal cord
- (12) Power cord
- (13) Smart Faucet

Tools and Materials Required

- Hand or electric drill(cordless preferred)
- · Adjustable wrenches
- Slotted and Phillips screwdrivers
- · Utility knife or scissors
- Safety glasses
- Drill bits: 1"(for faucet hole), 1/4"(for drain tubing)
- · Safety mask



NOTICE

Not all tools may be necessary for installation. Read installation procedures before starting to determine what tools are required.

3 Installation

3.1 Installation Instructions

Read all installation and operating instructions before installing and using your RO system.



NOTICE

- Please check if there is sufficient space for installing the system itself, its accessories, connection.
- Under no circumstances should the system be installed outdoors.
- The environment where the system is installed should adhere to appropriate hygiene and sanitation conditions. Avoid any external dripping liquids from pipes or drains, etc, onto the system.
- This system should be placed on a stable and at the surface.
- Keep the system away from heat. It shall not be placed in a place that may have in-inflammable gas leakage.

How to use the quick-connector fitting

To connect

