


2 MAKE WATER SUPPLY CONNECTIONS

- Turn off hot and cold water supplies.
- Thread RED SUPPLY HOSE (1) onto HOT WATER SUPPLY (3).
- Thread BLUE SUPPLY HOSE (2) onto T-CONNECTOR (4).
- Thread T-CONNECTOR (4) onto COLD WATER SUPPLY (5).
- Firmly push the BLUE HOSE (6) in to END CAP (4).

Note: If additional supply length is required, installer must purchase additional parts separately.

Note: If SUPPLY HOSES (1, 2) are too long, loop as illustrated to avoid kinking.

Note: Connection on fitting supplies are 3/8" compression.



3 FILTER OUTPUT CONNECTION

- Thread hose T-CONNECTOR (1) onto HOSE (2).
- Thread hose T-CONNECTOR (1) onto HOSE (4).
- Firmly push the WHITE HOSE (5) into hose END CAP (3).

3

5

2


1

4 FILTER INSTALLATION

INSTALL FILTER ON COUNTERTOP

- Insert FILTER (3) through mounting hole in countertop.
- Hand tighten MOUNTING NUT (2) to secure FILTER (3).
- Firmly push the WHITE HOSE (4) into PORT (5) labelled "CONNECT TO FAUCET".
- Firmly push the BLUE HOSE (6) into PORT (7) labelled "CONNECT TO FILTER".

NOTE: To remove plastic hose firmly push in the white or blue collar at HOSE PORT **(5)** and pull the hose out.




INSTALL FILTER BELOW COUNTERTOP

- Secure FILTER SLEEVE (1) at a 45° degree angle below the countertop with the four SCREWS (2) provided.
- Insert FILTER (3) into FILTER SLEEVE (1) and rotate clockwise until tight.
- Firmly push the WHITE HOSE (4) into PORT (5) labelled "CONNECT TO FAUCET".
- Firmly push the BLUE HOSE (6) into PORT (7) labelled "CONNECT TO FILTER".

NOTE: Installing at a 45° angle helps to prevent drippage.

NOTE: To remove plastic hose firmly push in the white or blue collar at HOSE PORT **(5)** and pull the hose out.




J


5 BATTERY PACK CONNECTIONS

- Install BATTERY PACK (1) below the countertop with velcro on the back of BATTERY PACK (1). The BATTERY PACK (1) should be close to the faucet and filter so that the wired connections can be made.
 OPTIONAL: Instead of Velcro the battery pack can be hung from a nail or hook from LOOP (7).
- Connect FEMALE WIRE (2) to BATTERY PACK (1) as illustrated by a dashed line. NOTE: Secure this connection by installing inside the CONNECTORS HOUSING (8) as shown.
- Connect MALE WIRE (3) to FILTER (4) as illustrated by a dashed line.
 NOTE: Secure this connection by installing inside the CONNECTORS HOUSING (8) as shown.
- Connect THREADED WIRE (5) to FAUCET WIRE (6) as illustrated by a dashed line.
- Insert batteries into battery pack.
- Two cable ties are provided for cable management.

6 INSTALL PULL-DOWN HOSE WEIGHT


• With HAND SPRAY (1) seated in SPOUT (2), install WEIGHT (3) onto HOSE (4) 18" below the countertop, secure with SCREW (5).






7 FILTER INSTALLATION


- Remove FILTER COVER (1) by pulling up.
- Unthread FILTER CAP (2) from FILTER HOUSING (4).
- Insert FILTER (3) into FILTER HOUSING (4).
- Thread FILTER CAP (2) onto FILTER HOUSING (4).
- Push FILTER COVER (1) onto FILTER CAP (2).



8 PREPARE FAUCET & CHECK CONNECTION FOR LEAKS

- Move HANDLE (1) into "off" position.
- Turn on water supplies and check connections for leaks.
- With HANDLE (1) in "off" position, unthread AERATOR (4) from SPRAY HEAD (2) with AERATOR KEY (5).
- Operate HANDLE (1) up and down, left and right to flush water lines thoroughly.
- Thread AERATOR (4) onto SPRAYHEAD (2) with AERATOR KEY (5).
- Press and hold the FILTER ACTIVATION BUTTON (3) for approximately 5 seconds. The filter will run for 1 minute. Check connections for leaks.
- This concludes the installation of your filtration faucet.





MAINTENANCE & SERVICE

FAUCET DRIPS


- Turn VALVE to OFF position.
- Operate HANDLE several times from OFF to ON position. Do not apply excessive force.
- If drips persist call customer service 1 (800) 442-1902.

LOW FLOW RATE

- Remove aerator and flush faucet.
- Turn off hot water supply.
- Unthread water supply hose.
- · Check supply pipe and supply hose for debris.
- If low flow persist call customer service.

PULLDOWN HOSE NOT RETRACTING

- Check under countertop to see if the hose is getting snagged.
- Check that the WEIGHT (1) is on the correct side of the hose loop.



- Water Filtering System Specifications
- Rated Service Life of 300 gallons (1136 L)
- Pressure: 20 125 psi (0.7 8.6 bar)
- Temperature: 35 95°F (2 35°C)
- Flow Rate: 0.65 gpm (2.46 L/min)
- The system and installation shall comply with applicable state and local regulations.
- System tested and certified by NSF International against NSF/ANSI Standard 42 for the reduction of chlorine, taste and odor, Particulate Class I, and against NSF/ANSI Standard 53 for the reduction of lead.
- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- Important Notice: Read the Manufacturer's Performance Data Sheet.
- NOTE: Use only F50 Filter Cartridge with the Saybrook Filtered Kitchen Faucet Purchased from americanstandard-us.com
- Water Filter System to be supplied with Cold Water Only.

CLEANING:

• Clean with clear water, dry with a soft cotton flannel cloth,

NOTE: Do not clean the product with acid, polish, abrasives, harsh cleaners, or a cloth with a coarse surface.