


HOUSEHOLD REFRIGERATOR

Instruction Manual

SKU: RSD-44H





Facebook: @Euhomy.Official

Congratulations

Dear Customer:

Welcome to the Euhomy family. Thank you for purchasing one of our products.

Our goal is to provide you with superior service. If there is anything missing from or wrong with your order, or if you have any questions about using our ice maker, PLEASE contact us.

Email: support@euhomy.com Facebook: @Euhomy.Official

The Euhomy team is available 24/7 to address your questions, comments, and concerns. Your satisfaction is our ultimate goal. We want to make everything right so you'll share your positive experience with other shoppers on Amazon.

If you experience any problems, please send an email to support@euhomy.com.

Our mission:

- * To be the most trusted appliance brand.
- * To create practical, compact appliances that better your life.

Be sure to register at **www.euhomy.com/register** for updates, warranty, and other relevant information.



IQ&A

1. How often do I need to clean my ice maker?

Depending on how frequently you use it, it is recommended that you clean it at least once a week. Failure to clean the machine will cause scale accumulation, which will eventually block the pump and cause the product to stop working properly.

2. How should I clean the machine?

It is recommended to use lemon water or weak acid vinegar for cleaning. Drain immediately after cleaning, and then clean it with pure water.

It is recommended to drain the water at least once every three days (pulling out the small hose on the right side of the water tank). Draining will not only ensure that the hardness of the water is not too high, but also ensure that impurities can be discharged well, and it is not easy to produce scale in the water tank.

3. Why is my ice cube cloudy?

It means that the water quality is turbid. It is recommended to use drinking water and distilled water. If your water quality problem is serious, it is recommended that you install a water filter kit.

4. Can I put milk and juice into the water tank to make ice cubes?

We recommend that you do not do that. Our research has found that the high concentration of milk and beverages can easily block the pump and reduce the life span of the pump. At the same time, the protein in milk is prone to calcification, which chemically reacts with the PU water pipe inside the machine, which easily breaks it, making the product unable to continue working.

5. Why does my ice cube melt easily?

Since the ice maker is not a refrigerator, it does not have a heat preservation function. The high ambient temperature in summer will accelerate the melting of ice cubes. You can close the lid of the machine to keep the internal temperature. Some customers also put electric fans on the side of the machine to blow away the hot air surrounding the device, thus solving the problem. Feel free to try it yourself. However, if you are not using ice cubes for a long time, we recommend removing them from the ice basket and storing them in the refrigerator.

6.Why is my ice so thick and difficult to fall from the ice tray? What should I do?

It may be that your ice making time is set for too long, or it may be that the temperature of your environment is very low. You can reduce the time to 0 or -6 by pressing the minus key on the touch panel.

7. Why does the ice cubes have a plastic smell?

The ice cube itself has no taste. If you feel there is a plastic smell, try to clean the inside of the machine with lemon water, then run a few cycles, and finally rinse with distilled water.

8. Why is there noise in the operation of my machine?

There is a faint sound when the machine is running. Closing the lid can reduce the noise. If the water pump makes a noise during use, it is recommended to turn off the machine first, and then turn on the machine after cleaning the filter in the water tank to observe whether or not the noise disappears.

9.Why is water leaking from my machine?

It may be that the PUA tube inside the machine fell off during transportation. You can remove the back cover of the machine and connect it by yourself. If you don't know how to operate, please contact the Euhomy team. We will give you a professional video to help you solve the problem.

10. Why is there water flowing but not making ice?

Please provide a video or picture and send it to us. The Euhomy team will assist you.



Contents

Safety	02
Safe Disposal	02
Technical Specifications	03
Installation	03
Door Reversal Instructions	04
Operation	04
Maintenance	05
Troubleshooting	06



Safety

Do not store explosive substances such as aerosol cans with a flammable propellant in thisappliance.

Refrigerant and foaming material is fammable. Take precautions during handling, installationand maintenance.

Ensure that the refrigerant circuit is not damaged

Keep ventilation openings clear of obstructions

When positioning the appliance, ensure the electrical cord is not trapped or damaged

Do not place multiple portable socket-outlets at the rear of the appliance.

Never unplug the appliance by pulling on the power cord. Grip the plug firmly and pull straightout to remove from wall socket.

Do not place the power cord near water or where it could be a tripping hazard and do not usea damaged power cord.

Ensure that the power cord is not near the compressor of the Refrigerator.

Do not use an extension cord.

Do not defrost with electrical devices or scrape the ice with sharp tools.

Children should be supervised to ensure that they do not climb on or play with the appliance.

This appliance is not intended for use by persons (including children) with reduced physicalsensory or mental capabilities, or lack of experience and knowledge, unless they have beengiven supervision or instruction.

Safe Disposal

- Danger: Prevent risk of child entrapment. Before discarding the Refrigerator, remove thedoor but leave shelves in place so that children may not easily climb inside.
- Please dispose of this appliance in accordance with local regulations.



| Technical Specifications

SKU	RSD-44H	
Capacity	4.4 cu ft	
Voltage	115V 60Hz	
Current	0.8A	
Refrigerant	R600a, 0.8 oz	
Net Weight	50.9 lbs	
Product Dimensions (HxWxD)	32.1×20.3 ×22.2 (inch)	


I Installation

- When transporting the refrigerator, keep it in an upright position. Do not tilt the Refrigerator atan angle of more than 45°
- · Place the appliance away extreme heat and cold. It is not designed to be in direct sunlight oroutside.
- Before connecting the refrigerator to power, let it stand upright for at least 4 hours.
- Check the plug and cord before you connect the power and make sure it is a properly grounded115/60 Hz outlet.
- The Refrigerator is designed for recessed installation.
- Place the Refrigerator on a flat level surface, leaving 2 inches (5 cm) on either side and atleast 3 inches (8 cm) between back of appliance and the wall. Allow sucient clearance (160°) for the door to open completely.
- The feet of the appliance can be adjusted to make it level. Turn counterclockwise to raise and clockwise to lower.



Door Reversal Instructions

The Refrigerator is built with a reversible door which lets you open it from either the left or rightside. In order to reverse the opening of the door, transfer the hinges and screws indicated in the figure below from one side to the other.



Operation

Clean the outside and inside of the Refrigerator with a soft cloth.

Insert the power cord into the outlet.


The temperature control dial is located at the top right corner inside the Refrigerator.

Turn the temperature control dial to 7, the coldest setting.

After 2 hours, change the dial setting to 4, which is the normal position to keep food cold.

Wait to put food inside the Refrigerator until it is adequately cold. If a slightly higher or lower temperature is preferred, the dial can be changed with 1 being leastcold and 7 being the coldest.

To turn the Refrigerator off, turn the dial setting to 0.





Maintenance

Make sure the power cord is unplugged before moving or cleaning the back of the appliance.

Clean the outside and inside of the appliance regularly, using water and mild detergent.

Do not touch cold surfaces with wet hands, because the skin may stick to the surface.

When the Refrigerator is not going to be used for an extended period of time:

- Remove the power cord plug from the outlet.
- · Remove all contents.
- Dry the interior and leave the door open.

The following phenomenon is normal:

- Moisture on the door- wipe with dry cloth
- Sound of fluid is the compressor when it is starting or stopping
- Flowing sound of refrigerant in the refrigeration system
- Condensation forming inside the cabinet- wipe with dry cloth
- Warm Refrigerator front (anti-condensation pipe heats up the front)



| Troubleshooting

Problem	Possible Cause and Solution
Not Working	Check the fuse has not blown.Check if it is plugged in correctly to the power source.
Not Cooling	 Temperature is set too high. Lower the temperature. Move it if near a heat source or in direct sunlight. Check for proper ventilation and that air inlet or outlet is not blocked. Door opened frequently or not closed properly. Check to see if door seal is damaged. Too many items stored that are blocking internal circulation.
Too muchcooling	Temperature is set too low. increase the temperature. Food is placed directly under the cool air outlets. Move the food awayfrom the affected area of the Refrigerator.
Too muchnoise	 Appliance is not placed on flat surface or not level. Adjust the feet to level it. Check if some items inside the Refrigerator are causing rattling. Check if something has fallen behind the Refrigerator.
Door does notclose properly	 Check the door seal. Shelves are not positioned properly. Adjust the shelves. Items in the Refrigerator are causing an obstruction.
Defrost wateroverflows	 Check that the drain pipe and drain hose are not clogged. Check that the drain pan behind the Refrigerator is placed properly.

California Proposition 65:

WARNING: This product contains chemical known to the State of California to cause cancerand birth defects or other reproductive harm.



EUHOMY # Live the *cool life*



