

For longer use

Re-tighten bolts every 6 months by using the enclosed allen-key.

\*Using an electric drill can damage the chair. Please re-tighten bolts manually.





## **Safety Information**



Sit in the center of the chair, with your back to the backrest



Do not sit at the front edge of the chair



Do not stand on the chair



Do not use the chair with more than one person




Do not push the chair around when a person is sitting in it




Do not push down on the backrest when a person is reclined




Do not place all your weight on only the backrest



## **Package List**




## **Assembly Instruction**




Fix the Leg (B)\*1(R) and (A)\*1(L) with Bolts (F)\*2.

**Note:** Bolts are only tightened **50%**. Make sure the "**FRONT**" on the Leg is mounted correctly.



Install Round Tube (D)\*2 to the Legs (B&C) with Bolts (E)\*4.

Note: Bolts are only tightened 50%. The grooves of the Round Tube fit the Legs.



Place the Seat (A) face down. Attach Legs (B&C) to the Seat (A) with Bolts (G1)\*2 and (G2)\*2.

100% tighten the Bolts in the order shown. G1, G2  $\rightarrow$  F  $\rightarrow$  E

**Note:** Make sure the "**FRONT**" on the Seat and Legs are the same direction.



## **CAUTION:**

- \* Before using the chair, check to ensure that all bolts are fully tightened.
- \* Lubricate all parts and tighten all bolts every 6 months or whenever needed.