
Maxxima LED Shop Light Installation Instructions

1. Mounting surface must be capable of supporting the fixture. For plaster board ceiling, #8 screw eye hooks with plastic anchors are included or expansion bolts may be used (not included). If installed onto a plaster board surface, we recommend minimum 3/8" thick.

NOTE: You are responsible for secure installation.

- 2. Install the 2 plastic anchors 47 1/4" apart, then screw the eye hook into each anchor.
- 3. Install one "S" hook into each end of the chain, then crimp the "S" hook end which is attached to the chain with pliers.(Leave one side open from the "S" hook) Repeat step for the second chain provided.
- Install the "S" hook from one end of the chain into the 4 4. end cap of the LED lamp, then crimp the hooks end with pliers. Repeat same step for the opposite side.

5. Install the LED lamp with chains, one end at a time on to each screw eye hook. Crimp screw eye hook if needed.



Crimp


with

pliers.


S-hooks

Installation (Continued)

6. Plug the power supply cord into the electrical outlet.



Linking Multiple Shoplights



(5)

Maxxima LED Shop Light Installation Instructions

General Safety Information

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- DO NOT INSTALL DAMAGED PRODUCT!

CAUTION:

- Turn off the switch and circuit breaker before installing this LED lamp.
- Suitable for dry locations.
- Not for use with dimmers.
- Install directly beneath a ceiling-mounted receptacle.
- Use only insulated staples or plastic ties to secure the cord.
- Not intended for recessed installation or on ceiling.
- Do not install directly over a heat source (stove, etc.)
- Use safety precautions. Safety eye glasses and gloves are recommended.
- Installation should not be made on a radiant-heating ceiling.
- Injury to people and damage to the lamp and/or mounting surface may result if the lamp is pulled from the surface. To reduce the likelihood of such injury or damage, mount only on a mechanically sound surface.
- Do not alter the plug or power supply cord in any way or try to install this product in any other method besides method shown on this sheet.

NOTICE:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- To install onto a plaster board surface, plaster board requires minimum 3/8" thick.

Models:

MSL-404400F, 4400 lumens, frosted lens

MSL-404800C, 4800 lumens, clear lens

Rated: 120V 60Hz AC ONLY 40W

Linkable: Connect/Link shoplights together, 4 units maximum

NO SERVICABLE PARTS!

Five Year Warranty:

Maxxima extends a 5 year limited warranty to the original purchase that the products listed are free from defects in material and/or workmanship only. Maxxima will replace any warranteed product to the original consumer/purchaser if the product fails because of defects due to workmanship and/or materials within the limited warranty period. Limited warranty is not transferable and applies to the original installation of the Maxxima product. This offer does not constitute in any way a product guarantee and Maxxima does not hereby assume any obilgation whatsoever beyond sending a free replacement product.



Picture is for illustration purposes only.

Your model may vary.

