

CUSTOMER SERVICE



GQBrands.com • CustomerService@GQBrands.com • 1-866-498-5269 • 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Thank you for purchasing: DURA-BOUNCE 8FT TRAMPOLINE SET

MODEL# 9308TS

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com to open a ticket.

At GQBrands®, we want all of our customers to be completely satisfied with their purchase. Take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will provide replacement parts at no charge within 30 days of purchase.

Please keep in mind that for select damaged part replacement requests, we will require a photo for submission.

To register you product please visit: www.globalqualitybrands.com/product-registration or Scan code



To order these parts, or if you have any other questions or concerns about this GQBrands product, please contact us at

PureFun.Net GQBrands® Phone: 1-866-498-5269 Email: CustomerService@GQBrands.com 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Please be sure to include the following information when you contact Customer Service:

YOUR NAME:	RETAILER WHERE PURCHASED:
YOUR MAILING ADDRESS:	DATE OF PURCHASE:
YOUR EMAIL ADDRESS:	ORDER NUMBER: (If Available)
PRODUCT NAME:	QUANTITY NEEDED:
PRODUCT MODEL#:	SERIAL NUMBER:
PART NUMBER	

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of **90 DAYS FROM THE DATE OF ORIGINAL PURCHASE**. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from the date of purchase, GQBrands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY,

THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQBRANDS® CAN WAIVE OR CHANGE.



A WARNINGS



Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:

- It is essential that the intended site for this trampoline is completely flat and level. If the ground is not level this will cause movement in the frame and could cause stress on the joined sections.
- Before each use of this product, inspect the entire assembly and replace any worn, defective or missing parts.
- It is only recommended for use by children 3-9 years of age.
- DO NOT exceed the recommended MAXIMUM WEIGHT limit of 250lbs (113kgs).
- DO NOT wear glasses or helmets when using the trampoline.
- D0 NOT use the trampoline in wet, windy or other adverse weather conditions. Use only when the trampoline mat is clean, dry, and safe of obstructions.
- ALWAYS jump in the center of the trampoline mat.
- DO NOT use the trampoline as a springboard to or from other objects. NEVER jump from or attempt to jump to other objects, bodies of water, buildings or surfaces, or into or over the trampoline enclosure.
- DO NOT allow other persons to go under, sit, stand or lie on the trampoline or the frame pads while the trampoline is in use.
- D0 NOT use the trampoline set when under the influence of alcohol, drugs or medication which may impair the jumper's judgment and coordination.
- ALWAYS remove jewelry, belt buckles or any other sharp objects before using the trampoline.
- ALWAYS secure the trampoline against unauthorized and unsupervised use.

- NEVER wear footwear (e.g. shoes) when using the trampoline. ALWAYS wear socks when using the trampoline.
- Children MUST NEVER use the trampoline unless supervised by a responsible adult with knowledge of trampoline use.
- Ensure the trampoline set is on level ground with a minimum of 8 feet (2.5M) clear space around the sides, 26 feet (8M) clear height space above and that no obstructions are under the trampoline.
- ALWAYS watch for hazards or obstructions above, around and below the location where you are installing your trampoline set. Failure to do so can result in serious injury, death, and property damage.
- Children should be assisted when entering and exiting the trampoline to reduce the risk of falling.
- The frame of your trampoline set is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, etc.) should be permitted on or around the trampoline under any circumstance.
- DO NOT allow more than one (1) person on the trampoline at a time. Jumpers may collide with one another, fall off the trampoline, fall on or through the springs or land incorrectly on the mat. Multiple jumpers increase the chances of loss of control, collision and falling off. This can result in severe injury or death.
- Always secure the trampoline against unauthorized and unsupervised use.
 - IMPORTANT:
- You must not use the trampoline if you have a medical history of neck or back injuries or certain mental or physical conditions – an existing condition dramatically increases the risk of serious injury or death.


- No modification should be carried out to the trampoline or any of its components. Any modification could lead to damage to the product or result in a personal injury.
- Should there be any missing parts, the trampoline must not be used until replacement parts have been fitted.
- The frame pad should always be fitted properly, fully covering the trampoline frame and springs.
- The use of gloves to protect your hands from pinch points during assembly is also strongly recommended.

WEATHER CONDITIONS:

- Special care should be taken as weather conditions change. In particular, a wet trampoline mat (bed) is too slippery for safe jumping.
- Gusty or severe winds can cause jumpers to lose control. To reduce the chance of injury, use the trampoline only under appropriate weather conditions. In cold weather, tongues and lips can stick to metal at sub zero temperatures. In warmer and sunnier weather, parts can become extremely hot, and the temperature should be regularly checked during play, especially metal parts. HIGH WINDS:
- If you anticipate high winds, the Trampoline must be moved to a sheltered location, or be disassembled. GQBrands is not responsible for any damage to property or product resulting from wind or extreme weather.


TRAMPOLINE - PARTS LIST

1- Jump Mat





x1


2- Frame Pad



3- Curved Frame with T-Section











4- "U" Shaped Leg


TOOLS INCLUDED



ENCLOSURE - PARTS LIST



7



STEP 1:

Parts:

Part 4 (x3) - "U" Shaped Leg Part 5 (x6) - Extension Leg

Attach the Leg Extensions (5) to all T-Section with the horizontal opening facing the inside of the frame.

Place the "U" Shaped Legs [4] with the openings aligning to the horizontal opening from the Extension Leg.

STEP 2:


Parts:


Part 7 (x6) -Screw

With the openings aligned, use a screwdriver to unite the Leg Extensions and the "U" Shaped Leg.

STEP 3:

Repeat Steps 1 and 2 until you have three completed legs.







STEP 4:

Once all x3 completed Legs have been installed, Flip each at a time and connect them to ensure they stay connected.

With the help of another adult, carefully flip the complete frame so it stands on its own.

Once all assemble legs are connected, make sure to push all parts together to make sure they are connected and snug






STEP 5:

Parts: Part 1 (x1) - Jump Mat

Place the Mat (1) in the middle of the frame, with the logo facing upwards and the stitching facing the floor.



LEARNING TO INSTALL SPRINGS

Install the Spring (6) by placing the "R" Hook on the V-Ring of the Trampoline Mat.

Using the Spring Tool (8), pull the "C" Hook until it reaches the opening in the frame.

STEP 6:

Parts:


Part 6 (x48) - Spring Part 8 (x1) - Spring Tool

To ensure that Jump Mat and Frame Pad won't suffer from any excessive tension that will cause ripping or tearing on the Mat, the springs must be installed in a specific order.

Follow the Spring order shown for the best way to properly install and secure the Jump Mat and Frame Pad to the Top Rails.

Once the first 16 Springs have been installed on the Frame, install the remaining 32 Springs.

NOTE: Failure to install the springs to the correct V-Ring and Top Rail openings and/ or not follow the Spring Order Installation as shown, may result in tearing or injury while in use.



Hook to the V-rings of Trampoline Mat

STEP 7:


Parts:

Part 2 (x1) - Frame Pad

Unfold the Frame Pad (2) and place it on top of the Top Rail and springs. The Frame Pad must cover the Top Rails completely to avoid injury.

STEP 8:

Tighten the Elastic Hook at the bottom of the Frame to the V-Ring as shown to secure to the trampoline.




STEP 9:

Parts:

Part 9 (x6) - Lower Pole


Align the openings of the Lower Pole (9) to the openings of the T-Section and the middle opening of the Leg extension.




STEP 10:

Following the instructions on Page 11, install all Lower Poles to the frame of the trampoline.












80mm M6 Bolt


M6 Nut

Plastic Washer

Washer

Nut Cap





STEP 11:

Parts:

Part 11 (x6) - Pole Foam


Slide x6 Pole Foams (11) once all Lower Poles have been installed.

STEP 12:

Parts:

Part 10 (x6) - Upper Pole Part 11 (x6) - Pole Foam Part 12 (x6) - Pole Sleeve

Slide all x6 Pole Foams(11) to x6 Upper Poles. (10). Once assembled, locate the larger opening of the Pole Sleeve (12) and slide until the top of the upper pole shows on the smaller opening of the sleeve.



STEP 13:

Slide all x6 Assembled Upper Poles with the larger opening sliding through the bottom pole.


Make sure that the top of the Bottom Pole aligns and attached to the bottom Upper pole when sliding the sleeve down.

STEP 14:

Parts:

Part 13 (x6) - Pole Caps

Place all x6 Pole caps at the top of the Upper Poles.



STEP 15:


Parts:

Part 14 (x1) -Enclosure Net

Place the Enclosure Net (Part 14) in the middle of the Trampoline, and hook each upper loop to a Pole Cap

NOTE:

Leaving the zipper open will make it easier to install the enclosure netting.



STEP 16:

Close the zipper of the enclosure netting and secure with the Buckle Hook.

At the bottom of the Enclosure netting there are hooks that need to be attached to the V-Rings of the trampoline.

Secure all Hooks to tighten the Enclosure netting to the trampoline as shown.

FREQUENTLY ASKED QUESTIONS

• Question: "The foam padding or mat is damaged, what should I do?"

Answer: If you are still within your warranty period (90 Days from initial purchase) you should contact customer service. You can also purchase replacement padding and mats at: www.PureFun.net • Question: "I had a part missing from my box" or "something was damaged in shipping, can you send it to me?"

Answer: If it has been 30 days or less from the date of your initial purchase, you can contact customer service for a replacement part to be issued.

CARE & MAINTENANCE

- It is essential that the intended site for this trampoline is completely flat and level. If the ground is not level this will cause movement in the frame and could cause stress on the joined sections.
- Before each use of this product, inspect the entire assembly and replace any worn, defective or missing parts.
- The following conditions could represent potential hazards: Missing, improperly positioned, or insecurely attached frame padding; Punctures, frays, tears, or holes worn in the bed or frame padding; Deterioration in the stitching or fabric of the bed or frame padding; Broken or missing springs; A bent or broken frame; A sagging jump mat; or sharp protrusions on the frame or suspension system; Bent or broken enclosure poles; Missing or torn foam on the poles; Torn or ripped enclosure netting; Broken or fraying zipper in the enclosure opening. Cease using trampoline immediately and secure it against unauthorized use if any of these conditions are present.
- If any part of the trampoline frame requires cleaning, simply wipe with a damp cloth. (Do not jump on the trampoline after cleaning until completely dry).
- To clean chalk from mat, wipe down net with wet rag. Allow mat to fully dry before jumping.

Thank You Coupon!

As a way of saying thank you for purchasing one of our products, here is a 10% OFF coupon for your next purchase at

www.PureFun.net

Use Code: GQBRANDS10 at Checkout