


How to Measure

Measure each window individually as size variances are common. Record width first, then height (also referred to as length) to the nearest $\frac{1}{8}$ ". Measure width from left to right, height from top to bottom, using a steel tape measure. Do not use a cloth tape.

Inside Mount

Inside mount blinds are installed inside the window casing. **Window casing must be at least the listed depths for inside mount blinds.**

Type of Blind	Minimum Depth Mount (inches)	Depth Needed for Full Recess (inches)
Vinyl	$\frac{3}{4}$	$1\frac{1}{4}$
Faux Wood—Headrail Only	1	$2\frac{5}{8}$
Faux Wood—Headrail with Standard Valance	1	$3\frac{1}{8}$
Faux Wood—Headrail with Decorative Valance	1	$3\frac{1}{4}$
Cellular	$1\frac{1}{2}$	$2\frac{1}{8}$
Verticals—Flush Track	$2\frac{3}{4}$	$4\frac{5}{8}$
Verticals—Flush Vane	$3\frac{3}{4}$	$4\frac{5}{8}$




1. Measure the exact inside width of the window casing from one inside edge to the other in three different places. Record the narrowest measurement.
2. Measure the exact height in three different places from top edge of opening to top of sill. Record the longest measurement. (Verticals: Record the shortest measurement.)
3. Measure the window diagonally in two places as shown. If the two diagonal dimensions are not equal, we recommend an outside mount application for optimal function and aesthetics.
4. Do not take deductions. Allowances are made at the factory to ensure a perfect fit.

Outside Mount: Horizontal Blinds and Cellular Shades

Outside mount blinds are installed outside the window casing, covering an area larger than the window itself.

1. Measure the exact width to be covered. If window opening allows, overlap by at least $1\frac{1}{2}$ " on each side (3" total overlap) to ensure light control and privacy.
2. Measure the exact height to be covered, including desired overlap (typically from top edge of molding to bottom edge, or to top of sill if there is one).
3. The factory makes NO allowances on outside mount.



Outside Mount: Vertical Blinds

Outside mount blinds are installed outside the window casing, covering an area larger than the window itself.

1. Measure the exact width of the window, including the frame if there is one. Add 3" for each side (6" total overlap) to ensure light control and privacy.
2. Measure the exact height of the window from top edge of molding to bottom edge, or total top of sill if there is one. Add 3" to allow for adequate mounting area above the window.
3. If blind extends to the floor (e.g., to cover patio door), measure as in step two. Then add 3" to allow for adequate mounting area above the window and deduct $\frac{1}{2}$ " for clearance so the vanes do not touch the floor.
4. The factory makes NO allowances on outside mount.