


Assembly Instruction Sheet #IS-9957P42-12
For Style 9957P42-12

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.
Light Sources: (12) E12 Candelabra Base Bulbs, 60W Maximum (Not Included).
Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, inspect, or operate the fixture. Contact customer service for replacement parts.

Warnings and Cautions
Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.
These instructions are provided for your safety. It is very important you read them completely before installing the fixture.
We strongly recommend that a licensed, professional electrician perform the installation.
Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

Package Contents



Hardware Contents		
PART	DESCRIPTION	QUANTITY
AA	Canopy Lock Ring	1pcs
BB	Wire nut	3pcs
CC	Canopy Chain Loop	1pcs
DD	Crossbar	2pcs
EE	Outlet Box Screw	2pcs

STEP 1 -Install Side Arms to Fixture Body

- A. Rotate the inner ring 80 degrees.
B. Pass supply wires with ground wire through one Quick Connector (HH) and the Middle Canopy.
C. Attach one end of the Side Arm (B) to the loop on the Fixture Body (A) with one Quick Connector (HH) and attach another end of the Side Arm (B) to the loop on the bottom of the Middle Canopy with another Quick Connector (HH).




Figure 1

STEP 2 - Install the Canopy Chain Loop and Nipple

- A. Thread the nipple into the crossbar. Thread the lock washer and the hex nut onto top end of the nipple. Do not tighten at this moment.
B. Attach the crossbar to the outlet box and secure with outlet box screws (not included). Hand tighten until snug.
C. Thread the canopy chain loop onto the end of the nipple and hand tighten until snug. Place the ceiling canopy over the canopy chain loop against the ceiling to determine the correct position of the nipple. Thread the canopy lock ring onto the canopy chain loop. Adjust the nipple to allow the ceiling canopy to rest against the ceiling when held in place by the canopy lock ring.
D. Remove the canopy lock ring from the canopy chain loop and remove the ceiling canopy. Unscrew outlet box screws to remove the crossbar assembly. Tight the hex nut above the crossbar. And then reinstall the crossbar assembly to the outlet box.




Figure 2

STEP 3 - Install the Fixture Chain and Ceiling Canopy

- A. Adjust the fixture chain to your desired length by attaching chain if needed.
B. Put the supply wires through the fixture chain attaching link. Allow the wires pass through the fixture chain, pull the supply wires and the ground wire through the canopy lock ring and the ceiling canopy in order.
C. Attach one end of the fixture chain to the fixture loop with one quick link. Let the fixture and fixture chain up and adjust the other end of the fixture chain onto the canopy chain loop with another quick link.
D. The fixture will now hang safely.
E. Feed the supply wires and ground wire through the canopy chain loop and nipple into the outlet box. Cut the wires leaving approximately 6" of wire extending from the outlet box.
F. Go to Step 4 for wire connections and follow the directions. Return to Step F in this step when complete with Step 4.
G. Pull the ceiling canopy and canopy lock ring up the fixture chain and over the canopy chain loop. Tighten the canopy lock ring onto the canopy chain loop until tight.




Figure 3

STEP 4 - Wire Connections

- A. Use standard wire connectors (not included) to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.




Figure 4

STEP 5 - Install Bobechas, Socket sleeve, Crystal Ball and Bulbs.

- A. Place bobechas and socket sleeve over sockets as shown.
B. Install bulbs onto sockets and push energy into place.




Figure 5

There are ways to adjust the Fixture body vertically
If you find the Bottom Crystal Ball can not line up the bottom
frame finial . Please try belowing steps to adjust it.

First, if the direction of the lamp body and the crystal ball is not perfect, please gently rotate the Angle of the connecting rod to ensure that the crystal ball is at the center point.




Figure 1

second , If the previous steps still not work, check which side is more heavy to make the crystal ball not in the center. Turn the loop on the side of the metal ring which will adjust the length of the side rods to make the weight of the fixture averagely then to keep the balance of the bottom ball.as shown in the figure




Figure 2

third , please check the arms are locked in the lamp box averagely or not. If not , please adjust them , the space between them should be the same . This will make the fixture weight both sides the same.as shown in the figure




Figure 3

Fourth , If after the first step checking, the crystal ball still in the center. Exchange the bobèche both side. Different bobèche also have different thickness which effect the fixture weight bot side.as shown in the figure.




Figure 4