


## PREPARATION

- Record your model number for future reference.
- DANGER: Risk of electric shock. To avoid electric shock, the power must be turned off at the circuit breaker or fuse box before beginning the installation procedure.
- DANGER: Risk of electric shock. To avoid electric shock, the outlet box must be properly grounded.
- 4. Important Information. Inspect the product for any damage. This product is for indoor use only. Observe all local codes.

## Please see next page for a larger installation image

## TOOLS AND MATERIALS NEEDED



## FIXTURE INSTALLATION

- Remove the fixture and parts bag(s) from the carton. Put them onto a clean and soft cloth to protect finish. Confirm all parts are included.
- Determine what height you want the fixture to rest at by mixing and matching the down rods (H, I, J, and K).
- Thread wire and ground wire (L) through desired down rods (H, I, J, and K). Then tighten the desired rods together and attach to base structure (M).
- Loosen ball nuts (G) and remove mounting plate (B) from canopy (F).
- Thread wire and ground wire (L) through canopy (F), ball joint (E), mounting plate (B). Tighten ball joint (E) onto the top down rod (shown as H). Take care not to have canopy (F) Scratch downrod during this process.
- Trim excess cord to minimum 13" beyond canopy (F). Strip wires to 5/8" at the end, and twist.
- Attach mounting plate (B) onto outlet box with screws (D). Ensure ground screw (C) is attached to mounting plate (B) as shown.
- NOTICE: To avoid short circuit, make sure wires are not exposed. Fasten
  fixture green or bare ground wire to the green or bare copper wire in
  outlet box with wire nut (A) or fasten onto ground screw (C) on mounting
  plate.
- NOTICE: To avoid short circuit, make sure wires are not exposed. Fasten
  fixture white wire to the white wire in outlet box with wire nut (A). Wrap
  the wire connector with electrical tape so that the tape seals the end of
  wire nut (A). See diagram 1.
- NOTICE: To avoid short circuit, make sure wires are not exposed. Fasten
  the fixture black wire to the black wire in outlet box with wire nut (A).
  Wrap the wire connector with electrical tape so that the tape seals the
  end of wire nut (A). See diagram 1.
- Tuck wires carefully inside outlet box. Put ball joint (E) onto canopy (F).
   Please note that the notch in canopy (F) should rest in the slot in ball joint (E). Lift the fixture then attach the canopy (F) onto mounting plate (B) with ball outs (G).
- NOTICE: Do not exceed recommended wattage. Rated Max 60W, E26, type T. (Bulb(s) not included).
- 13. Install bulb to the socket.
- 14. Tighten glass shade (N) onto base structure (M).
- 15. Restore power to circuit at breaker or fuse box.

**CLEANING:** Please clean fixture with a soft and dry cloth ONLY. Clean glass with a mild soap.

