



## HOW-TO GUIDE

# SikaBond® Construction Adhesive

FLEXIBLE POLYURETHANE • PAINTABLE • STAINABLE • SANDABLE

### MATERIALS:

- Safety glasses and gloves
- Utility knife
- Cartridge of SikaBond® Construction Adhesive
- Standard caulk gun
- Small spatula

### SITE PREP & PROCEDURE

1. Make sure that all surfaces are clean, structurally sound, and dry. Remove all dirt, oil, moisture, and/or old adhesive that may adversely effect the adhesion of the material.
2. Cut the tip of the nozzle at a 45° angle to the desired bead size, then puncture the seal inside of the nozzle and place the cartridge into a caulking gun.
3. Wearing protective gloves and safety goggles, hold the gun at a 45° angle and squeeze the gun handle to start the flow of adhesive. One 10.1 fl oz. cartridge will yield 24 linear feet of adhesive in a 1/4" bead.
4. Gun the adhesive onto the substrate/area to be bonded. If desired, smooth the bead to a desired shape using a spatula.
5. Clean up all tools, spills, and excess material with clean rags after use. If necessary, use a paint thinner or other approved solvent such as acetone, following the solvent manufacturer's precautions.

