
HOGYME

User Manual

Instruction for Assembly 4' * 6' Metal Shed



Missing Parts, Quality Problem, Questions on Assembly? Email: Hogyme.service@gmail.com Request will be replied in 24 hours.

Model Number: HG61X0561

HG61R0644 HG61M0661 HG61N0734



Assembly Preparation

Owner's Manual

Please check local building codes regarding footings, location and other requirements before beginning construction.

Assembly instructions:

Reviewing all instructions and the appropriate information before you begin, make sure following the step sequence carefully for successful results.

Flooring base:

A good location for the storage building is a square and level area with good drainage. The base is not included in the kit which may need purchase separately or may construct a foundation and anchoring system of your own.

A strong plastic sheet (thickness: at least 150µm) should be placed under the foundation to assist in reducing rising dampness from the soil, thus reducing condensation build up in the shed. Your storage building must be anchored to prevent wind damage. Once secured, it is highly recommended applying silicone along the inside of the base rail to minimize condensation.

Parts and Parts List:

Before you start, separate and identify all the parts and hardware to be sure that you have all the necessary parts for your building (refer to the Parts List Page).

If you find that a part is missing, please notify the seller within one week after receiving the product. Do not attempt to assemble the building if parts are missing because any building left partially assembled may be seriously damaged by light winds.

Tools you need:

(Please tear off the safety protection layer before the assembly, keep the part number label if needed)




Safety must be put in the No. 1 position:

- Select a dry and calm day for your assembly. Team works (Two or more people) are required during the assembly. It is also recommended to finish the assembly in a day to avoid damage to the product or missing of some small parts.
- Wearing safety gloves, eye protection and long sleeves during the assembly to prevent injury. Pay attention to the sharp edge of some parts.
- 3. Children and pets are not allowed entering into the construction site.
- Never concentrate your total weight on the roof of the building.
 When using a step ladder make sure that it is safe.


Care & Maintenance:

- 1. Keep the shed clean with soft cloth, use water if necessary.
- 2. Keep the door tracks clear of dirt and other stuff that prevent them from sliding easily.
- 3. Clean the snow with necessary tools to make sure it is safe to enter into.
- 4. The shed is not made for living but storing stuff.
- 5. Please add some oil on the top and bottom door sliding channel to make door slides smoothly.


Size:




Area of installation requirement:



PRODUCT ASSEMBLY





HOGYME HOGYME

Hardware List

PART	NO.	Qty.	Box No.
	G2	4	2/2
000	GB	2	2/2
	GC	4	2/2
	GD	4	2/2
	GF	2	2/2
<m(2)< th=""><td>F1</td><td>199</td><td>2/2</td></m(2)<>	F1	199	2/2
	F2	68	2/2
400 (2)	F3	8	2/2
	S1	98	2/2
	S2	148	2/2
Ş >	1	1	2/2
۲ - ا	2	1	2/2
}	3L	1	2/2
<u> </u>	3R	1	2/2

PART	NO.	Qty.	Box No.
	4L	1	2/2
٢	4R	1	2/2
<u> </u>	5	1	2/2
.]	6	1	2/2
	7	1	2/2
	8	1	2/2
Г	9	1	2/2
г	10L	1	2/2
г	10R	1	2/2
г	11	1	2/2
	12L	1	2/2
	12R	1	2/2
г	15	2	2/2
Г	17	4	2/2

- ;

6

PART	NO.	Qty.	Box No.
,	20	4	2/2
	21L	1	2/2
	21R	1	2/2
	25L	1	1/2
	25R	1	1/2
€	27	2	1/2
• •	B1	4	2/2
	P1	6	2/2
	P2	4	1/2
	P3	3	1/2
\	P4	2	2/2


PART	NO.	Qty.	Box No.
	P7	6	1/2
	D1	1	1/2
	D2	1	1/2
	A1	1	2/2
г	28	2	2/2
	29	2	2/2
	30	2	2/2
Г	31	2	2/2

8

Check the package contents before getting started!


STEP 1

4L	× >	X1	4R	× >	X1
F1	(M)	X4			




PRODUCT ASSEMBLY

2	۷ ۲	X1	F1	√m (3	X2




STEP 3

1	۲	X1	F1	X2




PRODUCT ASSEMBLY

3L	}	X1	3R	}	X1
F1		X4			




STEP 5





The floor frame must be level and square or holes will not align.

(Notice: Measure the floor frame diagonally. When the diagonal measurements are equal, the floor frame is square.)




PRODUCT ASSEMBLY




Make the colored side of the steel plate outward.

	P2		X1	F1	₹	ХЗ
I	S2	0	Х3			




STEP 7

P1	X1	F1	₹	ХЗ
F2	X1	S2	0	ХЗ




PRODUCT ASSEMBLY

P2		X1	F1	₹	Х3
S2	(6)	ХЗ		,	




STEP 9

P1	X1	F1	₹	Х3
F2	X1	S2	0	Х3



PRODUCT ASSEMBLY

P2	X1	F1	4111 (3)	ХЗ
92	Y3			




HOGYME HOGYME


PRODUCT ASSEMBLY

STEP 11

P1	X1	F1	<m()< th=""><th>ХЗ</th></m()<>	ХЗ
F2	X1	S2	0	Х3




PRODUCT ASSEMBLY



STEP 13

P1	X1	F1	₹	Х3
F2	X1	S2	0	Х3




PRODUCT ASSEMBLY

STEP 14

9	r	X1	F1	₹	X6
S2	0	X6			



Put the side with fewer holes facing up.




STEP 15

	11		X1	F1	₹	X6
Ī	S2	©	X6			




Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 16






Put the side with fewer holes facing up.



STEP 17

F1	(3)	X6	S2	©	X6
				_	1 1



PRODUCT ASSEMBLY


	7	X1	8	0	X1
I	A1	X1			




HOGYME


PRODUCT ASSEMBLY


STEP 19





PRODUCT ASSEMBLY






HOGYME HOGYME

PRODUCT ASSEMBLY


STEP 21

P3	X1	F1	√m()	X10
F2	X2	S2		X10




PRODUCT ASSEMBLY

P3	X1	F1	√m (2)	X10
F2	X2	S2		X10




STEP 23

P1		X1	F1	△m ()	X6
F2	((C)	X1	S2		X6



PRODUCT ASSEMBLY

P3	X1	F1	√m (3	X8
F2	X1	S2		X8




HOGYME HOGYME

PRODUCT ASSEMBLY


STEP 25

P1	X1	F1	√m()	X8
F2	X2	S2		X8



PRODUCT ASSEMBLY

P4	1	X2	F1	√m (2)	X8
F2		X2	S2		X8




HOGYME

PRODUCT ASSEMBLY


STEP 27

25L	: : : : : : : : : : : : : : : : : : : :	X1	25R	: : : : : : : : : : : : : : : : : : : :	X1
F1	√m (3	X12	S2		X12




PRODUCT ASSEMBLY

12L	X1	12R	X1
GF	X2	F2	X4




STEP 29

B1	 X2	F2	X4




PRODUCT ASSEMBLY






STEP 31



PRODUCT ASSEMBLY

21L		X1	21R	X1
F1	400 ()	X10	F2	X6






Screws on the top panel can't be fixed too tightly in the beginning, and they can only be tightened after all holes are aligned.


STEP 33

P7		X6	F1	₹	X34
92	(A)	X24			



PRODUCT ASSEMBLY

15		X2	17	г	X4
GC		X4	F1	√m()	X18
S2	(a)	X14			





STEP 35

D1		X1	20	 X1
27		X1	30	 X1
31	r	X1	F2	Х3




GD	(F)	X2	F2	X4







STEP 37

29	 X1	GB	(000)	X1
F2	Х3		•	




PRODUCT ASSEMBLY






STEP 39

F2	X4



PRODUCT ASSEMBLY

D2]	X1	20	 X1
27		X1	30	 X1
31	r	X1	F2	ХЗ





STEP 41

GD	X2	F2	X4




29	г	X1	GB	(X1
F2	(III)	Х3			





STEP 43


20	 X1	28	Г	X1
F2	X5			



PRODUCT ASSEMBLY

STEP 44







HOGYME HOGYME

PRODUCT ASSEMBLY

STEP 45







PRODUCT ASSEMBLY



