



Ladder Stabilizer Part #65025

CAUTION: READ AND FOLLOW INSTRUCTIONS CAREFULLY BEFORE USE!

Read all labels on stabilizer and instructions with ladder. Check that the stabilizer is attached to the ladder correctly. Be sure the stabilizer is positioned inside of the ladder, between the ladder and work surface. Inspect for damaged or missing parts before each use. Never use a stabilizer with missing or damaged parts. Never repair a damaged stabilizer. Destroy stabilizer if exposed to excessive heat or any corrosive agent. **DANGER! Metal conducts electricity!**

Never use near any electrical current. Do not stand on stabilizer. Do not use as support for planks. Do not use stabilizer on any slippery surface. You should never use a stabilizer or any climbing equipment if you are not in good physical condition. Check that all four points/ends of the ladder and stabilizer are firmly supported to prevent excessive movements. Securely engage ladder locks before climbing. Before each use check to see if the wing nuts are tight.

Stabilizer is designed to support one person only (Max 300 lbs. 136.2kg). Follow ladder instructions for recommend angle against vertical wall. When used against a flat wall, bottom of the ladder must be 12" (30.48 cm) further away from the wall than the distance recommended by the ladder manufacturer. Never over reach beyond stabilizer to right or left.

Work directly in front of you. Failure to do so may cause injury.