

## ASSEMBLY INSTRUCTIONS

---

# METAL GARDEN SHED


---

8 x 6 Metal Shed



Store Your Patio Well

[www.patiowell.com](http://www.patiowell.com)



**Patiowell**  
Metal Garden Shed  
Installation Tutorial  
[https://www.patiowell.com/  
pages/video-t-ps1268s0bna](https://www.patiowell.com/pages/video-t-ps1268s0bna)


✉ [saleservice@patiowell.com](mailto:saleservice@patiowell.com)

# SITE PREPARATION

Level the ground surface.



Recommendation: Construct a wooden or concrete base as a foundation.





# BEFORE STARTING ASSEMBLY


Remove all of the pieces from the 1 package and spread them out on the ground. Before installation, please check the type and quantity of parts first.

It is recommended to use a clean work surface to spread the parts out and for pre-assembly steps. Review all instructions before you begin, continue to refer to instructions during assembly.

Be sure to follow all steps thoroughly.


Please prepare these components in advance at the beginning of each stage.

## REQUIRED TOOLS



## CAUTION























Some parts have steel edges. Please be careful when handling components. Always wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your shed. Do not attempt assembly on days with strong winds or low temperatures.



























Requires two people and takes 2-3 hours for Installation.  
Recommended to wear gloves to avoid scratches.  
Please read the manual carefully before installation.

**DO NOT RETURN YOUR UNIT  
TO THE STORE**  
Contact us first  
[saleservice@patiowell.com](mailto:saleservice@patiowell.com)








# ROOF PARTS

 A3 X2	 A4 X2	 C4R X2	
 C4L X2	 C5 X4	 GC X4	 F5 X4
 GE X2	 M2 X4	 M2L X4	
 M9 X2	 M10 X2	 M11 X4	
 M13 X2			
 PE3 X2			
 PE4 X4			
 PE5 X2			
 PE6 X2			













# WALL PARTS

			
W1A X12	WS2A X4	WS3A X2	ULA X1
			
			
			
			
			
			
			
			


# DOOR PARTS

					
DLA X1	DLB X1	DRB X1	DRA X1	DG X1	DH X4
				DF X1	
DX2 X4					

# SCREW


   F1(X371) M4*10	   F2(X46) M4*10
   F3(X32) M5*12	   F4(X5) M6*10






Bottom frame construction

09-12  
(page)




Wall construction

13-24  
(page)



Roof Mount


25-28  
(page)




Door installation

29-36  
(page)


## STEP 1




## STEP 2



## STEP 3




## STEP 4







## STEP 5




## STEP 6



## STEP 7




## STEP 8



## STEP 9




**Tips:** Align the gasket with the hole, and then use the electric drill to drill the V2 into the hole.




## STEP 10




Please align the screws with the screw holes for installation.






## STEP 11





## STEP 12




## STEP 13




## STEP 14






## STEP 15







## STEP 16







## STEP 17






## STEP 18



## STEP 19





## STEP 20






## STEP 21






x2





## STEP 22



Note: The door frame (ULA,UR1) should cover the raised part on the wall panel, not insert.




x2




x2




## STEP 23



## STEP 24




## STEP 25





**Note:** M2L is pressed into M2.

## STEP 26





**Note:** Do not tighten F2 yet.


## STEP 27




## STEP 28




**Note:** Finally tighten all F2.




## STEP 29



## STEP 30




## STEP 31




## STEP 32

**Note:** Do not install F1 and V2 in the holes near the outer side of PE5.







## STEP 33





## STEP 34






## STEP 35



**Note:** Do not install F1 and V2 in the holes near the outer side of PE5.




## STEP 36








## STEP 37




## STEP 38





## STEP 39




x2




## STEP 40



x4




# STEP 41




# STEP 42


The other door operates the same way




x2





# STEP 43





The other door operates the same way








STEP 44






# STEP 45






STEP 46



# STEP 47





# STEP 48







# STEP 49




**X2**



# STEP 50




X4




F3 X16


## STEP 51



Put it on the screw tip to prevent injury.



## FINISH



## CARE & SAFETY

- Unsuitable for storage of flammable or corrosive substances.
- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any step.
- Please consult your local authorities if any permits are required to erect shed.
- Periodically check shed to assure that it remains stable and that the site remains level.
- It is highly recommended to secure the shed to an immovable object or to the ground by drilling holes in the floor at the pre-marked locations and inserting proper screws into the ground (screws are not included).
- Wear safety-goggles and always follow the manufacturer's instructions when using power tools.
- Wash shed with garden hose or a mild detergent solution. Using a stiff brush or abrasive cleaner could damage shed.
- Hot items such as recently used grills, blowtorches, etc. Must not be stored in the shed.
- Heavy articles should not be leaned against the walls, as this may cause distortion.
- Keep roof clean of snow and leaves. Heavy amounts of snow on roof can damage the shed making it unsafe to enter.
- Although wind direction varies, it is an important factor when taking into account where to place your shed. Therefore, it is recommended to reduce wind exposure of the shed in general, and the door side in particular.
- Keep doors closed and locked to prevent wind damage.
- Do not stand on the roof.

