


HAPPINESS INSTALLATION



- If you have any questions with the product, please contact us by:
- **Email: customerservice@zoy-living.com**
(we will reply to you within 24 hours)

Assembly Instructions









CR6315NF51D-WF

Your recliner comes packaged in **two boxes**. Carefully remove all of components from the packaging and set aside for assembly.

CAUTION:


DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Package Contents


			
BOX 1		BOX 2	
A 1* Chair Seat	B 1* Chair Back	G 1* Left Armrest	H 1* Right Armrest
			
C 1* Left Ear (under the seat)	D 1* Right Ear (under the seat)	E 1* Massage Remote	F 1* Power Plug

PLEASE NOTE that Box 1 and Box 2 may not arrive on the same day. Please wait 2 or 3 days more for the second parcel. Have any questions, just be free to contact us for further shipping information.

Step 1 Insert both the left armrest (G) and right armrest (H) into the chair seat (A) by aligning the metal grooves and sliding down to the bottom.



Step 2 Insert the chair back (B) into the chair seat by aligning the metal grooves and sliding down to the bottom; Insert both the left ear (C) and right ear (D) into the chair Back.



ATTENTION!!

Ensure the slots of armrests and backrest are fully assembled to the bottom to avoid tilting or moving. And please not sit on the armrests for the user's safety.


Tips of Connecting Power Cords:

No.1 and No.2 wires connect the backrest to the chair seat. (White to White/ Red to Red)


No.3 wire connects the backrest to the power plug (F).

No.4 wire connects up the backrest and massage remote (E).

Plug the power source (F) into outlet to get the massaging and heating function working.



Remote Operation Instruction



Warnings

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly before you connect the chair to the power.
3. Please DO NOT sit on the armrests or footrest to eliminate the risk of tipping over.
4. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.
5. If the recliner doesn't work, you may try the following measures for self-checking firstly:
 - a) Check if all the cables are connected;
 - b) Check if the light of transformer is on.

If the chair still doesn't work, please feed the information back to our customer service in time and we'll help you solve the matter as soon as possible.

6. If you have any questions with the product, please contact us by:

Email: customerservice@zoy-living.com (we will reply to you within 24 hours)

