



Terraced Double Bed Extension

Installation Guide

Thank You!

You're only a few steps away from your perfect vegetable garden or elevated planter. We hope you enjoy!

Model# R1421E4821
Dimensions 68" L x 21" W x 14" & 21" H


Before You Start

Please read the instructions carefully to familiarize yourself with every detail and step involved. Keep this manual for future reference. Find a suitable space to assemble your new Terraced Double Bed Extension with Everbloom Wallside Raised Garden Bed (Model# R144524) or Cornerstone Raised Garden Bed (Model# R212421). A flat and firm area (like a garage floor or flat yard space) is perfect! The only tool you may need is a rubber mallet.

Important Notes

Small parts are included; we advise you to keep them away from children and pets. We also suggest having another person help you assemble. Maximum Load capacity: approximately 12 cu. ft. of soil

★ **Subscribe at www.everbloom-garden.com for extra savings and upgrading information!**



Everbloom-Garden.com

Questions or Comments?
Email us at service@everbloom-garden.com

Parts List

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Left Joiner
Corner
X 2


Top



Bottom


Right Joiner
Corner
X 2

Top




Bottom

Short Board
X 8



540mm

Long Board
X 4



1140mm

Post Cap
X 4



+ 2pc
replacement

Assembly

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

This kit can be assembled with Everbloom Wallside Raised Garden Bed (R144524) to create a Low-Hi-Low triple bed. And it also can be assembled with Everbloom Cornerstone Raised Garden Bed (R212421) to create a Hi-Low-Hi triple bed.

With more of these extensions, you can build 5 beds, 7 beds or more continuous beds in this Hi-Lo version. Every extension can add a pair of Hi-Lo beds additionally, to an unlimited length, as long as your land can take.


** For Low-Hi-Low Triple bed, please follow steps of Assembly 1 from this page.*

** For Hi-Low-Hi Triple bed, please follow steps of Assembly 2 from page 9.*

Assembly 1

Start by making sure each corner post is oriented correctly. Reference image 1.

IMAGE 1




Assembly 1

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Fix the left joiner corner and left corner post (360mm) on one long board from above, as shown in Image 2.
Note: The boards need to be placed in the inward "U" shape of the brackets. (Image 2).

IMAGE 2




Assembly 1

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Fix other joiner corners and corner posts (360mm) on long boards from above, as shown in Image 3.

IMAGE 3




Assembly 1

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Slide all the short boards to form the bed, as shown in Image 4.

IMAGE 4




Assembly 1

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

If necessary, use your rubber mallet to ensure the boards are tightly in place. Cover the brackets with the 8 end caps, as shown in Image 5.

IMAGE 5




Assembly 1

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Now you get a Low-Hi-Low triple garden bed, as shown in Image 6.

IMAGE 6




Note: Store the additional caps for future use.

Assembly 2

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Start by making sure each corner post is oriented correctly. Reference image 7.

IMAGE 7




Assembly 2

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Fix the right joiner corner and left joiner corner on one long board from above, as shown in Image 8.
Note: The boards need to be placed in the inward "U" shape of the brackets. (Image 8).

IMAGE 8




Assembly 2

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Slide another long board from bottom and fix another two joiner corners on long boards from above, as shown in Image 9.

IMAGE 9




Assembly 2

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Slide all the short boards to form the bed, as shown in Image 10.

IMAGE 10




Assembly 2

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

If necessary, use your rubber mallet to ensure the boards are tightly in place. Cover the brackets with the 8 end caps, as shown in Image 11.

IMAGE 11




Assembly 2

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Now you get a Hi-Low-Hi triple garden bed, as shown in Image 12.

IMAGE 12



Note: Store the additional caps for future use.

Note

Terraced Double Bed Extension - 68" L x 21" W x 14" & 21" H

Sometimes there might be a misalignment of the Corner Posts as shown in Image 13 and Image 14, which may result in difficulty of sliding boards into the brackets. Please adjust them to the right position so that they are parallel to each other, and perpendicular to the ground.

IMAGE 13

Assembling Problem 1





IMAGE 14

Assembling Problem 2



Bloom On.

Everbloom-Garden.com

US Patent Pending

★ Subscribe at www.everbloom-garden.com for
extra savings and upgrading information!



Distributed by:
Dynaforge Trading LLC
St. Paul, MN55101
Email: service@everbloom-garden.com