

16535



***Call Us First!***  
***DO NOT RETURN TO STORE.***

**For immediate help with assembly or product information  
call our toll-free number:**

**1-888-826-9056**

**or email:**

***customerservice@backyardproductsllc.com***

**Our staff is ready to provide assistance.**

**April through October M - F 8:00 AM to 8:00 PM EST**

**Saturday 8:30 AM to 4:30 PM EST**

**November through March M - F 8:00 AM to 5:00 PM EST**

(This page is intentionally left blank.)

# ASSEMBLY MANUAL


## DOUBLE WINDOW w/ TRANSOM

### OPTION KIT

16535

09-30-2021

KEEP THIS MANUAL FOR FUTURE REFERENCE



**IMPORTANT!** READ INSTRUCTIONS THOROUGHLY PRIOR TO BEGINNING ASSEMBLY.



## BEFORE YOU BEGIN

- **BUILDING RESTRICTIONS AND APPROVALS**  
Be sure to check local building department and homeowners association for specific restrictions and/or requirements before building.
- **ENGINEERED DRAWINGS**  
Contact our Customer Service Team if engineered drawings are needed to pull local permits.
- **CHECK ALL PARTS**  
Inventory all parts listed on the next page. Contact our Customer Service Team if any parts are missing or damaged.

## TOOLS REQUIRED

Drill / Driver

Utility Knife

Safety Glasses

Caulk Gun

Nail Gun or Hammer

Pencil

Tape Measure

Ladder

Square

Paint Tools

Sabre Saw/Hand Saw for Window Cutout


Safety! Always use approved safety glasses during assembly.

## - CUSTOMER SERVICE -


Call: 1-888-827-9056 email: [customerservice@backyardproductsllc.com](mailto:customerservice@backyardproductsllc.com)

# PARTS LIST

PART STAMP ID:



## FASTENER/HARDWARE BAG





# FRAMING

## Parts Required:

X4 2 x 4 x 22-1/2"

X2 2 x 3 x 22-1/2"



AO  
LV

## Fasteners Required:

X12 3" Nails


X 8 2" Screws

## ASSEMBLY STEPS / NOTES:

1. Mark measurements on wall studs as shown.

### IMPORTANT!

Must have extra 2x4x96"  
stud for framing



# FRAMING

**Parts Required:**

X4	2 x 4 x 22-1/2"	<input type="text"/>	AO LV
X2	2 x 3 x 22-1/2"	<input type="text"/>	

\_\_\_\_\_

\_\_\_\_\_


AO  
LV

**Fasteners Required:**  
X12     3" Nails  
X 8     2" Screws

X 8      2" Screws

### ASSEMBLY STEPS / NOTES:


1. Use 3" nails as shown to install window framing centered on measurement marks.



# WINDOW CUTOUT

## ASSEMBLY STEPS / NOTES:

1. Drill a  $\frac{1}{2}$ " hole in each corner of framing as shown. Sixteen (16) holes.
2. For the transom windows you will have to cut back the siding along each stud. Cutting the siding back will allow for the transom window to fit in the opening extending over the studs, see below for measurements.
3. Cutout window opening beginning at one hole and cutting along framing.



# WINDOW INSTALLATION

## Parts Required:


X2 Small Window  
X2 Large Window

## Fasteners Required:

X24  $\frac{3}{4}$ " Screws

## ASSEMBLY STEPS / NOTES:

1. Insert windows into openings and screw in place using  $\frac{3}{4}$ " screws as shown.
2. For large windows use (2)  $\frac{3}{4}$ " screws in each corner.
3. Use (4)  $\frac{3}{4}$ " screws for the transom two each at the top and bottom.





# WINDOW TRIM

## Parts Required:

X2 Small Window  
X2 Large Window

## Fasteners Required:

X30 2" Finish Nails

## ASSEMBLY STEPS / NOTES:

1. Install window trim using 2" finish nails as shown. Trim is flush to window frame.

