
## ASSEMBLY INSTRUCTION

# **GAZEBO**

N715P261153+N715P261154



### **Read Manual**

Your gazebo Frame requires assembly prior to use. It is important that you read the entire manual to become familiar with the unit BEFORE you set up the gazebo Frame.

#### **Safety Warning and Precautions**


**WARNING:** When using product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

#### Read all instructions before assembly and usage this product

- **1. Select ideal location.** Set out all parts on a clear and level surface prior to assembly. Ideally, the gazebo Frame should be set up in the desired location to avoid moving it after assembly.
- **2. Use caution.** During all the processes of assembling, especially when lifting heavy or large parts, pay attention to safety.
- **3. Tools and Assistance.** Ladder and Phillips screwdriver are self-provided. Whenever possible, assistance is preferred.
- **4. Check for parts available.** Before assembling your gazebo Frame, make sure that you have all parts described in the Parts List.
- **5. Check for damaged parts.** Before assembling your gazebo Frame check for damaged parts. Any part that appears damaged should be carefully checked to determine if it can be operated properly and perform its intended function. Any part that is damaged should be properly repaired or replaced by a qualified technician.
- **6. Refer to assembly diagram.** During assembly, it will be helpful to refer to the assembly diagram.
- **7. Keep children away.** Children shouldn't be allowed in the work area. Do not let them handle parts and tools. No people should be permitted to enter into work area except who is working.


Note! This gazebo is meant to be used for Decorative and sunshade purposes only and is not meant to withstand all elements of the weather. Please remove all FABRIC during inclement weather.


N715P261153 PART LIST						
A x4pcs						
B x2pcs Fing Beam 1						
B2 x2pcs Ring Beam 2						
B3 x2pcs Ring Beam 3	··· · · · · · · · · · · · · · · · · ·					
B4 x2pcs Ring Beam 4						
C x4pcs Four-corner Upward Sloping Tube 1						
D x4pcs	e					
E xópcs esino-slanting Tube	•					
H x1pcs Top Plate 1	H2 x1pcs Top Plate 2					
K x4pcs Feet	K2 x4pcs Foot Gover					
O x6pcs Middle Support	N x4pcs Four-corner Support					
U x4pcs U-shaped Connectors	P x4pcs Ring Beam Connectors					
T1 x8pcs Four-corner Wrapping Piece	T2 x6pcs Middle Wrapping Piece					





N715P261153 HARDWARE LIST			
1# M6*15 x156+4 Bolt 1			
3# M6*30 x32+2 Bolt 2			
4# M6*45 x2 Bolt 3			
6# x2 Gasket			
7# ST5×12 x14+1 Screw			
8# x88+2 Plastic Opening Ring			
R x2pcs Top Plate Hook			
R4 x2pcs Round Tube Connectors 2	0		
Q x8 Ground Spike			
S1 x1 Hex Wrench			
S3 x1 Phillips Screwdriver	<b>→</b>		


N715P261154 PART LIST				
X1 x4 Sun Panel 1				
X2 x4 Sun Panel 2				
X3 x4 Sun Panel 3				
X4 x4 Sun Panel 4				
X5 x4 Sun Panel 5				
X6 x4 Sun Panel 6				
X7 x6 Sun Panel 7				
Y1 x2 Sun Panel 8				
Y2 x2 Sun Panel 9				
Z2 x4 Tulle				
Z3 x4 Sidewall				



















12/22














17/22


STEP 11 x2





X1x2	X2x2	X3x2		
X4x2	X5x2	x6x2	J1x4	J2x4





20/22

