



SUPA-BOUNCE 12FT TRAMPOLINE SET

MODEL# 9412TS - TRAMPOLINE
PRODUCT MANUAL - VERSION 7.20.03

FOR AGES:

6+

WEIGHT LIMIT:

320 Lbs
145 Kgs

ADULT(S) NEEDED:



TOOLS NEEDED:


N/A




WARNING/ADVERTENCIA


- Do not allow more than one person on the trampoline at any time.
- Do not allow small children to use unless supervised by an adult.
- ADULT ASSEMBLY REQUIRED.
- The contents of this package are not suitable for children under 3 years of age. Contains small parts which may cause choking.
- Consult a physician before beginning any exercise program or strenuous activity.

CUSTOMER SERVICE

 GQBrands.com

 CustomerService@gqbrands.com

 1-866-498-5269

 4401 Samuell Blvd, Ste 150
Mesquite, TX 75149

CUSTOMER SERVICE INFORMATION

Thank you for purchasing:

SUPA-BOUNCE 12FT TRAMPOLINE SET

MODEL# 9412TS

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com to open a ticket.

At GQBrands®, we want all of our customers to be completely satisfied with their purchase. Take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will provide replacement parts at no charge within 30 days of purchase.

Please keep in mind that for select damaged part replacement requests, we will require a photo for submission.

To register your product please visit:
www.globalqualitybrands.com/product-registration
or Scan code



To order these parts, or if you have any other questions or concerns about this GQBrands product, please contact us at

PureFun.Net
GQBrands®
Phone: 1-866-498-5269
Email: CustomerService@GQBrands.com
4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Please be sure to include the following information when you contact Customer Service:

YOUR NAME: _____

YOUR MAILING ADDRESS: _____

YOUR EMAIL ADDRESS: _____

PRODUCT NAME: _____

PRODUCT MODEL#: _____

PART NUMBER _____

RETAILER WHERE PURCHASED: _____

DATE OF PURCHASE: _____

ORDER NUMBER: (If Available) _____

QUANTITY NEEDED: _____

SERIAL NUMBER: _____

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of **1 YEAR STEEL/90 DAYS PARTS FROM THE DATE OF ORIGINAL PURCHASE**. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from the date of purchase. GQBrands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY,

THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQBRANDS® CAN WAIVE OR CHANGE.





IMPORTANT MESSAGE

WARNING - PLEASE READ

ADULT ASSEMBLY REQUIRED

CHOKING HAZARD - Small Parts

NOT for children under 3 years of age.

WARNING:

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risks of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

WARNINGS

Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:











- Ensure the trampoline has been assembled correctly, per the instructions in the manual.
- It is essential that the intended site for this trampoline is completely flat and level. If the ground is not level this will cause movement in the frame and could cause stress on the joined sections.
- Before each use of this product, inspect the entire assembly and replace any worn, defective or missing parts.
- It is only recommended for use by children 6+ years of age.
- DO NOT exceed the recommended MAXIMUM WEIGHT limit of 350lbs (159kgs).
- DO NOT allow more than one person on the trampoline at a time.
- DO NOT wear glasses or helmets when using the trampoline.
- DO NOT use the trampoline in wet, windy or other adverse weather conditions. Use only when the trampoline mat is clean, dry, and safe of obstructions.
- DO NOT somersault or perform flips. This can cause serious injury, resulting in paralysis or death.
- DO NOT use the trampoline as a springboard to or from other objects. NEVER jump from or attempt to jump to other objects, bodies of water, buildings or surfaces, or into or over the trampoline enclosure.
- DO NOT allow other persons to go under, sit, stand or lie on the trampoline or the frame pads while the trampoline is in use.
- DO NOT use the trampoline set when under the influence of alcohol, drugs or medication which may impair the jumper's judgment and coordination.
- ALWAYS remove jewelry, belt buckles or any other sharp objects before using the trampoline.
- ALWAYS jump in the center of the trampoline mat.
- ALWAYS secure the trampoline against unauthorized and unsupervised use.
- NEVER wear footwear (e.g. shoes) when using the trampoline. ALWAYS wear socks when using the trampoline.
- Children MUST NEVER use the trampoline unless supervised by a responsible adult with knowledge of trampoline use.
- Children MUST NEVER be left unattended at any time.
- Ensure the trampoline set is on level ground with a minimum of 8 feet (2.5M) clear space around the sides, 26 feet (8M) clear height space above and that no obstructions are under the trampoline.
- ALWAYS watch for power lines, overhead cabling, and other hazards or obstructions above, around and below the location where you are installing your trampoline set. Failure to do so can result in serious injury, death, and property damage.
- Mount and dismount from the trampoline and enclosure with care as injury may result. Children should be assisted when entering and exiting the trampoline to reduce the risk of falling.
- The frame of your trampoline set is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, etc.) should be permitted on or around the trampoline under any circumstance.
- Please read and refer to other warnings and use information in the trampoline instructions before use.
- Dispose of all packaging materials safely and per local ordinance. This Safety

SAFETY INFORMATION

- **Safety Information:** This trampoline is designed and manufactured to provide you and your family with many years of fun and exercise, but for your benefit and safety, please read this manual carefully and in full before assembling and using your trampoline.
- **DO NOT** allow more than one (1) person on the trampoline at a time. Multiple jumpers increase the chance of someone becoming injured. Jumpers may collide with one another, fall off the trampoline, fall on or through the springs or land incorrectly on the mat. Multiple jumpers increase the chances of loss of control, collision and falling off. This can result in severe injury or death.
- Always secure the trampoline against unauthorized and unsupervised use.
- Trampolines are rebounding devices which propel the user to unaccustomed heights and into a variety of body movements. Rebounding off of the trampoline, striking the frame or springs, or improperly landing on the trampoline mat (bed) may cause injury.
- The frame of your trampoline is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, extension cords, household appliances, etc.) should be permitted on or around the equipment under any circumstances to avoid the risk of electrocution.
- As your trampoline mat is raised off the ground, there is the risk of falling when entering or exiting the trampoline. Children should be assisted when entering and exiting the trampoline to reduce their risk of falling.
- Do not flip, somersault or perform maneuvers which may cause you to land on the head or neck. Paralysis or death can result even if you land in the middle of the trampoline mat.
- **IMPORTANT:**
You must not use the trampoline if you have a medical history of neck or back injuries or certain mental or physical conditions – an existing condition dramatically increases the risk of serious injury or death.
- No modification should be carried out to the trampoline or any of its components. Any modification could lead to damage to the product or result in a personal injury.
- **WEATHER CONDITIONS:**
Special care should be taken as weather conditions change. In particular, a wet trampoline mat (bed) is too slippery for safe jumping. Gusty or severe winds can cause jumpers to lose control. To reduce the chance of injury, use the trampoline only under appropriate weather conditions. In cold weather, tongues and lips can stick to metal at sub zero temperatures. In warmer and sunnier weather, parts can become extremely hot, and the temperature should be regularly checked during play, especially metal parts.
- **HIGH WINDS:**
It is possible for the Trampoline to be blown about by high wind. If you anticipate high winds, the Trampoline must be moved to a sheltered location, or be disassembled. Pure Fun™ is not responsible for any damage to property or product resulting from wind or extreme weather. You can purchase an ANCHOR KIT for your trampoline from Pure Fun, by visiting us on the web at: **www.PureFun.Net**

TRAMPOLINE PARTS LIST

Part #	Description	QTY	Part#	Description	QTY
1	Jump Mat	x1	5	Leg Extension	x10
2	Curved Top Rail	x10	6	U Shaped Leg	x5
3	T-Section with Bolt	x10	7	Spring	x70
4	M6x45mm Bolt	x15	8	Frame Pad	x1
4a	Nut	x15	9	Wrench	x1
			10	Spring Tool	x1





TRAMPOLINE ASSEMBLY INSTRUCTIONS

STEP 1:

Gather all 10 Curved Top Rails (Part 2) and 10 T-Sections (Part 3). Flip the Curved Top Rails (Part 2) over so the spring holes are facing up. Make sure to place them all on a flat and secure surface before you begin.

NOTE:

The Curved Top Rail has 7 spring holes in the top section.



STEP 2:

Unscrew the bolt from all 10 of the T-Sections (Part 3)


Step 3:

Connect both ends of the Top Rail (2) by sliding each end into the T-Section (3). Make sure the T-sections have the opening to attach the legs facing the ground.

Step 4:

Insert the M6x45mm bolt (4) into the top of the T-section (3) to secure both top rails using the wrench tool (Part 9). Tighten securely. Repeat step 3 and step 4 until you have formed a complete circle as shown to the left.

TRAMPOLINE ASSEMBLY INSTRUCTIONS




STEP 4:

Gather all Leg Extensions (Part 5) and U-Shaped Legs (Part 6). You will be attaching 2 leg extensions (5) to each U-Shaped Leg.

NOTE:

The Leg Extension will have 3 openings. The 2 openings closest to each other, will go on the top and connect to the T-Section at the top of the trampoline. Make sure to connect the U-Shaped leg to the single horizontal hole on the leg extension.



STEP 5:

Attach the U-Shaped Legs to the Leg Extensions with 1 M6x45mm bolt and Nut. Tighten with the Wrench Tool.


Repeat step 5 until you have 5 complete sets of U-Shaped legs with leg extensions.

STEP 6:

NOTE:

It is recommended that you use the help of 2 more adults in order to attach all Legs to Base of Trampoline.


Lift the Top Rail with T-Sections that you completed earlier and insert the U-Shaped Legs and Extensions into the T-Sections like picture shown to the left. Repeat step 6 until all 5 U-Shaped legs are attached to the top rail to form the entire base of the trampoline.



STEP 7:

THIS WILL BE ON EVERY OTHER LEG EXTENSION (The Enclosure Poles will be on the other leg extensions in step 4 of the enclosure section) - Attach the T-Section to the Leg Extension with 1 M6x45mm bolt and Nut into the top hole as shown in figure C. Tighten with the Wrench Tool.

TRAMPOLINE ASSEMBLY INSTRUCTIONS



Repeat step 7 until you have attached 5 of the top T-Sections which will look like figure shown.





Figure C

TRAMPOLINE ASSEMBLY INSTRUCTIONS



STEP 8:

Place the Jumping Mat (Part 1) in the middle of the frame and unfold it completely.

NOTE:

Make sure the stitching of the Jumping mat is facing the floor

In order to avoid ripping and to distribute tension when attaching springs to the frame, follow the numbered order shown.

Once a spring is attached to the Jumping mat, you must attach the other in the opposite direction of the mat.

Once the first 16 Springs (Part 7) have been placed, Attach all remaining Springs using the Spring Tool (Part 10) that was provided clockwise.

NOTE:


Failure to use appropriate tools may result in injury or pinching due to tension of the springs. We recommend you use gloves when attaching springs to the frame.

HOW TO USE SPRING TOOL:


In order to insert the spring properly, hook the curved end to the V-ring of the jumping Mat. Then, pull on the Long Round end with the Spring Tool until it is attached on one of the corresponding openings of the Top Rail as shown.

HOW TO USE SPRING TOOL:

In order to insert the spring properly, hook the curved end to the V-ring of the jumping Mat. Then, pull on the Long Round end with the Spring Tool until it is attached on one of the corresponding openings of the Top Rail as shown.



TRAMPOLINE ASSEMBLY INSTRUCTIONS


**STEP 9:**

Unfold the Frame Pad (Part 8) and place it on top of the Top Rail and springs. The skirt of the Frame Pad must cover the Top Rails completely to avoid injury.

NOTE:

Make sure the connecting straps are facing down towards the Top Rails in order to secure the Frame Pad to them in Step 10.

TRAMPOLINE ASSEMBLY INSTRUCTIONS





STEP 10:

Find all the bottom connecting straps of the trampoline frame pad and secure them by tying them in a knot around to the top rail to avoid moving or shuffling when jumping on the trampoline as shown below.

ENCLOSURE PARTS LIST

Part #	Description	QTY	Part#	Description	QTY
1	Straight Enclosure Pole	x5	6	Washer	x10
2	Curved Enclosure Pole	x5	7	Nut	x10
3	Enclosure Pole Cap	x5	8	Black String	x1
4	M6x75mm Bolt	x10	9	Enclosure Net	x1
5	Spacer	x10	10	Lime Pole Cover	x5



ENCLOSURE ASSEMBLY INSTRUCTIONS


STEP 1:

Gather all Curved Enclosure Poles (Part 2) and Enclosure Pole Caps (Part 3).

IMPORTANT:

Do not attach the Enclosure Pole Caps to the Straight Enclosure Poles. **If an Enclosure Pole Cap has been accidentally installed on a straight pole it cannot be removed.**

Slide all Enclosure Pole caps onto the top of the Curved Enclosure Pole. The top of the Curved Enclosure Pole will not have any holes at all.




STEP 2:

Collect all Straight Enclosure Poles (Part 1)

Connect the Straight Enclosure Poles and Curved Enclosure Poles using the Snap and Click mechanism. Button must be pushed down, and you will hear a click once successfully attached. See figure to the left.

You will repeat this until you have 5 complete Enclosure Poles.

ENCLOSURE ASSEMBLY INSTRUCTIONS



STEP 3:

Slide the Lime Pole Cover (Part 10) over the foam of the connected enclosure poles as shown. Repeat this on all 5 poles before moving to next step.

ENCLOSURE ASSEMBLY INSTRUCTIONS

STEP 4:


A. With the help of another adult, hold the completed enclosure pole by aligning both square holes to begin installation.

NOTE:


Curved Enclosure Pole must face towards the center of the trampoline.

B. Once aligned, attach the completed enclosure pole to the trampoline leg. Follow the directions on the next page (Page 16) for the order and right parts to attach properly


C. Continue to do this on EVERY OTHER Leg one by one until you have installed all 5 Enclosure poles tightly.




ENCLOSURE ASSEMBLY INSTRUCTIONS




M6x75mm Bolt




Spacer




Washer



Nut



ENCLOSURE ASSEMBLY INSTRUCTIONS




STEP 5:

Place the Enclosure Net (Part 9) on top of the trampoline. Align the straps to the corresponding Enclosure Poles so they are as near to each other as possible when lifted.

NOTE:



Make sure that zipper and buckle snap are facing the outside of the trampoline. This is good to ensure that Enclosure is not reversed.



STEP 6:

Use the Black String (Part 8) to attach the Enclosure Net to the Jump Mat. by sliding the string through the hole in the net then looping through the nearest V-Ring slot, and hook to an adjacent V-Ring as shown. Repeat this until ends meet then tie in a knot securely on each V-Ring.

Step 6:



A. Locate the top of the enclosure netting loops with snaps.

B. Detach the snaps by pushing on the middle of the buckle.

C. You can adjust straps on buckle as needed.

D. Once strap length is adjusted loop through enclosure pole cap and fasten.

FREQUENTLY ASKED QUESTIONS

- Question: "The foam padding or mat is damaged, what should I do?"

Answer: If you are still within your warranty period (90 Days from initial purchase) you should contact customer service. You can also purchase replacement padding and mats at: www.PureFun.net

- Question: "I had a part missing from my box" or "something was damaged in shipping, can you send it to me?"

Answer: If it has been 30 days or less from the date of your initial purchase, you can contact customer service for a replacement part to be issued.

CARE & MAINTENANCE

- It is essential that the intended site for this trampoline is completely flat and level. If the ground is not level this will cause movement in the frame and could cause stress on the joined sections.
- Before each use of this product, inspect the entire assembly and replace any worn, defective or missing parts.
- The following conditions could represent potential hazards: Missing, improperly positioned, or insecurely attached frame padding; Punctures, frays, tears, or holes worn in the bed or frame padding; Deterioration in the stitching or fabric of the bed or frame padding; Broken or missing springs; A bent or broken frame; A sagging jump mat; or sharp protrusions on the frame or suspension system; Bent or broken enclosure poles; Missing or torn foam on the poles; Torn or ripped enclosure netting; Broken or fraying zipper in the enclosure opening. Cease using trampoline immediately and secure it against unauthorized use if any of these conditions are present.
- If any part of the trampoline frame requires cleaning, simply wipe with a damp cloth. (Do not jump on the trampoline after cleaning until completely dry).
- To clean chalk from mat, wipe down net with wet rag. Allow mat to fully dry before jumping.

Thank You Coupon!

As a way of saying thank you for purchasing one of our products, here is a 10% OFF coupon for your next purchase at

www.PureFun.net

Use Code: GQBRANDS10 at Checkout