




INSTRUCTIONS FOR INSTALLATION OF SINGLE AND DOUBLE CYLINDER DEADLOCKS


FOR USE ON DOORS 1-3/8" TO 1-3/4" (35mm-45mm)

1. MARK DOOR

A. Fold and apply template to high edge of door bevel and mark center of door edge as indicated on template at the desired height from the floor.




B. Mark center hole on door face through guide on template for either 2-3/8" (60mm) or 2-3/4" (70mm) backset.




5. INSTALL EXTERIOR MECHANISM

A. Press cylinder side flush against door making certain the torque blade is properly positioned in latch cam.
B. Tapped holes in exterior cylinder should be lined up with latch holes. Key hole should be in down position.




TORQUE BLADE SHOULD BE HORIZONTALLY INSERTED INTO LATCH CAM.




2. DRILL HOLES

A. Drill thru door face as marked for lockset. It is recommended that holes be drilled from both sides to prevent splitting. Hole size is 2" (50.8mm) for standard installations.




B. Drill 1" (25mm) hole in center of door edge thru to 2" (50.8mm) hole for latch.




6. INSTALL INTERIOR MECHANISM

TURN PIECE 1" THROW




A. Slide turn piece onto torque blade.




B. Insert machine screws through holes engaging holes in cylinder and tighten.

3. INSTALL LATCH

A. Insert latch in hole keeping it parallel to face of door. Mark outline and remove latch.



B. Chisel 1/8" deep or until latch face is flush with door edge.



INSTRUCTIONS FOR INSTALLING DOUBLE CYLINDER DEADLOCKS


Exterior half is fully assembled with exterior torque blade.




EXTERIOR TORQUE BLADE

NOTE: This assembly is placed through latch first

C. Install deadbolt latch in up position into hole as shown on latch. Insert and tighten screws.




D. For drive-in deadbolt, press flush to door edge. Bolt must be vertically aligned with door edge as indicated by arrow.




4. INSTALL STRIKE


A. Bore 1" hole 1" minimum deep for deadbolt.




B. Mortise 1/16" deep for strike locating from 1" hole in door insert and tighten screws



B. Press interior assembly flush against door making certain the torque blade is properly positioned in latch cam. Key hole should be in down position.



C. Insert (2) two screws through countersunk holes engaging holes in exterior cylinder and tighten.



1 FOLD HERE

FOR INSTALLING DEADLOCKS

READ INSTRUCTIONS
1 1/2" (4mm) THICK
DOOR

2 MARK
PROPER
DOOR
THICKNESS

3 DRILL 1" (25mm)
HOLE IN EDGE OF DOOR
(2" IN DEPTH)

2 3/8" BACKSET

NOTE:
TEMPLATE MUST
BE PLACED ON
HIGH EDGE OF
DOOR BEVEL

