

Ramp Selection Guidelines



1

Determine Slope

Slope 1

The ADA recommended slope for long (up to 30 ft.) portable ramps—for strong unassisted manual chair users.

Slope 2

Maximum slope for occupied chairs and scooters with a qualified assistant.

■ **Slope 3**

For loading unoccupied chairs and scooters.

2

Determine Height

Measure the height or “rise” incline/decline.



3

Determine Ramp Type

Check the appropriate ramp type(s) based on your slope and height determination.

