


CHARISMA-X

SHOWER AND TUB DOOR INSTALLATION INSTRUCTIONS


PLEASE REVIEW THIS ENTIRE MANUAL PRIOR TO INSTALLATION



MODEL #s:
SHDR-136058X-##

= finish

01 - Chrome 06 - Oil Rubbed Bronze
04 - Brushed Nickel 09 - Satin Black



MODEL #s:
SHDR-134876X-##
SHDR-136076X-##

IMPORTANT!

DreamLine[®] reserves the right to alter, modify or redesign products at any time without prior notice for the purpose of product improvement and customer experience. Please refer to the model's web page on **DreamLine.com** for the latest technical drawings, installation manuals, warranty information or additional product details.

Do Not Return Product to the Store. Contact DreamLine[®] with any questions



Questions?

Please Call **DreamLine** Customer Support: **1-866-731-2244**
Hours of Operation M-F 8AM - 6PM EST

Support@DreamLine.com





This model is treated with DreamLine’s exclusive ClearMax™ Glass technology. This is a specially formulated coating that prevents the build up of soap and water spots.

Install the surface with the ClearMax™ label towards the inside of the shower. Please note that depending on the model, the glass may be coated on either one or both surfaces.

For best results, squeegee the glass after each use and dry with a soft cloth.

Record the following purchase information for your records or in the event you need to contact DreamLine®:

Purchase Order Number _____

Store/Vendor Purchased From _____

Installation Date _____

OD Number (optional) _____
*found on the shipping box or label if available.

Installed By: _____

SKU Number _____

Table of Contents

Section Title	Page #
ClearMax™ Coating Information	—
Warnings and General Preparation	2
Model Specific Preparation	3
Tools	4
Detailed Diagram of Shower and Tub Door Components	5
Parts List	6-7
Installation Steps	8-22
Wall Profile Installation	13
Towel Bar Handle Installation	20
Product Maintenance	23
Troubleshooting	24
Installation on an Unlevel Threshold	25
Factory Parts Information	26-28

Symbol Legend



TIP - for ease of installation.



CORRECT - recommended.



NOTE - take note of special feature; additional information.




INCORRECT - not recommended.



REQUIRED - requires special attention; signifies a warning.

Average Installation Time





IMPORTANT

- DreamLine® reserves the right to alter, modify or redesign products any time without prior notice for product improvement and customer experience. Please refer to the model's web page on DreamLine.com for the latest technical drawings, installation manuals, warranty information or additional product details.
- This product should be installed by someone familiar with the construction requirements for this type of project and the care necessary for the safe installation and operation of the product.
- The safety of any installation is the responsibility of the installer.
- Professional installation recommended. *(All Models)*
- Professional installation required. *(Enigma Series)*
- To prevent damage or serious injury, Do Not lean against the installed panel/door/glass.
- To prevent damage or serious injury: Do Not attempt to lift or move a heavy lite of glass alone. Use an assistant and/or a professional grade glass suction cup.
- The installation of some models may require drilling down into the threshold. Contact the manufacturer of the base, tub, or threshold material with any questions regarding the drilling of holes into their product.
- All drawings in this installation manual are for illustrative purposes only and are not drawn to scale.

TEMPERED GLASS WARNING

- Your Shower Door Glass Could Shatter Without Warning if Improperly Installed or Mishandled
- Do Not install or operate a shower door if the glass has chipped corners, slivered edges or is otherwise damaged and/or has been dropped or banged into a hard surface such as tile, marble or glass.
- **The main causes of tempered glass breakage are:**
 - Improper handling, storage or installation
 - Misuse/abuse
 - Lack of maintenance
 - Failure to replace damaged glass
 - **Improper handling during storage, unpacking and installation:**
 - Corners and edges are the most susceptible area to damage on a lite of tempered glass and should be protected and handled with care during storage, unpacking, installation and operation. A concentrated point of pressure or impact with a surface harder than itself may cause the tempered glass to shatter. The tempered glass may release immediately, within several hours or even days later.
 - **Incorrect installation of door hardware, rollers, hinges, channels, stopper or glass:**
 - Improper installation may include: loose hardware and/or lack of proper gaskets between the hardware and glass. Additionally, improper alignment of guide rails, wall profiles or other hardware during installation or operation may place stress on the glass edges and cause it to break.
 - This product must be installed by a professional and experienced installer familiar with the safe handling of tempered glass.
 - **Improper use of this product:**
 - Aggressively opening or closing the door may cause trauma to the glass, which can lead to breakage. This may occur immediately or hours or even days later.
 - **The shower door hardware and glass should be inspected periodically:**
 - Instruct the homeowner how to perform a periodic inspection of the shower hardware and glass - some minor adjustments may be necessary based upon the use (or misuse) of the shower door. Ensure that the hardware remains tight and that the door alignment and operation are correct. Any adjustments should be made upon discovery to prevent damage to the product.
 - Additional considerations should be given to the installation of frameless tempered glass products in households with young children or an elderly person due to an increased chance of improper handling. In such cases, alternatives such as shower curtains or grab bars should be considered.

GENERAL PREPARATION

- After opening all boxes and packages, read this introduction carefully. Check that all the items are included in the package by marking off the components on the **"Detailed Diagram of Product Components"** page. Examine all boxes and packages for shipping damage. If the unit has been damaged, has a finishing defect, or is missing parts; please contact our Customer Support department within 3 business days of the delivery date. **Please note that DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Please contact DreamLine® if you have any questions.
- **Please note that you should refer to your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.**
- If this unit is going to be installed in a new construction, install all the required plumbing and drainage before installing the shower. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**
- Make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please note that some adjustments and drilling will be necessary during the installation process.
- Protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until it is necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.
- This unit must be installed upon a finished threshold and against finished walls.
- *DreamLine® shower doors are not designed to be installed into a fiberglass surround due to the radius corners and lack of a solid surface to mount the hardware.*

WARNING: TO AVOID THE RISK OF DAMAGE OR INJURY:

- **Follow all recommendations and requirements as shown in the installation instructions.**
- Perform a thorough inspection of the glass and all parts for any damage prior to installation. Any damage to tempered glass can cause breakage. **Do Not install damaged glass!**
- Do Not install or operate a shower or tub door if the glass has chipped corners, slivered edges or is otherwise damaged. Do Not install or operate a shower or tub door that has been dropped or banged into a hard surface such as tile, marble or glass.
- **CAUTION:** Contact with any hard surface can damage tempered glass and cause it to shatter.
- This product uses tempered glass. Glass cannot be cut after it has been tempered. **Do Not attempt to cut tempered glass.**
- DreamLine® Glass Shower doors, Tub doors, Inline panels, and Return panels can shatter due to improper handling or lack of maintenance. Conduct periodic inspections of glass and all parts for possible damage, missing or loose parts.
- Always wear proper safety equipment such as: safety goggles, work gloves and appropriate footwear during the installation process.
- **WARNING. Risk of leakage and/or damage.** Follow all instructions regarding the application of silicone sealant or caulk. Allow 24 hours for the sealant to cure before the initial use of the shower or tub product. Follow the silicone manufacturer's recommendations regarding the use of their product.
- **Thoroughly read these instructions before installing or using this product.**
- **Leave this manual for the end-user of the product.**




This product should be installed by someone familiar with the construction requirements for this type of product and the care necessary for the safe installation and operation of the product.







Model Specific Preparation

! REQUIRED:


No Out-of-Plumb Adjustment; Verify threshold and walls with a level




Threshold must be level




Tile



Acrylic



Tub





Contact the manufacturer of the base, tub or threshold material with any questions regarding the drilling of holes into their product.



Drilling into a stud or other wood reinforcement behind the wall is recommended.



DO NOT install the Towel Bars onto the Door Glass until instructed. DO NOT attempt to lift the glass with the Towel Bars. This could result in damage to the glass and/or serious personal injury. Always use an assistant or a professional-grade glass suction cup when handling heavy glass.




Professional installation recommended. Two installers suggested.

Tools




Level




Tape Measure



Pencil



Phillips Screwdriver



Silicone



Power Drill



Drill Bit
Ø9/64"
(3.5mm)



Drill Bit
Ø3/16"
(5mm)



Drill Bit
Ø5/16"
(8mm)



Drill Bit
Ø3/8"
(10mm)




Soft Head Hammer




Safety Glasses




Work Gloves




Mitre Saw




Hacksaw




Painter's Tape



Razor Knife



Professional-grade Glass suction cup



0-5/16" tapered shims
(wood or plastic)

Threshold must be level; Walls must be plumb.



Measure the finished opening before proceeding with the installation to be sure that the correct model size has been ordered.



Use a good quality waterproof, mildew-resistant 100% silicone caulk.



Be sure to cover the shower drain to prevent losing small parts.




Unpack your unit carefully and inspect it. Lay it out and identify all parts using the **Detailed Diagram** on page 5; and packing list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine® for replacement. The shipping boxes may contain extra parts not used in your model configuration. Retain these installation instructions for future reference.



These instructions will show the installation of the shower door. Please follow the same steps for the installation of the tub door.

Detailed Diagram of Shower and Tub Door Components















CLEARMAX
 The glass surface with
 the ClearMax™ label
 must be installed
 facing the inside of
 the shower

CLEARMAX
 The glass surface with
 the ClearMax™ label
 must be installed
 facing the inside of
 the shower


for Model #:
 SHDR-136058X-##
 SHDR-134876X-##
 SHDR-136076X-##

Parts List



Parts List


15



ST4.0×55mm
Pan Head Screws

x4



16



ST4.0×16mm
Pan Head Screws

x4

17




Wall Profile

x2


Installation Steps

1






**This model does not allow for out-of-plumb wall conditions!
If the threshold is unlevel, refer to page 25 for further
instructions, before proceeding!**

Tools Needed




2




Use a metal file to deburr the cut end

Parts Needed




Tools Needed



The Top Guide Rail (#01) fits wall-to-wall and can be cut from either end.

3



W^{bot} - 1/16"
equally from
both ends

Fig 3a




Fig 3b





Fig 3c




Use a metal file to deburr the cut end

Parts Needed



Tools Needed



4




Fig 4



Before marking its desired position, make sure the **Bottom Guide Rail (#02)** is parallel to the front edge of the shower base or tub deck.



Use painter's tape to secure the **Bottom Guide Rail (#02)** in place while the silicone caulk cures.

Tools Needed



5




Fig 5

NOTE

Repeat this step to install the **Guide Block (#12)** on the opposite side.

Use caution not to move the Bottom Guide Rail (#02) out of position while drilling and attaching the Bottom Guide Blocks (#12a/12c)!

Parts Needed


- 06 x4
- 09 x8
- 12 x1set
a c

Tools Needed

-
-
-

6

Wall Profile Installation



7





Fig 7



Correctly position the **Wall Profiles (#17)** onto the guide blocks by aligning the inside face of the **Wall Profile** with the inside-face of the **Bottom Guide Rail (#02)** as shown above. (See Figs 8.2-3)

Parts Needed



Tools Needed



8






Fig 8


NOTE

- **If a stud is present behind the wall:**
drill a $\text{Ø}3/16''$ (4mm) hole up to the stud, drill an $\text{Ø}1/8''$ pilot hole into the stud and use the **ST4.2 x 40mm Countersunk Screws (#08)**
- OR
- **If no stud is present behind the wall:**
drill a $\text{Ø}5/16''$ (7mm) hole and insert the **Wall Anchors, 8mm (#05)** and use the **ST4.2 x 40mm Countersunk Screws (#08)**.

Parts Needed



Tools Needed



9




Fig 9



Before proceeding, **repeat steps 7-9** to install the **Wall Profile (#17)** and **Guide Rail Bracket (#11)** on the opposite side. **If the threshold is unlevel, refer to page 25 for further instructions before proceeding.**

Parts Needed

(11)	(15)
(x1)	(x2)



The **Guide Rail Bracket (#11)** aligns with the outside-facing edge of the **Wall Profile (#17)**.
(See Fig 9.2)

- **If a stud is present behind the wall:** drill a $\text{Ø}3/16''$ (4mm) hole up to the stud, drill an $\text{Ø}1/8''$ pilot hole into the stud and use the **ST4.0 x 55mm Pan Head Screws (#15)**
- OR
- **If no stud is present behind the wall:** drill a $\text{Ø}5/16''$ (7mm) hole and insert the **Wall Anchors, 8mm (#05)** and use the **ST4.0 x 55mm Pan Head Screws (#15)**.

Tools Needed

10





Fig 10



To ensure proper operation of the doors, the **Top Guide Rail (#01)** must be installed level and parallel to the **Bottom Guide Rail (#02)**. If the threshold is unlevel, refer to page 25 for more information.

Parts Needed



11





Fig 11

Ensure that all **Roller Assemblies (#10)** face towards the outside of the shower and only two roller assemblies are inserted into each guide rail channel. (see Fig 11.4)




Make sure to secure both **Guide Rail Brackets (#11)** to the **Top Guide Rail (#01)** with the **ST4.0×16mm Pan Head Screws (#16)**. (see Fig 11.7)

Parts Needed






Tools Needed




12



Be sure to cover the drain to prevent losing any screws



To avoid glass-to-metal contact, use **0-5/16"** wedged shims when installing the **Door Glass (#03)** onto the **Roller Assemblies (#10)**!



Parts Needed







Fig 12

*Top Guide Rail (#01) hidden for clarity of installation



Rotating the Roller Assembly (#10) Outer Disk:

The disk bolt is positioned off-center by 1/8" to provide for some minor adjustments to the **Door Glass (#03)** to achieve a better seal with the **Wall Profiles (#17)**.

An assistant is needed to support the weight of the glass when loosening the bolt, rotating the disk and re-tightening the bolt.

13

Towel Bar Handle Installation

NOTE

On the outside-facing Door Glass (#03), the Towel Bar Handle (#04) is facing outward.

NOTE

On the inside-facing Door Glass (#03), the Towel Bar Handle (#04) is facing inward.







Fig 13



DO NOT attempt to lift the glass with the Towel Bars (#04). This could result in damage to the glass and/or serious personal injury. Always use an assistant or a professional-grade glass suction cup when handling heavy glass.

Parts Needed



Tools Needed



14







Fig 14

Parts Needed



Tools Needed



15



The surfaces need to be clean and free of debris before applying silicone.





Fig 15



Allow 24 hours for the silicone caulk to cure before using the shower.

Tools Needed



Product Maintenance

BASES and BACKWALLS: To ensure long lasting life for your acrylic back walls: wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could permanently scratch or dull the surface.

GLASS: To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface of the glass.

HARDWARE: To ensure a long lasting finish: wipe off all metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft clean-cloth.

Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with the grain (not across the grain). Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.



To maximize the life of your door, it is important to regularly inspect the glass and other hardware for misalignment, proper attachment, and/or damage. Contact DreamLine® with any questions or concerns.

CHARISMA-X Maintenance Checklist

- Bottom Guide Rail** secured and tight to the threshold
- Guide Blocks (left, middle, right)** secured to the **Bottom Guide Rail**
 - Wall Profiles** align properly with the **Bottom Guide Blocks**
- Guide Rail Brackets** level and secured to the **Top Guide Rail** and wall
- Top Guide Rail** level and parallel to the **Bottom Guide Rail**
- During operation, the **Door Glass** passes through the **(middle) Guide Block** and creates a seal with the **Bulb Vinyl Inserts** and **Wall Profiles**
- Roller Assembly** bolts tight and adjusted so the **Door Glass** creates a seal with the **Bulb Vinyl Inserts** and **Wall Profiles**
- Towel Bar Handles** bolts tight and vinyls are present to avoid glass-to-metal contact
- Decorative Phillips Screw Caps** are present and covering all screws securing the **Guide Block(s)** and **Wall Profile(s)**
- Inspect the edges of the **Door Glass** for concealed damage
 - Damaged glass must be replaced!**
- Replace damaged or missing **Bulb Vinyl Inserts**
- Inspect and replace silicone as necessary to prevent water leakage

Troubleshooting

Problem/Symptom	Suggested Solution
Missing Parts	<ul style="list-style-type: none"> •Check all shipping/package material for missing parts/components. •If not found, contact DreamLine Customer Support [1-866-731-2244] to order factory part replacement.
Top Guide Rail (#01) and/or Bottom Guide Rail (#02) was cut too short.	<ul style="list-style-type: none"> •If either the Top Guide Rail (#01) and Bottom Guide Rail (#02) is cut too short during installation, contact DreamLine® Customer Support [1-866-731-2244] to order factory part replacement.
Door Glass (#03) does not seal into the Wall Profiles (#17) during operation.	<ul style="list-style-type: none"> •Shim the Door Glass (#03) and adjust the Roller Assemblies (#10) to achieve a better seal with the Wall Profiles (#17) [see Page 19] •Confirm the Wall Profiles (#17) are installed in the correct position so the Door Glass (#03) makes even contact with the Bulb Vinyl Inserts (#13) during operation. •Confirm with a level that the Top Guide Rail (#01) and Bottom Guide Rail (#02) are installed level and parallel to one another. •Removal and reinstallation of the Wall Profiles (#17) maybe necessary to achieve a tighter seal. [see Pages 13-15]
Water Leakage: beneath the Bottom Guide Rail (#02)	<ul style="list-style-type: none"> •Confirm the Bottom Guide Rail (#02) has been tightly secured to the threshold with silicone caulk [see Page 11] •Confirm the entire unit has been properly sealed with a waterproof, mildew-resistant 100% silicone caulk; allow at least 24 hours for the silicone to cure and set before using the shower unit. •Direct the shower head/water flow away from the area
Towel Bar Handle(s) (#04) are loose.	<ul style="list-style-type: none"> •Verify that the vinyl gaskets and screws are in place and tightly secured. [see Page 20]




Prior to contacting DreamLine® Customer Service, please have the following information readily available:

- Purchase Order Information
 - Name, PO Number, Dealer/Vendor Name, etc.
- SKU/Model Number (see Pages 26-28)
- Factory Part Information (see Pages 26-28)

© DreamLine® All Rights Reserved

Installation on an Unlevel Threshold




If the threshold is not level:
Install the **Wall Profile (#17)** on the **higher side** of the unlevel threshold first.

1. Install the **Wall Profile (#17)** on the **higher side** of the threshold
2. Install the **Guide Rail Bracket (#11)**. Attach the **Top Guide Rail (#01)** and use a level to find the location for the Guide Rail Bracket on the **lower side** of the threshold.
3. Install the Guide Rail Bracket for the **lower side**. Then install the **Wall Profile (#17)**.
4. The **Roller Assemblies (#10)** may need adjustment to ensure the doors close properly into the **Guide Blocks (#12)** and **Bulb Vinyl Inserts (#13) / Wall Profiles (#17)** during operation.

During Installation Step 9:

When your threshold is not level:

A gap will be present between the **Wall Profile (#17)** and **Guide Rail Bracket (#11)** on the **lower side** of the unlevel threshold.



Example of gap between the wall profile and guide rail bracket on the lower side of an unlevel threshold.

Factory Parts Information

CHARISMA-X 60 x58 {SHDR-136058X-##}		FACTORY PARTS INFORMATION	
ITEM #	FACTORY PART NUMBER	ITEM DESCRIPTION	QTY
01	042420 11 -1524 / 042420 41 -1524 / 042420 61 -1524 / 042420 91 -1524	Top Guide Rail	1 pc
02	041120 11 -1524 / 041120 41 -1524 / 041120 61 -1524 / 041120 91 -1524	Bottom Guide Rail	1 pc
03	10220040	Door Glass	2 pcs
04	0722 1 033 / 0722 4 033 / 0722 6 033 / 0722 9 033	Towel Bar Handle Assembly for 8mm (5/16 in) Glass	2 pcs
05	07552148	Wall Anchor 8mm (5/16in)	8 pcs
06	092102	ST4.2 x 16mm Countersunk Screw	4 pcs
08	092108	ST4.2 x 40mm Countersunk Screw	4 pcs
09	0755 1 156 / 0755 4 156 / 0755 6 156 / 0755 9 156	Decorative Phillips Screw Cap	8 pcs
10	0732 1 001 / 0732 4 001 / 0732 6 001 / 0732 9 001	Roller Assembly	4 pcs
11	0701 1 045 / 0701 4 045 / 0701 6 045 / 0701 9 045	Guide Rail Bracket	2 pcs
12a	07553148	Bottom Guide Block (Left) for 10mm (3/8in) Glass	1 pc
12b	07553150	Bottom Guide Block (Middle) for 10mm (3/8in) Glass	1 pc
12c	07553151	Bottom Guide Block (Right) for 10mm (3/8in) Glass	1 pc
13	063064000-1398	Bulb Vinyl Insert	4 pcs
15	091131	ST4.0 x 55mm Pan Head Screw	4 pcs
16	091102	ST4.0 x 16mm Pan Head Screw	4 pcs
17	042270 11 -1389 / 042270 41 -1389 / 042270 61 -1389 / 042270 91 -1389	Wall Profile	2 pcs

BOLD digit indicates finish color:

- 1** = Chrome
- 4** = Brushed Nickel
- 6** = Oil Rubbed Bronze
- 9** = Satin Black

Contact Support@DreamLine.com for Part replacement, installation assistance or additional information.

Complete **Warranty** information is available on DreamLine.com.

Factory Parts Information

CHARISMA-X 48 x76 {SHDR-134876X-##}		FACTORY PARTS INFORMATION	
ITEM #	FACTORY PART NUMBER	ITEM DESCRIPTION	QTY
01	042420 1 1-1219 / 042420 4 1-1219 / 042420 6 1-1219 / 042420 9 1-1219	Top Guide Rail	1 pc
02	041120 1 1-1219 / 041120 4 1-1219 / 041120 6 1-1219 / 041120 9 1-1219	Bottom Guide Rail	1 pc
03	010220041	Door Glass	2 pcs
04	0722 1 093 / 0722 4 093 / 0722 6 093 / 0722 9 093	Towel Bar Handle Assembly for 8mm (5/16 in) Glass	2 pcs
05	07552148	Wall Anchor 8mm (5/16in)	8 pcs
06	092102	ST4.2 x 16mm Countersunk Screw	4 pcs
08	092108	ST4.2 x 40mm Countersunk Screw	4 pcs
09	0755 1 156 / 0755 4 156 / 0755 6 156 / 0755 9 156	Decorative Phillips Screw Cap	8 pcs
10	0732 1 001 / 0732 4 001 / 0732 6 001 / 0732 9 001	Roller Assembly	4 pcs
11	0701 1 045 / 0701 4 045 / 0701 6 045 / 0701 9 045	Guide Rail Bracket	2 pcs
12a	07553148	Bottom Guide Block (Left) for 10mm (3/8in) Glass	1 pc
12b	07553150	Bottom Guide Block (Middle) for 10mm (3/8in) Glass	1 pc
12c	07553151	Bottom Guide Block (Right) for 10mm (3/8in) Glass	1 pc
13	063064000-1851	Bulb Vinyl Insert	4 pcs
15	091131	ST4.0 x 55mm Pan Head Screw	4 pcs
16	091102	ST4.0 x 16mm Pan Head Screw	4 pcs
17	042270 1 1-1846 / 042270 4 1-1846 / 042270 6 1-1846 / 042270 9 1-1846	Wall Profile	2 pcs

BOLD digit indicates finish color:

1 = Chrome

4 = Brushed Nickel

6 = Oil Rubbed Bronze

9 = Satin Black

Contact Support@DreamLine.com for Part replacement, installation assistance or additional information.

Complete **Warranty** information is available on DreamLine.com.

Factory Parts Information

CHARISMA-X 60 x76 {SHDR-136076X-##}		FACTORY PARTS INFORMATION	
ITEM #	FACTORY PART NUMBER	ITEM DESCRIPTION	QTY
01	04242 011 -1524 / 04242 041 -1524 / 04242 061 -1524 / 04242 091 -1524	Top Guide Rail	1 pc
02	04112 011 -1524 / 04112 041 -1524 / 04112 061 -1524 / 04112 091 -1524	Bottom Guide Rail	1 pc
03	010220006	Door Glass	2 pcs
04	0722 1033 / 0722 4033 / 0722 6033 / 0722 9033	Towel Bar Handle Assembly for 8mm (5/16 in) Glass	2 pcs
05	07552148	Wall Anchor 8mm (5/16in)	8 pcs
06	092102	ST4.2x16mm Countersunk Screw	4 pcs
08	092108	ST4.2x40mm Countersunk Screw	4 pcs
09	0755 1156 / 0755 4156 / 0755 6156 / 0755 9156	Decorative Phillips Screw Cap	8 pcs
10	0732 1001 / 0732 4001 / 0732 6001 / 0732 9001	Roller Assembly	4 pcs
11	0701 1045 / 0701 4045 / 0701 6045 / 0701 9045	Guide Rail Bracket	2 pcs
12a	07553148	Bottom Guide Block (Left) for 10mm (3/8in) Glass	1 pc
12b	07553150	Bottom Guide Block (Middle) for 10mm (3/8in) Glass	1 pc
12c	07553151	Bottom Guide Block (Right) for 10mm (3/8in) Glass	1 pc
13	063064000-1851	Bulb Vinyl Insert	4 pcs
15	091131	ST4.0×55mm Pan Head Screw	4 pcs
16	091102	ST4.0×16mm Pan Head Screw	4 pcs
17	042270 11 -1846 / 042270 41 -1846 / 042270 61 -1846 / 042270 91 -1846	Wall Profile	2 pcs

BOLD digit indicates finish color:

1 = Chrome

4 = Brushed Nickel

6 = Oil Rubbed Bronze

9 = Satin Black

Contact Support@DreamLine.com for Part replacement, installation assistance or additional information.

Complete **Warranty** information is available on DreamLine.com.



TEL: 866-731-2244
FAX: 866-857-3638
DREAMLINE.COM



For more information on DreamLine® Shower Doors and Enclosures please visit **DreamLine.com**