


ASSEMBLY INSTRUCTIONS

30 INCH BATH VANITY (COMBO)






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Thank you for buying our products.

Please read the installation manual carefully before installation,

we need you to follow the instructions on the accessories and hardware

step by step assembly complete, our instructions are very detailed.

Products are environmentally friendly products,

Please rest assured that you do not soak in water, do not place very heavy items,

do not malicious push and pull,

if you have any problems in the process of assembly and use, please contact us.

Thank you again for your purchase of our products,

I wish you a happy life.

Before Installation










Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- . We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.
- . Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions















		Diagram A Insert Cam Bolt into hole as shown in diagram A.	
		Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.	
		Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - CABINET














Identifying the Hardware-Identify the hardware using the illustrations below.





















Part List - N725P269701

1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Mid Panel - 1pc		Top Frame - 1pc
5		6	
	Top Panel Rear - 1pc		Top Bar Front - 1pc
7		8	
	Bottom Panel Rear - 1pc		Mid Bar - 1pc
9		10	
	Bottom Frame - 1pc		Flip Drawer - 1pc
11		12	
	Flip Drawer Face - 1pc		Adjustable Shelf - 1pc
13		14	
	Door Cabinet - 1pc		Door Side Panel (L) - 1pc









Part List - N725P269701

15		16	
	Door Side Panel (R) - 1pc		Door Mid Panel (A) - 1pc
17		18	
	Door Mid Panel (B) - 1pc		Door Mid Panel (C) - 1pc
19		20	
	Round Bar - 1pc		Drawer Face - 2pcs
21		22	
	Drawer Back Panel - 2pcs		Drawer Side Panel (L) - 2pcs
23		24	
	Drawer Side Panel (R) - 2pcs		Bottom Drawer Panel - 2pcs
25			
	Sink - 1pc		




Hardware List - N725P269701


A  ø13x1/4"x28mm	B  ø1/4"x16x1mm	C  ø6x35mm
Hex-Head bolts(4pcs)	Washer(4pcs)	Three in one bolts(31pcs)
D  ø14.5x12mm	E  ø8xø4x19mm	F  ø8xø4x32mm
Three in one lock(31pcs)	Round head screw(2pcs)	Round head screw(16pcs)
G  Handle (4pcs)	H  ø5/32"x20mm	I  ø5/32"x32mm
Handle (4pcs)	Handle screw (1pc)	Handle screw (3pcs)
J  Damping hinge (2pcs)	K  ø7xø3.5x12mm	L  ø8x30mm
Damping hinge (2pcs)	Flat head screw(12pcs)	Wood dowel(41pcs)
M  ø6x30mm	N  Hinge(1pc)	O  Rotary Hinge (2pcs)
Wood dowel(8pcs)	Hinge(1pc)	Rotary Hinge (2pcs)
P  ø6xø3x12mm	Q  Laminate pad (4pcs)	R  4mm
Flat head screw (8pcs)	Laminate pad (4pcs)	Allen key(1pc)
S  Anti fall hardware(1set)	T  ø8xø4x25mm	
Anti fall hardware(1set)	Round head screw(2pcs)	

STEP: 1











STEP: 2

D	L	T
		
6PCS	6PCS	2PCS









STEP: 3







E		G		I	
2PCS		1PC		1PC	
		O		P	
		2PCS		4PCS	



STEP: 4

A	B	D
		
2PCS	2PCS	6PCS
L		
		
7PCS		












STEP: 5

A	B	D
		
2PCS	2PCS	5PCS
		L
		
		6PCS












STEP: 6

C	D	L	N	P
				
4PCS	4PCS	4PCS	1PC	4PCS







STEP: 7

C	D	L	J	K
				
10PCS	10PCS	18PCS	2PCS	4PCS




STEP: 8




G	H	K
		
1PC	1PC	8PCS


Use the screws to adjust up or down




Use the screws to permanent




Use the screws to adjust left or right




Use the screws to adjust in or out










STEP: 9



Q

4PCS


STEP: 10

F	G	I	M
			
16PCS	2PCS	2PCS	8PCS






x2

STEP: 11




STEP: 12

Wall




STEP: 13

**Install the sink on the cabinet with glue.
Let stand for 24 hours**




***Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.**

STEP: 14



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

