

# Metal Garden Shed

## OWNER'S MANUAL

Size 6 Ft X 9 Ft



Tall walk in Shed

Quick & Easy Assembly

Ridge Reinforced walls




Wide Double Doors

Available in Various Sizes

















Take care of sharp edges;














Please wear gloves;









It will take 2 people 4 - 5 hours to install.






## PARTS LIST


NO1	PART	QTY
D1		1
D2R		2
D2L		2
D3		1
D5		1
S1		1
S2R		2
S2L		2
S3		1
KL		1
KR		1
L1L		2
L1R		2
B1		4
B2L		2
B2R		2


NO1	PART	QTY
C		2
L3		2
L4L		2
L4R		2
GB1		4
GB2		2
GB3		2
GW1		1
GW2		1
GW3		1
M2		4
M3		4
M4		2
M5L		1
M5R		1
Q1		12

NO1	PART	QTY
Q2		4
Q3		5
Q4		18
M		2
J1		4
MB		2
DJT		2
FJT		4
ZJT		2
DGT		4
GE		2
GD		4
G2		4
B3L		1
B3R		1
F1		392

## PARTS LIST

NO1	PART	QTY
F3		24
F11		25
F14		300

NO1	PART	QTY
F4		12
LSM		75

NO1	PART	QTY
F8		4

Install LSM at screw exposure, Prevent collisions.

This part is used with all screws, Such as F1 and F3, located in the external tool room. Easy to seal and waterproof.

## Warning & Attention:

**-Take care of sharp edges; Please wear gloves;**

-You are advised to read the whole procedure before installing it;

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;

-All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step.

Each screw has a surplus quantity, which can be used in reserve

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

## Tools:



Gloves



Ladder



Electric drill




Phillips screwdriver



Safety Helmet Hat




goggles



Note: Take care of sharp edges.

All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step.

NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
D1		1	D2R		2	DGT		4	F1		12
D2L		2	D3		1	DJT		2	F8		4



Notice:

DJT installation: At the junction of two arrows, please install in the direction indicated by the arrows (→←).

DGT installation: Two ground pallets are connected to the DGT as shown in the figure.

Each DGT needs to be fixed with two F1s.




F8 installation: After the overall installation is complete, in the case of mud floor.

F8 is installed into the DGT hole, as shown in Figure 1.

Use expansion screws to install other floors.




The installation space should be flat, and at least 2300x3100mm. The foundation is fixed on the ground in this space.






Note: Please wear gloves


NO.	PART	Qty.
D5		1




Notice:  
You do not need to install screws in this step. Align the holes, which are the same as in the previous step.






NO.	PART	Qty.
Q2		4
F1		12



Notice:  
In this step, only the three holes in the middle of Q2 need to be installed and reserved on both sides. The reserved holes are shared with the following steps.






NO.	PART	Qty.
S1		1
G2		4







Notice:




G2 has been placed in the S1 before delivery. If it slides out, follow Step A to insert it



NO.	PART	Qty.
S2R		2
S2L		2

NO.	PART	Qty.
ZJT		2
S3		1

NO.	PART	Qty.
FJT		4
F1		12







Notice:


ZJT installation: At the junction of two arrows, please install in the direction indicated by the arrows (→←).

FJT installation: Connect the two floor frames to the FJT as shown. Each FJT needs to be fixed with two F1s.

S1 has no fixed hole positions




NO.	PART	Qty.
F1		12











Notice:  
 In this step, only the middle three holes need to be installed, and both sides need to be reserved.  
 The reserved hole is shared with other steps.  
 The walls are tiled on the outside and framed on the inside


NO.	PART	Qty.
Q1		12
Q3		5
F11		23
F1		132










Notice:  
 As shown in the picture, assemble the wall tiles in turn, Q1\Q3, The top, middle and bottom of the wall tiles need to be screwed,  
 The upper and lower ends are fixed with F1, and the middle is fixed with F11.




NO.	PART	Qty.
KL		1
KR		1
F1		4
F11		2






Notice:  
 As shown in the picture, the steps of door frame and wall tile installation are the same.  
 The upper, middle and lower parts of KR and KL need screws.  
 The upper and lower ends are fixed with F1, and the middle is fixed with F11.


NO.	PART	Qty.	NO.	PART	Qty.
B1		4	F3		2
B2L		2	F1		10
B2R		2			
L1L		2			
L1R		2			




Notice:  
 B1 has holes on both sides, and the large holes are 2 B1s, L1L, and L1R joined together.  
 The small holes are 2 B1s connected to L1R and L1L respectively.  
 B2R and B2L have holes on both sides, and the large holes are B2R and B2L connected to L4L and L4R.  
 The small holes are B2R and B2L, which are connected to L1R and L1L respectively.








NO.	PART	Qty.
F1		12




Notice:  
The assembled roof support parts are successively installed on the wall tiles with F1









NO.	PART	Qty.
C		2
F3		2
B3R		1
B3L		1



Notice:  
Connect C with 2 B1, L1L, L1R, B3L and B3R and fix them with F3;  
After completing step A, bend the other end of C about 45° and connect it to the bottom of L3.



NO.	PART	Qty.	NO.	PART	Qty.
L3		2	F3		16
L4L		2	F1		2
L4R		2			



Notice:



Step A: Insert the connected L4R and L4L into the B2L and B2R holes respectively.


Step B: Connect two L3s and place them on L1R and L1L.

Temporarily fixed with F1, later need to remove the hole and share with Q4.

The other end of part C is fixed to the bottom hole of L3 with F1.



Step C: Connect L4R and L4L and install both sides outwards, as shown in the figure.






NO.	PART	Qty.
Q4		18
F1		54




Notice:

Install Q4 in sequence, overlap between every 2 pieces, and each Q4 needs 3 rows of F1 fixed.





NO.	PART	Qty.	NO.	PART	Qty.
GB1		4	F1		6
GB2		2	J1		4
GB3		2			









Notice:

Step A: Use F1 to secure GB2 and GB3 to the positions shown in the figure.

Step B: Place GB1 and J1 in the positions shown in the figure and use F1 to secure them to the tiles.



NO.	PART	Qty.	NO.	PART	Qty.
GW1		1	GE		2
GW2		1	F1		10
GW3		1			
















Notice:



Step A: GW1, GW2 and GW3 are fixed at the top with F1.




Step B: GE is fixed at both ends with F1.


① Description: The holes on the most sides are shared by GW1, GW2, GW3, Q4 and GB1.




NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
M2		4	M5L		1	M		2	F3		4
M3		4	M5R		1	GD		4	F4		12
M4		2	MB		2	F1		6			





NO.	PART	Qty.
F1		3
F3		2
F4		6



NO.	PART	Qty.
F1		3
F3		2
F4		6



NO.	PART	Qty.
F1		8



Notice:

Use F1 to secure the installed door to the pulley

The adjustment of the door can be achieved by the three holes of the pulley being at different heights

