
### **ASSEMBLY INSTRUCTIONS**

# **PATIO SOFA SET**


If you have any questions, please feel free to contact us. Email: lowesteam@aminalife.com



NOTE: 50% TIGHTEN BEFORE FIXING ALL BOLTS


WF316867 WF316870 WF316868 WF316871

WF316869



#### **Notice:**

- 1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
- 2. Place the item on a flat ground to adjust and make sure it remains stable
- 3. Tighten up all screws with tools gradually.
- 4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
- 6. Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.




Hardware List		
1	2	3
Bolt M6 x 55 mm 4 pcs + extra 1 pc	Bolt M6 x 35 mm 74 pcs + extra 3 pcs	Bolt M6 x 25 mm 10 pcs + extra 1 pc
4	5	6
Bolt M6 x 15 mm 60 pcs + extra 3 pcs	Eru M6 4 pcs + extra 1 pc	M6 x 1 mm Washers 152 pcs + extra 3 pcs
7	8	9
Feet cap M6 x 15 mm 40 pcs + extra 3 pcs	Keeper Plate 24 pcs	Allen key M4 (2 pcs)
10		
Spanner (1 pc)		
4/13		

## CARTON CONTENT:


### WF316867



**C** x 8



L x 4



M x 1

#### WF316868



**A** x 1



**B** x 1




D x 2



E x 4



F x 4




M x 1

#### WF316869




H x 2



M x 1




N x 3



O x 1

## CARTON CONTENT:


### WF316870



J x 1




**G** x 2



I x 2



**K** x 2



N x 3



**HARDWARE** 

### WF316871



**A** x 1



**B** x 1




D x 2



E x 4



F x 4



M x 1

