


# ENCLO

HIDE IT WITH STYLE



## Alpine Screen Kit

36"W X 54"H

**60 min**

*Approximate assembly  
time for 2 panels*



**Scan the QR code**  
*for an assembly video*



## ASSEMBLY INSTRUCTIONS

**EC18012** (WHITE COLOR)

**EC18013** (CHARCOAL COLOR)

[www.encloscreens.com](http://www.encloscreens.com)

VER. 031622

## GENERAL INFORMATION



### IMPORTANT

- « Check the inside of the larger pieces in your box for other materials packed inside.
- « When assembling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- « We recommend an area approximately 5'x 8' for unobstructed assembling.
- « You should not need to use excessive force when assembling components.

## MISSING OR DAMAGED PARTS?

### VISIT OUR WEBSITE FIRST, SO WE CAN HELP YOU RIGHT AWAY!

Although great care has been taken to ensure proper packaging and handling of this product, occasionally problems occur. If you discover any missing, damaged, or defective parts, please visit our website to order replacement parts. If you experience any further trouble with your product, please contact our customer service department.

 [parts.nychbrands.com](http://parts.nychbrands.com)

 [support@encloscreens.com](mailto:support@encloscreens.com)

 **704-892-5222 / 877-234-6196**

*Customer service agents are available to take calls weekdays from 9am-5pm EST. If you call outside of business hours, please leave a voicemail.*

To help you quickly and accurately, please have reference item number **EC18012 (WHITE COLOR)** and **EC18013 (CHARCOAL COLOR)** and the specific part name which can be found on the next page. It is helpful if you can provide the batch lot which is a stamped number on the end of the box.


## NEED ASSEMBLY HELP?

If you are having problems with the assembly or installation of this product, we are happy to assist you with the process, **so please give us a call at 704-892-5222 / 877-234-6196.**











## NEED TO RETURN?

If for some reason you need to return this product, please allow us to help resolve your issues first. If you still decide to return the product, **you will need to initiate the return from the company you originally purchased from.**

## Detailed Product Dimensions & Specifications




## STEP 1: LAY OUT MATERIALS

<div>A</div> <div></div> <div><p><b>Note:</b> Holes through both walls.</p></div> <div><p><b>Middle Post (2)</b> 5/8" x 1" x 50 3/8"</p></div>	<div>B</div> <div></div> <div><p><b>Slat (44)</b> 1/4" x 1 1/4" x 34"</p></div>	<div>C</div> <div></div> <div><p><b>Post (4)</b> 7/8" x 1 1/2" x 53 7/8"</p></div>	
<div>D</div> <div></div> <div><p><b>Top Rail (2)</b> 1 1/2" x 1 1/2" x 36"</p></div>	<div>E</div> <div></div> <div><p><b>Bottom Rail (2)</b> 1 1/2" x 1 1/2" x 36"</p></div>	<div>F</div> <div></div> <div><p><b>Ground Stake (4)</b> 3/4" x 1 1/4" x 20"</p></div>	
<div>G</div> <div></div> <div><p><b>Rail End Cap (8)</b> (4 installed; 4 loose)</p></div>	<div>H</div> <div></div> <div><p><b>3/4" Self-Drilling Stainless Steel Screw (28)</b></p></div>	<div>I</div> <div></div> <div><p><b>Joiner Clip (2)</b></p></div>	<div>J</div> <div></div> <div><p><b>1/8" Drill Bit (1)</b></p></div>

## STEP 2: ASSEMBLING THE FIRST PANEL


### STEP 2.1

1. Insert (22) Slats **(B)** through the Middle Post **(A)**.
2. Insert (1) Post **(C)** over one end of the slats until they hit the back wall of the post.
3. Insert (1) post over the ends of the slats until they hit the back wall of the post.




## STEP 2.2

1. Insert (1) Bottom Rail (**E**) until the bottom of the middle post hits the bottom rail wall. Do not install the screws yet.
2. Insert (2) Ground Stakes (**F**) up the post until the pre-drilled holes in the anchor and the side of the posts align.
3. Drive (4) total  $\frac{3}{4}$ " Self-Drilling Stainless Steel Screws (**H**) in to the pre-drilled holes to secure the anchors.




## STEP 2.3

1. **(Optional)** Ensure the pre-drilled holes in the bottom rail and the post are aligned and pre-drill (4) total holes in the ground stakes using the included  $\frac{1}{8}$ " Steel Drill Bit (**J**).
2. Drive (4) total  $\frac{3}{4}$ " self-drilling stainless steel screws through the pre-drilled holes in the bottom rail.
3. Insert (2) Rail End Caps (**G**) over the ends of the top and bottom rail.




**STEP 2.4**

1. Insert (1) Top Rail (D) over the posts until the pre-drilled holes on the post and the top rail align.
2. Drive (4) total  $\frac{3}{4}$ "  $\frac{3}{4}$ " self-drilling stainless steel screws into the pre-drilled holes in the top rail.

**STEP 3: ASSEMBLING THE SECOND PANEL****STEP 3.1**

- Repeat steps 2.1-2.4 to assemble the second screen.




## STEP 4: INSTALLING PANELS IN THE GROUND


### STEP 4.1

1. Move the screen to its final location and mark where the posts meet the ground.
2. Attempt to push the screen into the ground.

1





2



**Push down**  
on posts with  
both hands.

### STEP 4.2

1. Loosen the top 6" of the ground with a claw hammer.
2. Add water to loosened soil.
3. Use a block of wood to protect the post and gently hammer each post into the ground.







**STEP 4.3**

► **Optional in hard ground:** If your ground is too hard, or you have more than 3 or 4 panels to install, please consider these options:

1. Use a 1¾" diameter auger bit (commonly used for planting tulips) as illustrated (\$15-\$20 on Amazon.com).
2. Drill a hole about 12" to 16" deep at the desired location, and fill the holes with water as illustrated.
3. Push the panel posts into the holes.

**STEP 4.4**

1. If your ground is very hard, you may need to dig an 8" by 14" deep hole to accommodate one post from each panel.
2. Level the screen as necessary, backfill excavated dirt, and tamp if needed.




## STEP 5: CONNECTING THE PANELS


### STEP 5.1

- 1. Straight Line Application:** Connect the screens as shown below using the Joiner Clips (I) and (4)  $\frac{3}{4}$ " self-drilling stainless steel screws.
- 2. Corner Application:** Connect the screens as shown below using the Joiner Clips (I) and (4)  $\frac{3}{4}$ " self-drilling stainless steel screws.

1



2





HIDE IT WITH STYLE

[www.encloscreens.com](http://www.encloscreens.com)

[support@encloscreens.com](mailto:support@encloscreens.com)



**704-892-5222**  
**877-234-6196**



*6935 Reames Rd. Ste. K.*  
*Charlotte, NC 28216*



## ASSEMBLY INSTRUCTIONS

**EC18012** (WHITE COLOR)

**EC18013** (CHARCOAL COLOR)