

BMS8100 / BMS8125 Storage Shed

ASSEMBLY INSTRUCTIONS

Tools Required









Scan QR Code for product assembly video.

Assistance is required during entire assembly.





Built for Everyday Life

Thank you for purchasing this Suncast® product.

Register within 90 days of purchase to activate Warranty!

Registration is not required for products with a warranty term of 90 days or less.

- 1. Verify warranty term of your product by visiting **www/suncast.com/warranty** (products with a warranty term of 90 days or less do not require registration)
- 2. Complete registration: fill out the form and upload a copy of your receipt by visiting https://support.suncast.com or scanning the QR code




Have Questions?

For product questions, assembly assistance, replacement parts and more:









Before you Begin...

- Consult your local authorities for any permits required to construct shed. Prior to the construction of your shed, check with the local building code official to review any required permits or building limitations.
- A level and sturdy foundation is required before shed construction can begin. Site preparation information is available later in this manual. A foundation that differs from the specifications within this manual could prevent proper assembly and may damage parts.
- **Read instructions thoroughly prior to assembly.** This kit contains parts that can be damaged if assembled incorrectly or in the wrong sequence.
- Please follow instructions. Suncast is not responsible for replacing parts lost or damaged due to incorrect assembly.



Indicates at least 1 additional adult is needed to complete this step.



Care & Maintenance

- At regular intervals, inspect your shed to make sure that assembly integrity has been maintained. Repair or replace broken parts immediately.
- Periodically check that the location you have chosen to set your shed is still level.
- Keep roof clean of snow and leaves.
- To maintain the look of your product, we recommend cleaning it at regular intervals with mild soap and water. DO NOT use bleach, ammonia, or other caustic cleaners, and DO NOT use stiff bristle brushes. Failure to perform cleaning at regular intervals could result in permanent staining of the plastic. This type of damage is not covered under warranty.



Assembly Day Tips

- DO NOT attempt to assemble on a day with strong winds.
- Set aside appropriate amount of time to completely assemble shed. An incomplete shed assembly may pose a safety hazard.
- Make sure you have assistance nearby to lift and secure parts in place.
- DO NOT use a torque wrench or hand drill to tighten easy bolts. Use provided easy bolt driver ONLY.
- Suncast provides extra hardware for small fasteners for customer convenience. In some cases, there will be extra small fasteners once the assembly is complete.

Note: This product contains parts that are used in different orientations to construct the shed. Please take note of the orientation of the parts shown throughout this instruction manual. Failure to follow instructions could result in damage to parts. Suncast is not responsible for replacing parts lost or damaged due to incorrect assembly.

Caution


- Proper site preparation is required.
- Shed not intended for storage of flammable, caustic or corrosive materials.
- Shed not intended for habitation or for use by children.
- **DO NOT** stand, sit, or store items on the storage shed roof.
- **DO NOT** place near objects that are hot or can become hot.
- Heavy articles should not be leaned against the walls, as this may cause panel distortion and permanent damage.
- Suncast is not responsible for damage caused by weather or misuse.
- This kit contains parts with sharp edges. Please be careful when handling, use of work gloves is recommended.
- **DO NOT** place in areas near highly reflective surfaces (Note: Low-E windows are more reflective than standard windows and may affect the longevity of the product).
- Product is water resistant and not waterproof. Locate unit away from gutter and down spouts for optimal performance.
- To maintain warranty coverage, the product should be padlocked with latching devices engaged at all times when not in use. Refer to the end of this manual for padlock specifications.


Parts- Walls and Floors

<u>IMPORTANT</u>

OPEN <u>ALL</u> BOXES FIRST AND NEATLY LAYOUT PARTS. SMALL PARTS MAY BE CONTAINED IN EACH BOX. PLEASE REFERENCE THE PARTS LIST WITHIN THIS MANUAL TO VERIFY <u>ALL</u> PARTS ARE PRESENT.

COMPLETE SITE PREPARATION AND <u>FOUNDATION CONSTRUCTION</u> BEFORE UNPACKING ALL PARTS.





Parts - Doors S 0440631 0B00163XXA 0440690A Door Window Left Door D-Ring Bolt xŽ х2

0102086XX

Door Window Frame

х2

0440655

Door Window Gasket

х2

0B00162XXA

Right Door

Parts - Headers 1MRG01002 1MRG01001 Ridge Beam (81.5") Ridge Beam (36.40") 1MRG10001 1MPG00001 Joiner (12") Header Bracket х2 0B00159XXB 1MRG02001 0B00161XXB Front Header Header Beam (62") Rear Header х2

Parts - Truss 0 1MRG05001 1MRG09003 1MRG09001 Truss Leg (52.2") Extension Bracket Roof Support Bracket (40.25") (35.1") χ4 χ4 х2 1MPG00003 Truss Bracket х2 1MRG06001 1MPG00024 1MPG00004 Truss Cross Beam (40.65") Side Adapter (11.5") Truss Strap (7.9") χ4 х4 χ4

Parts - Roof 010223107 0B00167XXA 0B00172XX Left Roof Left Roof Extension Skylight х6 х2 0464402 Skylight Sealing Gasket х6

0B00170XX


Right Roof Extension

0B00168XXA

Right Roof


х2

Parts - Hardware



Hardware shown at actual size (*Unless otherwise noted.) Extra hardware provided. Not all are used.

Parts - Door Handle and Door Latch Kits 0464240 - Door Handle Kit 010257710 x2 0480505 - Hardware Bag



*010257610 x2

Site Preparation and Platform Construction

Materials NOT supplied with Shed Kit

Important:

- Site preparation is required for this shed. Placing the shed on a properly constructed, square, flat and level foundation, as described below, is required. Without a properly constructed, square, flat and level foundation, settling will eventually occur, causing distortion and damage to the shed. Suncast is not responsible for replacing parts damaged or property lost due to incorrect foundation construction. Warranty requires a properly constructed foundation as described below.
- Complete the site preparation and foundation construction before unpacking parts and beginning assembly. For tips on site preparation, go to www.suncast.com, consult retailer, or local codes.

Site Preparation


- 1. Consult your local authorities for building codes and covenants before beginning foundation or erecting shed.
- 2. Before any digging, check with local utilities to determine location of buried cables, pipes, etc.
- 3. Decide which type of foundation is most suitable for your installation. The foundation surface must be square, flat and level. Follow the below guidelines for foundation options:

Concrete Slab

- Construct a slab of at least 4" thickness.
- The use of reinforcement bar is recommended.
- 4. Complete the foundation preparations as follows:
 - A vapor barrier may be applied over the foundation to prevent excessive condensation in the shed. Follow local building codes for a proper vapor barrier.
 - The ground should slope away from the foundation area to provide drainage.

Wood Platform

- · Use exterior grade wood.
- Set the platform on pier blocks or footing.



Anchor section example


Anchoring the floor panels to foundation is required after assembly is complete.

• Shed floor panels include flattened areas where anchors or lag screws are to be secured. These flat areas must be drilled through prior to securing the floor panels to the foundation.

Concrete Slab

 Secure shed to concrete slab using 3/8" masonry anchors with 1" washers. Masonry anchors and 1" washers are available at most local hardware retailers.


16 masonry anchors are required for this model



* Dimensions allow for shed to fit within the nearest 1" on each side.

Wood Platform

 Secure shed to wood platform using 1/4" - 3/8" x 3" lag screws with 1" washers. Lag screws and 1" washers are available at most local hardware retailers.16 lag screws are required for this model.




Note: Shed floor fastening locations are designed to align with the under-structure layout. Be sure the front of the base panels are oriented correctly on the platform to ensure lag bolts engage with the under-structure.


Site Preparation and Platform Construction

Materials **NOT** supplied with Shed Kit

Wood platform critical spacing



• Check all critical spacing measurements.




Wood platform materials list


Α	2	48" x 96" x ¾"
В	1	25¼" x 96" x ¾"
С	2	2" x 6" x 96"
D	4	2" x 6" x 141⁄4"
Е	7	2" x 6" x 118¼"

PLEASE NOTE-DIMENSIONAL LUMBER IS ACTUALLY ½" SMALLER THAN NOTED SIZES (A 2x 6 BOARD ACTUALLY MEASURES 1½" x 5 ½")

Pre-Assembly




Peel film from both sides of window (R).




Place gasket (U), window (R), and frame (T) into door channel. Secure with 10 screws (JJ), starting at corners. **Do not** overtighten screws. **Repeat** for right door (M).


Note: The cut portion of gasket **MUST** be assembled on bottom of door channel.




At top interior side of left door (L), attach 1 D-ring bolt (S) with 4 screws (JJ).



At bottom interior side of left door (L), attach 1 D-ring bolt (S) with 4 screws (JJ).




Place header beam (Z) into pocket of front header (J). Secure with 6 screws (JJ). **Do not** over tighten screws.




Slide roof ridge beam bracket (X) under tabs on inside peak of front header (J) and secure with 2 screws (JJ). **Do not** overtighten screws.


Repeat Steps 5-6 for rear header (K)



Place ridge beam joiner (DDD) into the 3' ridge beam (EEE). Secure with hex bolt (MM) and nut (LL). **Part (EEE) orientation is critical, see picture.**




Place 7' ridge beam (V) onto the ridge beam joiner (DDD). Secure with hex bolt (MM) and nut (LL).




Attach truss bracket (CC) to end of 1 truss leg (AA) with 1 hex bolt (RR) and nut (LL).

Repeat for second truss leg (AA).




Attach side adapter (FF) at end of left truss leg (AA) with 1 screw (MM) and nut (LL).

Repeat for remaining side adapter (FF).



Attach 2 truss cross beams (EE) to truss legs (AA) with 2 screws (MM) and nuts (LL).


Stand truss and check cross beam is level.




Place skylight gasket (YY) into skylight (HH). Place skylight (HH) onto right roof panel (O). Secure from underside with 8 screws (JJ). Make sure rib on plastic parts is seated fully against gasket on skylight.

Repeat for remaining roof panels.


Assembly



Push left floor (A) and right floor (B) panels together and secure with 6 screws (JJ).




Align left and right floor extensions (C,D) as shown and secure with 15 screws (JJ).




Align tab on bottom of left front corner (E) with slot on left floor (A). Lower panel into slot and lock in place by sliding panel toward door opening.

Note: A rubber mallet may be useful.





Tip left front corner (E) outward slightly and bend corner hinge.



Tip left front corner (E) back to vertical position and align lower tabs on right side with slots in floor.


Note: You will hear a snap when tab is fully engaged.






Align tabs on bottom of side panel (F) with slots along floor (A). Lower panel into slots and lock in place by sliding panel toward front corner.


Note: A rubber mallet may be useful.




Secure side panel (F) with 4 easy bolts (NN), working from floor to roof. Use easy driver and hand tighten. **Do not** overtighten.




Repeat steps 15-20 for remaining panels.




Place front header (J) over door opening. Align header tabs with pockets on corners. Secure front header using 2 screws (JJ).



Place rear header (K) over back walls. Align header tabs with pockets on back walls. Secure rear header using 7 screws (JJ).




Slide truss assemblies into place. Secure with 4 screws (JJ) in each side adapter.



Raise ridge beam (V/EEE) up and into rear header (K). Secure with 1 bolt (MM) and nut (LL). **Do not** overtighten. **Repeat for front header (J).**

Note: Header panels may need to be pushed inwards or outwards slightly as ridge beam is slid into place.




Attach the roof truss assembly to the ridge beam with 2 screws (JJ).




Attach truss strap (GG) to side adapter (FF) with 2 screws (JJ).


Repeat for remaining truss straps.




Before proceeding, locate and identify the six slots on interior side of right and left roof panels.




Before proceeding, locate and identify six front header tabs and six rear header tabs.




Lay right roof (O) directly over three tabs on right side of front header (J). With right roof slots seated over/on header tabs, check alignment in all three spots.




Slide right roof (O) down towards the outside of shed.




Press edge of right roof (O) into channel on truss leg (AA).




Repeat Steps 28-30 for remaining roof panels. Install panels in the order shown. Note: At this point, fully tighten ALL hardware.




Pull down each lower corner of roof from outside. From inside shed, attach tabs on right front corner (I) and side panel (F) to roof panel with 4 screws (JJ).



Secure roof to truss using 6 screws (JJ). Each screw will attach at a corresponding screw boss on the roof.




Raise roof support bracket (DD) into position against roof. Slide roof support bracket (DD) into front header. Secure roof support bracket (DD) to underside of truss leg with 1 screw (JJ).




Secure roof support to roof using 3 screws (JJ).

Repeat Steps 34-35 to install and secure remaining roof support brackets to three outer roof panels.




Attach extension bracket (BB) to truss legs with 1 screw (JJ), each side.




Secure extension bracket (BB) to inner roof panel using 2 screws (JJ).


Repeat steps 36-37 to install and secure remaining extension brackets to other inner roof panel.




Push down the roof from outside. From inside shed, secure roof panels together along ridge of roof using 9 rubber washers (QQ) and sealing screws (PP).




Stand right door (M) upright with three hinge mounts facing right. Slide 1 door hinge (II) up onto each hinge mount. Rotate door hinges to outside of door.




With door hinge in open position, slide 1 door hinge over each hinge receptacle on inside of right front panel.



Secure each hinge with 1 screw (KK) and nut (LL). Repeat Steps 39-41 for left door (L).




Insert 2 screws (CCC), into left latch plate (TT), and through pre-drilled holes in doors. While holding plate in place on exterior door, secure with 2 washers (III) and nuts (GGG). Repeat for right latch plate (FFF).




From the outside of doors, insert door handles (SS) onto the handle plates (UU). On inside of the doors, place washers (HHH) on center door handle locations, and secure each handle (SS) with 1 long screw (KKK). Secure handle plates (UU) with 4 washers (HHH) and

screws (JJJ).



Secure shelf (YY) in desired corner with 4 screws (JJ). Repeat for remaining shelf (YY).

Note: Shelf can be located in any of the four corners.



Attach a 5/16" lock (not provided) to door latch, to properly secure shed.

Note: To maintain warranty coverage, the product should be pad-locked at all times when not in use.

