HARDTOP GAZEBO WITH NETTING

If you have any questions about the outdoor gazebo, please feel free to contact us. Customer Service Email: **Service@alaulm.com**



1216Gazebo24

IMPORTANT

PLEASE READ BEFORE YOU COMMENCE ASSEMBLY

Follow the guidelines in this user guide to ensure correct assembly and care for this product.

SPECIFICATIONS



Catalog

Specifications	01
Notice And Warning	03
Exploded Views	05
First Part	
Second Part	07
Third Part	
Fourth Part	09
Fifth Part	10
Parts List	11
Hardware List	15
How to Assemble Hartop Gazbo	

Note: The gazebo needs to be installed in cooperation with five people. The following tools are not included and needed for assembly:



Warning

1. A 5 personal assembly is required for this gazebo.

2. Please take appropriate actions as heavy rain, wind and snow can damage the gazebo. If necessary please disassemble and store it for later use.

3. In snowy conditions, please do not allow the thickness of the snow to be more than 1.82 inches on the roof, this should be cleared as soon as possible for your safety. When the wind speed reaches 38.49 km/h, please take measures to avoid the wind.

PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. Dear Customer,

Thank you for shopping with us!

When you receive the product, please make sure that all the parts are intact. Then please browse the entire installation manual before assembling. If any problem occurs unsatisfactorily as follows:

- A.The outer box is damaged
- B.The product is damaged / bent / cracked while you open the box
- C.The parts / accessories / assembly tools are missing
- D.The product is hard to assemble
- E. The instructions are not clear and can not be referred
- F.The product has functional problems
- G.Other aspects that you are not satisfied with
- Please feel free to contact us for help. Our after-sales team service
- (Service@alaulm.com) will reply within 24 hours
- and will do our best to resolve the problem for you.



Attention:

1.Please fix all the screws first, do not lock them off, after assembling is fully completed, lock all at once finally.

2.Please check the manual carefully and make sure you have received all the parts.

3.If there is any missing, please let us know the letter of the parts you need.

4.If there is any damage, please send clear photos to us, and we will check and offer you best solution soon.









FOURTH PART



FIFTH PART



	Parts List (Box A)			
A	R4	R5	R6	R7
Q		<u> </u>		
Column	Cover plate on big top diagonal beam	Large top diagonal beam under cover	Small top diagonal beam cover 1	Small top diagonal beam cover 2
4 PCS	4 PCS	4 PCS	2 PCS	2 PCS
(T2)	T3			
e	¢;			
Short side mosquito net tube	Long side mosquito net tube			
4 PCS	4 PCS			
		Parts List (Box B)		
D3	E3	E4	E7	(M7)
<u> </u>	<u> (</u>	(<u> </u>	<u> </u>	
Big Top Frame Long Tube	Short side beam 1	Short side beam 2	Long side center beam	Big Top Downtube 1
2 PCS	2 PCS	2 PCS	2 PCS	4 PCS
<u>M8</u>	T4			
¢	e			
Big Top Downtube 2	Long side center mosquito net tube			
4 PCS	2 PCS			

Parts List (Box C)				
D	(D1)	D4	E5	E6
17 -		f rend igt	<u> </u>	(<u> </u>
Connector for the upper part of the big top diagonal beam	Large top frame short tube	Small Top Connector	Long side beam 1	Long side beam 2
4 PCS	2 PCS	1 PC	2 PCS	2 PCS
(H1)	(H2)		L3	(L5)
		<u> </u>	3	<u> </u>
Diagonal brace 1	Diagonal brace 2	Small top short side girder	Small top long side beam	Small beams on the upper edge of the big top
4 PCS	4 PCS	2 PCS	4 PCS	8 PCS
L6	L8	(M1)	(M3)	(M4)
<u> </u>	<u> </u>			¢
Small beams on the lower edge of the big top	Small beam in the center of the long side of the big top	Small top short side downstops	Small top long side down stop tube 1	Small top long side down stop tube 2
8 PCS	4 PCS	2 PCS	2 PCS	2 PCS
M10	(R3)	(X1)	X3	X4
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	\$ <del>}•••</del> {			
Big top long side center retaining tube	Roof Plate	Large top frame short side mosquito net cover plate	Large top frame long side mosquito net cover plate 1	Large top frame long side mosquito net cover plate 2
2 PCS	1 PC	2 PCS	2 PCS	2 PCS
(Y2)	(Y3)	Y8		
	l.	<u> </u>		
Center Beam Lower Connector	Inclined beam stopper	Beam Inserts		
6 PCS	8 PCS	6 PCS		

Parts List (Box D)				
B	C	(J1)	G1	<b>G2</b>
			<del></del>	<u>, , , , , , , , , , , , , , , , , , , </u>
Spike cover	Floorboards	Center crossbar	Upper part of the big top diagonal beam	Lower part of the big top diagonal beam
4 PCS	4 PCS	6 PCS	4 PCS	4 PCS
K	(K1)	P	S	(Y4)
····				
Small top sloping beam	Small top center beam	Hook up	Layer	Connector under inclined beam
4 PCS	2 PCS	2 PCS	40 PCS	4 PCS
Y5	Y6			
Beam corner stopper	Beam center stopper			
4 PCS	6 PCS			



Hardware List(Box F)				
AA	BB	CC	DD	EE
				θ
Cross big flat he ad self-tapping M4*16	Flat washer M6	Cross Outer Hexagon Bolt M6*35	Hexagon nut M6	Flat head hexagon socket head bolts M6*45
20 PCS	4 PCS	8 PCS	4 PCS	32 PCS
FF	GG	HH	JJ	KK
Cross Outer Hexagon Bolt M6*20	Cross Outer Hexagon Bolt M6*15	Mosquito net ring	Cross Outer Hexagon Bolt M6*55	Cross Outer Hexagon Bolt M6*45
360 PCS	72 PCS	128 PCS	4 PCS	2 PCS
PP	QQ	(Z1)	(Z2)	UU
		2		
Round head nail Ø8*180	Cross Outer Hexagon Bolt M6*40	Open wrench M6	Allen key M6	Expansion Bolt M6*80
8 PCS	20 PCS	2 PCS	2 PCS	8 PCS

1. Please ensure that all accessories are complete before starting the installation.

2. Due to the variety of accessories, many accessories may be glued together, please check carefully

3. If any accessories are missing or damaged, please contact the seller immediately.

E-Mail: Service@alaulm.com




























































## www.alaulm.com

Make your life much better.