

Upholstered Barstool with Metal Frame



ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:












CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE


Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.


PARTS

A		4pcs	LEGS	E		SEAT BACK		I		M6*25 16pcs	SCREWS
B		"X" CONNECTOR		F		SEAT		J		M6*20 6pcs	SCREWS
C		"L"CONNECTOR		G		4pcs	WASHER	K		ALLEN WRENCH	
D		FOOT REST		H		4pcs	Floor Glides				

STEP 1




STEP 2



STEP 3

STEP 3A: Lay the Seat (Part F) upside down on a smooth, clean surface. Align holes in the "X" Connector with holes in the seat bottom. Attach "X" Connector and legs to the underside of the Seat using (4) Washers (Part G), (4) M6*25 Screws (Part I) and tighten with the Allen Wrench (Part K).




STEP 4



STEP 5

STEP 5: Attach Seat Back (Part E) to the "L" Connector using (3) M6*20 Screws (Part J) and tighten using the Allen Wrench (Part K).



STEP 6

STEP 6: Ensure all screws are securely tightened.

