



MANHATTAN
COMFORT

888-230-2225

help@manhattancomfort.com

















Rockefeller

Open Wardrobe

Included in the package


- 01 - Base / Top panel = 02 pieces
- 02 - Left side panel = 01 piece
- 03 - Right side panel = 01 piece
- 04 - Crossbar = 02 pieces
- 05 - Back panel = 01 piece
- 06 - Front of the drawer = 02 pieces
- 07 - Left side panel of the drawer = 02 pieces
- 08 - Right side panel of the drawer = 02 pieces
- 09 - Rear panel of the drawer = 02 pieces
- 10 - Base of the drawer = 02 pieces
- 11 - Decorative apply = 02 pieces
- 12 - Feet = 04 pieces
- 13 - Aluminum bar = 01 piece
- 14 - Shelf = 01 piece
- 15 - Metallic support = 02 pieces



**Tools needed
(not included)**




⌘ Phillips screw driver
⌘ Screw driver




Step 01

Fix the hardware (D) with the hardware (C) on the part (12).





Step 02

Connect the parts (02) and (03) onto the part (01) with the hardware (E) and the hardware (B).




Step 03

Connect the part (04) onto the part (14) with the hardware (H + K + L).





Pay attention for the position of the parts 04 and the position of the hardware K+L.



Then, use the hardware L on the hardware K to fasten on the part 14.


Step 04

Connect the part (05)
with the hardware (I).
Pay attention to the position
of the part (05)!



Step 05


Connect the part (11) onto the part (06)
with the hardware (C).



Step 06

Connect the parts (07), (08) and (09) with the hardware (B).


Apply the part (10) in the groove of the parts (07) and (08) until the groove of the part (09).



Step 07


Connect the parts (07), (08) and (06) using the hardware (F + G).

Apply the hardware (R) on the hardware (G).




Step 08

Use the hardware (C) with the hardware (N) as shown on detail.




Step 09

Connect the part (12) onto the part (14) with the hardware (J).
 Connect the part (12) onto the parts (02) and (03) with the hardware (E).
 Apply the hardware (R) on the part (12).




Step 10

Use the hardware (M) from the inside to the outside into the parts (02) and (03) to fastening the part (12).




Step 11


Connect the part (13) onto the part (15) with the hardware (O).




Step 12



Connect the part (15) onto the top of the part (12) with the hardware (A).



Step 13




Install the drawer fitting it into the slides fixed on the side of parts (02) and (03).


Attention! Tipover System




C = 02x



Q = 01x




O = 01x





P = 01x

wall




First, approach as close as possible to the wall




Then, pass the hardware (Q) through the hole of the part (05) as shown in the figure above. You will need a pencil to mark where you should drill the wall with a 3/8" drill bit to put in the hardware (P).

*press the hardware wings (P) to put in the hole that you drilled in the wall.



Hardware (P), plugged in the wall.



Then fasten with the hardware (C) the hardware (Q) on the part (01)