



### 2-LIGHT VANITY BAR 3-LIGHT VANITY BAR

Español p. 9

ATTACH YOUR RECEIPT HERE



#### MODELS #VB24-2BNK/VB24-2BK/VB24-2GD



MODELS #VB24-3BK/VB24-3BNK/VB24-3GD



APPROVED FOR USE IN DAMP LOCATIONS



Thank you for purchasing this ALLEN + ROTH product. Questions, problems, missing parts? Before returning, contact us on: **866-439-9800**, 8 a.m-8 p.m., EST, Monday-Sunday or **ascs@lowes.com**.

Purchase Date \_


1

#### TABLE OF CONTENTS


Package Contents	. 2
Hardware Contents	3
Safety Information	. 3
Preparation	. 4
Assembly Instructions	5
Care and Maintenance	. 9
Troubleshooting	. 9
Warranty	. 9

#### PACKAGE CONTENTS


\*Drawing representational only; product may vary in appearance.








		#4968564	#2525800
		#5130253	#2589587
PART	DESCRIPTION	#5130254 QUANTITY	
A	Fixture	1	1
В	Socket Ring	2	3
	(preassembled to fixture (A))		
С	Shade	2	3
D	Mounting Strap	1	1
	(preassembled to fixture (A))		
E	Crossbar	1	1
	(preassembled to mounting strap (D))		
F	Fixture Screw	2	2
	(preassembled to mounting strap (D))		
G	Decorative Nut	2	2
	(preassembled to fixture screw (F))		
Н	Nut	2	2
	(preassembled to fixture screw (F))		



#### HARDWARE CONTENTS (shown actual size)



## 

#### READ AND SAVE THESE INSTRUCTIONS

## 

- For your protection and safety, carefully read and understand the information provided in this manual completely before attempting to assemble, install or operate this product. Failure to do so could lead to fire, electrical shock or other injuries that could be hazardous or even fatal.
- TURN OFF ELECTRICITY at main fuse box (or circuit breaker box) before beginning installation by removing the fuse (or switching the circuit breaker off).
- DO NOT connect this fixture to an electrical system that does not provide a means for equipment grounding. Never use a fixture in a two-wire system that is not grounded. Installing a fixture into an electrical system not having a proper grounding means could cause metal parts of the fixture to carry electrical currents if any of the fixture wires, wire connections or splices were to become broken, cut or loose during the mounting or normal operation of the fixture. Under this condition, anyone coming in contact with the fixture would be subject to electrical shock, which could cause serious injury or death.
- DO NOT connect the BARE or GREEN insulation fixture ground wire to the BLACK (HOT) current-carrying wire or the WHITE (NEUTRAL) house wire. Connection of the BARE or GREEN fixture ground wire to the BLACK or WHITE house wires may cause metal parts of the fixture to carry electrical currents. Under this condition, anyone coming in contact with the fixture will receive electrical shock, which could cause serious injury or death.
- DO NOT damage or cut the wire insulation (covering) during installation of fixture. DO NOT permit wires to contact any surface having a sharp edge. To do so may damage or cut the wire insulation, which could cause serious injury or death from electrical shock.

## 

- All electrical connections must be in agreement with local codes and ordinances, the National Electric Code (NEC) and ANSI/NFPA 70-1999. Contact your municipal building department to learn about your local codes, permits and/or inspections. Risk of fire - most dwellings built before 1985 have supply wire rated for 140°F. Consult a qualified electrician before installation.
- To avoid personal injury, the use of gloves may be necessary while handling fixture parts with sharp edges.
- To reduce the risk of damage to the fixture, DO NOT use power tools to assemble any part of the fixture.

### SAFETY INFORMATION

## 

- DO NOT suspend any fixture by the house wires. A fixture must always be mounted directly to an outlet box or to a mounting strap that is first attached to the outlet box. Wire connectors will not support the weight of a fixture. Suspending a fixture by the house wires and wire connectors will result in the fixture falling, with the possibility of personal injury and the danger of electrical shock or fire.
- To reduce the risk of fire, electrical shock or personal injury, lever wire connectors provided with this light fixture are designed to accept only one 12-gauge house wire and one lead wire from the light fixture. If your house wire is larger than 12-gauge or there is more than one house wire to connect to the corresponding fixture lead wires, consult an electrician for the proper size lever wire connectors to use.

# 

- If you are not sure the lighting system has a grounding means, DO NOT attempt to install this fixture. Contact a qualified, licensed electrician for information regarding the proper grounding methods as required by the local electrical code in your area.
- All fixtures must be mounted to an outlet box that is supported by the building structure.
- DO NOT use bulbs having a wattage greater than the maximum value stated on the fixture. The use of bulbs with higher wattage than specified will increase temperatures and risk of fire.
- If a dimmer control switch is used with this fixture, obtain professional advice to determine the correct type to use as well as the electrical rating required.

#### PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

#### Estimated Assembly Time: 30 minutes

Tools Required for Assembly (not included): Flathead Screwdriver, Phillips Screwdriver, Wire Strippers, Pliers, Wire Cutters, Safety Glasses, Stepladder and Electrical Tape

Helpful Tools (not included): A/C Tester Light, Do-It-Yourself Guide, Soft Cloth, Level


1. Turn off circuit breakers and wall switch to the fixture supply line leads.


**DANGER:** Failure to disconnect power supply prior to installation may result in serious injury or death.


2. Remove existing fixture and disconnect all electrical wiring.

 Remove two deocrative nuts (G) from fixture screws (F) on front of fixture (A) and remove mounting strap (D) from back of fixture (A).

Save deocrative nuts (G) for later use.









4a. **CAUTION:** The fixture (A) must be mounted to an outlet box that is supported by the building structure and can support the weight of the fixture (A). Plastic outlet boxes are not recommended.

Attach mounting strap (D) to outlet box (not included) using existing washers and outlet box screws or the machine screws (BB). **NOTE:** If the outlet box screws required for your outlet box are of a different size than the machine screws (BB), consult a licensed electrician before proceeding.

Turn crossbar (E) on mounting strap (D) so fixture screws (F) are level horizontally. Use a level (not included) to make sure fixture screws (F) on mounting strap (D) parallel with floor and ceiling as needed. Tighten set screw, located in the middle of the mounting strap (B) and machine screws (BB) completely to secure mounting strap (D) to crossbar (E).

#### Hardware Used






4b. Adjust fixture screws (F) to proper length by screwing them completely into mounting strap (D).

Temporarily place fixture (A) over mounting strap (D) to determine amount of adjustment necessary for fixture screws (F). **NOTE**: Fixture screws (F) should come through holes in fixture (A) just enough so decorative nuts (G) fit flush against fixture (A) when mounted. Once fixture screws (F) are adjusted, tighten nuts (H) securely against mounting strap (D).

Set fixture (A) aside.



5. **WARNING:** Never connect ground wire to WHITE or BLACK power supply wires.

A WARNING: To reduce the risk of fire, electrical shock or personal injury, wire connectors (AA) are designed to accept only one 12-gauge house wire and two lead wires from the light fixture. If your house wire is larger than 12-gauge or there is more than one house wire to connect to the corresponding fixture lead wires, consult an electrician for the proper size wire connectors to use.

Unwrap BARE wire on fixture (A) from BLACK and WHITE wires. Prepare wires by stripping 3/4 in. of insulation from wire ends using wire strippers (not included).

Connect BARE/GREEN ground wire from outlet box to BARE ground wire from fixture (A) with wire connector (AA).

Connect WHITE wire from fixture (A) to WHITE wire from outlet box using existing wire connector or wire connector (AA).

Connect BLACK wire from fixture (A) to BLACK wire from outlet box using existing wire connector or wire connector (AA).

**NOTE:** Screw wire connectors (AA) on in a clockwise direction.

#### Hardware Used



Wire Connector


or 🖡


х З

6. Wrap electrical tape (not included) around each individual wire connector (AA) down to the wire.

**A WARNING:** Make sure no bare wire or wire strands are visible after making connections.


Push wire connectors (AA) gently back into outlet box. Carefully push excess wiring into outlet box.






 Align holes in fixture (A) with fixture screws (F) on mounting strap (D) and push fixture (A) toward wall. Attach fixture (A) to mounting strap (D) using the decorative nuts (G) previously removed (Step 3, page 5).

**NOTE:**Check fixture (A) with level (not included), and adjust if necessary, before tightening decorative nuts (G) completely.



 Remove socket ring (B) from socket of fixture (A). Attach shade (C) to socket, securing with socket ring (B). Repeat for remaining sockets.

**WARNING:**Do NOT overtighten socket rings (B) as shades (C) may crack or break.




9. Install 60-watt max. standard-base incandescent bulbs (not included) or CFL/LED equivalents.

**WARNING:** When replacing bulb(s), please allow bulb(s), shade(s) (C) and fixture (A) to cool down before touching.

Restore power and test fixture (A).

If lights do not function, please refer to TROUBLESHOOTING on the following page.



#### CARE AND MAINTENANCE

• Shut off main power supply. Wipe with soft cloth or use window cleaner. Do not use an abrasive cleaner.

#### TROUBLESHOOTING

**WARNING:** Before beginning work, shut off the power supply to avoid electrical shock.

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Bulb(s) will not light.	<ol> <li>Bulb(s) is/are burned out.</li> <li>Power is OFF.</li> <li>Faulty connection.</li> </ol>	<ol> <li>Replace light bulb(s).</li> <li>Make sure power supply is ON.</li> <li>Check wiring and all connections.</li> </ol>
Fuse blows out or circuit breaker trips.	<ol> <li>Crossed wires.</li> <li>Power wire is grounding out.</li> </ol>	<ol> <li>Check wiring.</li> <li>Check all connections.</li> </ol>

#### WARRANTY

The distributor warrants all of its lighting fixtures against defects in materials and workmanship for five (5) years from the date of purchase. If within this period the product is found to be defective, take a copy of the bill of sale as a proof of purchase and the product in its original carton to the place of purchase. The distributor will, at its option, repair, replace or refund the purchase price to the consumer. All costs of installation and removal of the fixture is the responsibility of the consumer. This warranty does not cover fixtures becoming defective due to misuse, accidental damage or improper handling and/or installation and specifically excludes liability for direct, incidental or consequential damages, improper packaging of returned products and acts of God. As some states do not allow exclusions of limitations on an implied warranty, the above exclusion and limitation may not apply. This warranty gives you specific rights and you may also have other rights which may vary from state to state.