



How to Instal Your Ceiling Fan

Tips: Check out the assembly video on the Amazon product page!


1. Unscrew the screws, 10 in total (2 for each fan blade), from the fan blade holder.



2. Align the screw holes in the fan blade with the screw holes in the mount and turn the screws until tight.



3. Remove the fixing screws of the triangular plate, align the lamp tray with the mounting holes, then tighten the screws.



4. LED light source straight with strong magnetic fixed column, directly adsorbed to the light source fixed disk. Connect the LED light plate

5. Connect the LED light plate, then twist the light cover to secure it.



ENERGY SAVING LIFE

Ceiling Fan With Light User Manual

This manual is designed to make it as easy as possible for you to assemble, install, operate and maintain your ceiling fan.

Materials

⚠ WARNING


Before you start putting together your ceiling fan, be sure to check out the section on the correct wiring process for your fan (page 3). If you're not confident in your wiring skills or don't have enough experience, it's a good idea to have a licensed electrician install your fan for you.

The wiring outlet box and box connectors should meet the specifications outlined in the local building code. For the minimum wire, a 3-conductor (2-wire with ground) of the appropriate size must be used as per the guidelines.

Installed Wire Length	Wire Size A.W.G
Up to 50 ft	14
50-100 ft	12

NOTE: Put loose parts into a small container to prevent loss. If you lose any parts, please contact a nearby hardware store.

How to use it



SAFTY RULES

1. Before starting, turn off the power to the fan at the main circuit panel to reduce the risk of electric shock.
2. All wiring must comply with local or national electrical codes and should be installed by a qualified electrician.
3. When handling fan parts with sharp edges, gloves may be necessary to avoid personal injury.
4. Ensure the installation site allows clear space for the blades to rotate and at least 7 feet (2.13 meters) of clearance between the floor and the tips of the fan blades. Mount the fan so that the tips of the blades are at least 18 inches (45.72 centimeters) from walls or other upright structures.
5. **WARNING:** Only mount the fan to an outlet box marked acceptable for fan support, and use the provided mounting screws. Most outlet boxes for lighting fixtures are unsuitable for fan support and may need replacement. Consult a qualified electrician if unsure.
6. The outlet box and ceiling support structure must be securely mounted and capable of supporting at least 45 kilograms.
7. Be cautious when working around or cleaning the fan to avoid personal injury or damage to the fan and other items.
8. Use a dry dust cloth or lightly dampened cloth for cleaning the fan or fan blades. Do not use water or detergents.
9. After making electrical connections, carefully push the spliced conductors upward into the outlet box. Spread the wires apart with the grounded conductor and equipment-grounding conductor on one side of the outlet box.
10. Electrical diagrams are for reference only.
11. The fan can be installed in indoor spaces or in covered outdoor areas such as patios, screened porches, and sunrooms.

TOOLS REQUIRED

