



METRIE

SLAT WALL PANELS



RED OAK



BLACK WALNUT



WHITE OAK



SEE REVERSE FOR INSTRUCTIONS
SCAN THE CODE FOR MORE
PRODUCT INFORMATION

[METRIE.COM/THE-FINISHED-SPACE/SLAT-WALL](https://metrie.com/the-finished-space/slat-wall)



SLAT WALL PANEL

INSTALLATION INSTRUCTIONS



TOOLS REQUIRED:

- Black Screws (8pc per panel) approx. 35 mm.
- Construction Adhesive
- Circular saw
- Jig saw
- Utility Knife
- Measuring Tape
- Pencil
- Power Drill or Screwdriver
- Vacuum
- Wipe Cloth
- Sandpaper

1. Measure your wall height and cut each panel with the felt side up, using a *Circular Saw*.
2. Mark and cut holes for outlets, light switches, etc. by pre-cutting the felt with a sharp *Utility Knife*, and finishing the cut using a *Jig Saw*.
3. Lightly sand all cut edges with *Sandpaper* (240 recommended).
4. Use a *Vacuum* and clean *Cloth* to remove any dust and debris. If required, re-fasten any loose slats to the felt with a small amount of *Construction Adhesive*.
5. Start at one edge of your wall. Using a *Drill*, mount the first panel using *35mm Black Screws*. We recommend a minimum of 8 screws per panel, evenly spaced across the width and length.

SLAT WALL PANELS are designed to appear seamless when installed. Ensure that the exposed *felt side* from one panel is installed flush with the *slat side* of the next panel.

• **INSIDE CORNERS** orient both corner panels so that the *felt sides* are facing each other.

• **OUTSIDE CORNERS** orient both corner panels so that the *slat sides* are facing each other.

6. Repeat, following the correct orientation along the length of the wall. For the final piece of your project, measure the remaining width and cut the panel on the felt side using a utility knife.

ALTERNATIVE INSTALLATION

Use *Construction Adhesive* to adhere the panels to the wall by applying roughly a 3/8" bead of Adhesive in a zig-zag pattern directly on the *felt side* of the panel.

ENHANCED ACOUSTIC DAMPENING

Install 2" timber battens to the wall horizontally, and screw the panels directly into the battens through the felt. Install Mineral Wool behind the slat wall panels for additional dampening.