


# ASSEMBLY INSTRUCTION


## DINNING SET




**N704P250741;N704P250742**

**Notice:**

1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. Note : If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.









**x6**














**x1**

## Part List:

<b>A</b> x 6  <b>Back Chair Frame (6 pcs)</b>	<b>B</b> x 6  <b>Chair Frame (6 pcs)</b>	<b>C</b> x 2  <b>Top Table (2 pcs)</b>	<b>D</b> x 2  <b>Leg Table (2 pcs)</b>
<b>E</b> x 2  <b>Connector (2 pcs)</b>	<b>F</b> x 6  <b>Seat Cushion (6 pcs)</b>		


## Hardware List:

<b>1</b> x 40 pcs  Extra 2 pcs <b>BOLT M6 x 20MM</b>	<b>2</b> x 64 pcs  Extra 2 pcs <b>FLAT WASHER M6</b>	<b>3</b> x 12 pcs  Extra 2 pcs <b>BOLT M6 x 40MM</b>	<b>4</b> x 8 pcs  Extra 2 pcs <b>BOLT M6 x 30MM</b>
<b>5</b> x 2 pcs  Extra 1 pcs <b>BOLT M6 x 100MM</b>	<b>6</b> x 2 pcs  Extra 1 pc <b>ERU M6</b>	<b>7</b> x 1 pc  <b>KEY</b>	<b>8</b> x 2 pcs  <b>MIDLE CONNECTOR</b>
<b>9</b> x 2 pcs  <b>SIDE CONNECTOR</b>	<b>10</b> x 2 pcs  <b>ALLEN WRENCH</b>	<b>11</b> x 1 pc  <b>COVER CAP</b>	


## CARTON CONTENT:

### N704P250741



Ⓒ x 2



Ⓓ x 2




Ⓔ x 2




Hardware

### N704P250742



Ⓐ x 3



Ⓑ x 3




Ⓕ x 3




Hardware

### N704P250742



Ⓐ x 3



Ⓑ x 3













Ⓕ x 3







Hardware





## N704P250741

<b>1</b> x 28 pcs	<b>2</b> x 40 pcs	<b>4</b> x 8 pcs	<b>5</b> x 2 pcs
			
BOLT M6 x 20MM	FLAT WASHER M6	BOLT M6 x 30MM	BOLT M6 x 100MM
<b>6</b> x 2 pcs	<b>7</b> x 1 pc	<b>8</b> x 2 pcs	<b>9</b> x 2 pcs
			
ERU M6	KEY	MIDLE CONNECTOR	SIDE CONNECTOR
<b>10</b> x 1 pcs	<b>11</b> x 1 pc		
			
ALLEN WRENCH	COVER CAP		

## N704P250742

<b>1</b> x 6 pcs	<b>2</b> x 12 pcs	<b>3</b> x 6 pcs	<b>10</b> x 1 pcs
			
BOLT M6 x 20MM	FLAT WASHER M6	BOLT M6 x 40MM	ALLEN WRENCH

## N704P250742

<b>1</b> x 6 pcs	<b>2</b> x 12 pcs	<b>3</b> x 6 pcs	<b>10</b> x 1 pcs
			
BOLT M6 x 20MM	FLAT WASHER M6	BOLT M6 x 40MM	ALLEN WRENCH

## STEP 1


<b>A</b>	<b>x1</b>
----------	-----------

<b>B</b>	<b>x1</b>
----------	-----------

<b>①</b>	<b>x2</b>
----------	-----------

<b>②</b>	<b>x4</b>
----------	-----------


<b>③</b>	<b>x2</b>
----------	-----------



Connect Seat Chair (B) & Back Chair (A), Tighten Bolt (1), (3) & Flat Washer (2) with Allen Wrench (10).


## STEP 2

<b>F</b>	<b>x1</b>
----------	-----------



Open all the bags, adjust the cushions, Set up the Seat Cushions (F).

### STEP 3



**x6**

Finish Chair.

### STEP 4


<b>C</b>	<b>x 2</b>
----------	------------

<b>2</b>	<b>x 4</b>
----------	------------

<b>5</b>	<b>x 2</b>
----------	------------

<b>6</b>	<b>x 2</b>
----------	------------

<b>7</b>	<b>x 1</b>
----------	------------



Connect Top Table (C) Tighten Bolt (5) & Flat Washer (2) & Nut (6), Key (7) & with Allen Wrench (10) .


## STEP 5

① x12

② x12

⑧ x2

⑨ x2




Connect the part from step 4, with Middle Connector (8), Side Connector (9), Tighten Bolt (1) & Flat Washer (2) with Allen Wrench (10).

## STEP 6

E x2

② x8

④ x8




Connect the part from step 5, with Connector (E), Tighten Bolt (4) & Flat Washer (2) with Allen Wrench (10).

## STEP 7

**D** x2

**1** x16



**2** x16



Connect the part from step 6, Table Leg (D), Tighten Bolt (1) & Flat Washer (2) with Allen Wrench (10).

## STEP 8

**11** x1



Finish Table.