

Phone number: 303-747-4421 / (951) 213-4743

service@clihome.net
Web:www.clihome.net

Part List:

| ITEM | DESCRIPTION | PART | QTY |
|------|---------------------|------|-----|
| 1 | Top panel | | 1 |
| 2 | Bottom panel | | 1 |
| 3 | Front/Back panel | | 2 |

Part List:

| rart List. | | | | | |
|------------|-------------|------|-----|--|--|
| ITEM | DESCRIPTION | PART | QTY | | |
| 4 | Side panel | | 2 | | |
| 5 | Leg | | 2 | | |

Hardware List:


| ITEM | DESCRIPTION | PART | QTY |
|------|--------------|-----------|-----|
| A | Camlock bolt | | 18 |
| В | Camlock | 3% | 18 |
| С | Wooden dowel | Ф8*30mm | 20 |


Hardware List:

| ITEM | DESCRIPTION | PART | QTY |
|------|--------------|--------------|-----|
| D | Bolt | Φ1/4"*1 1/4" | 14 |
| Е | Allen wrench | | 1 |

- * Required screwdriver & mallet, not included.
- * Before discarding packing materials, please check to make sure that all parts and hardware is present.
- * Two people needed for assembly.
- * Please follow the instructions closely; do not over tighten screws or bolts unless instructed.
- * After a few days from initial assembly, the product may have acclimated to the new environment. Please retighten the hardware.

Guideline For Assembling of Cam Lock (A & B)








Screw camlock bolt (A) to wood part.


Do not assemble camlock (B) unless instructed.

To assemble camlock (B), ensure long side of the + is facing the bolt (A) before inserting into hole.














After installation, adjust the adjustable foot to keep the table balanced.