

- ❶ **Prepare the Wall:** Ensure that the wall where you intend to install the tiles is smooth, free from any oils, and thoroughly clean. Make note of any permanent obstructions i.e. wall outlets.
- ❷ **Plan Your Lay Pattern:** Begin your installation process from the highest point on the countertop. Draw a level line from this point, which will serve as your guideline for installing the first row of tiles.
- ❸ **Prepare the Tiles:** Trim the tiles as needed to fit your specific space. Remove the protective film from the back of each tile, one tile at a time.
- ❹ **Apply Soapy Water Mix:** Spray a small amount of soapy water mix onto the adhesive side (back) of the tile. Use your hand to evenly spread the soapy water mixture over the entire surface. This step allows you to adjust the tile on the wall with precision by extending the bonding time.
- ❺ **Place the Tile:** Position the tile onto the wall and use a small dry paint roller to firmly press it for a few seconds to ensure maximum adhesion.
- ❻ **Optional Finishing Touch:** If desired, use a silicone caulk or tile grout of your choice to seal any gaps between the tiles and the wall, as well as around any outlets, switches, or other obstructions. Allow time to dry completely.

CUTTING INSTRUCTIONS:

Be sure to always wear safety goggles and gloves during this step.

- For glass tiles or glass borders, use a diamond-tipped glass cutter or a wet saw cut them to the desired size.
- For metal, stone, or composite tiles, use a utility knife or a small table saw to cut them to the desired size.

IMPORTANT PREPARATION STEP BEFORE INSTALLING:

To guarantee the tiles interlock correctly and maintain an even appearance, please dry-fit tiles to desired location or simulate the installation by placing the tiles flat before proceeding with the actual installation process.

