


ASSEMBLY INSTRUCTIONS

MOD-7204

V0.07.29.24



Questions? Contact us!

609.256.9000 • cs@modway.com
www.modway.com

*modway



Read through all of the instructions before starting



Care instructions are listed in the last step of this manual



Approx. 120 minutes assembly time



Make sure you have all parts and components before discarding any packing materials



2 people recommended for assembly

Only use hand tools to assemble this item. Do not use power tools. Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.



Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.

Assemble your item on a flat, carpeted area, with plenty of space to work. This will prevent damage and scratches to your floors or the item while you're assembling the product.

Keep all components and packaging out of reach of children or animals to avoid risk of choking or suffocation.

Furniture components:





















1	Top Board	x1	11	Bottom Drawer	x6
2	Bottom Board	x1	12	Handle	x6
3	Side Board Left	x1	13	Back Board	x4
4	Side Board Right	x1	14	Support Board	x2
5	Assembly Leg	x2	15	Center Board	x1
6	Bottom Skirt	x2	16	Counter Wight Board	x2
7	Front Drawer	x6	LC16A1	Center Leg	x1
8	Side Drawer Left	x6			
9	Side Drawer Right	x6			
10	Back Drawer	x6			



Wait!

Missing parts or hardware? Need assistance?
Contact us before returning your item. We're here to help!
609.256.9000 • cs@modway.com

Provided hardware:

A		Cam Bolt Ø6 x 35 mm	x36	J		Screw M 3.5 x 13 mm	x36	RM35A		Drawer Runner	x6
B		Cam Lock Ø15 mm	x36	K		Screw M 8 x 39 mm	x24	What you need:			
C		Cam Lock Ø12 mm	x24	L		Screw M 3.5 x 15.5 mm	x24	Phillips		Phillips Head Screwdriver	
D		Wood Dowel Ø8 x 30 mm	x52	M		Wedge	x24				
E		Wood Dowel Ø6 x 30 mm	x12	N		Floor Protector	x4				
F		Wood Dowel Ø5 x 20 mm	x12	O		Screw M 6.4 x 25 mm	x18				
G		Cam Bolt Ø6 x 32 mm	x24	P		Screw M 6 x 10.5 mm	x36				
H		Screw M 7 x 50 mm	x10	Q		Screw M 4.5 x 12.5 mm	x4				
I		Allen Key	x2	PM2		Mounting Plate	x1				

Components Carton Placement

Carton 1 of 2

Label	Description	Qty
3	Side Board Left	x1
4	Side Board Right	x1
6	Bottom Skirt	x2
7	Front Drawer	x6
13	Back Board	x4
14	Support Board	x2
15	Center Board	x1
LC16A1	Center Leg	x1
	Hardware Pack	x3

Carton 2 of 2

Label	Description	Qty
1	Top Board	x1
2	Bottom Board	x1
5	Assembly Leg	x2
8	Side Drawer Left	x6
9	Side Drawer Right	x6
10	Back Drawer	x6
11	Bottom Drawer	x6
12	Handle	x6
16	Counter Weight Board	x2


Step 1

HARDWARE

- E** Wood Dowel Ø6 x 30 mm x12
- F** Wood Dowel Ø5 x 20 mm x12
- G** Cam Bolt Ø6 x 32 mm x24

COMPONENTS

- 7** Front Drawer x6
- 8** Side Drawer Left x6
- 9** Side Drawer Right x6
- 13** Handle x6




Step 2

HARDWARE

- C** Cam Lock Ø12 mm x24
- K** Screw M 8 x 39 mm x24

COMPONENTS




- 7** Front Drawer x6
- 8** Side Drawer Left x6
- 9** Side Drawer Right x6
- 10** Back Drawer x6
- 11** Bottom Drawer x6



Step 3

HARDWARE

- J** Screw M 3.5 x 13 mm x36
- L** Screw M 3.5 x 15.5 mm x24
- M** Wedge x24
- RM35A** Drawer Runner x6




Step 4

HARDWARE

- I** Allen Key x1
- O** Screw M 6.4 x 25 mm x18

COMPONENTS

- 12** Handle x6








Step 5

HARDWARE

- A** Cam Bolt Ø6 x 35 mm x16
- D** Wood Dowel Ø8 x 30 mm x12

COMPONENTS

- 1** Top Board x1
- 3** Side Board Left x1
- 4** Side Board Right x1
- 14** Support Board x1



Step 6

HARDWARE




P Screw M 6 x 10.5 mm x18

RM35A Drawer Runner x3

COMPONENTS

3 Side Board Left x1

4 Side Board Right x1



Step 7



HARDWARE

D Wood Dowel Ø8 x 30 mm x24

COMPONENTS

13 Back Board x4

16 Conter Wight Board x2





Step 8

HARDWARE

- A** Cam Bolt $\varnothing 6 \times 35$ mm x3
- D** Wood Dowel $\varnothing 8 \times 30$ mm x4
- P** Screw M 6 x 10.5 mm x18
- RM35A** Drawer Runner x6

COMPONENTS

- 15** Center Board x1




Step 9

HARDWARE

- B** Cam Lock $\varnothing 15$ mm x3

COMPONENTS

- 3** Side Board Left x1
- 14** Support Board x1
- 16** Counter Weight Board x1




Step 10

HARDWARE

B Cam Lock Ø15 mm x3

COMPONENTS

15 Center Board x1



Step 11

HARDWARE


A Cam Bolt Ø6 x 35 mm x3

B Cam Lock Ø15 mm x3

COMPONENTS

14 Support Board x1

16 Counter Weight Board x1





Step 12

HARDWARE

B Cam Lock Ø15 mm x3

COMPONENTS

4 Side Board Right x1





Step 13

HARDWARE

B Cam Lock Ø15 mm x6

COMPONENTS

1 Top Board x1





Step 14

HARDWARE

B Cam Lock Ø15 mm x4

COMPONENTS

13 Back Board x4



Step 15



HARDWARE

H Screw M 7 x 50 mm x10

I Allen Key x1

COMPONENTS



2 Bottom Board x1



Step 16

HARDWARE

- A** Cam Bolt Ø6 x 35 mm x10




Step 17

HARDWARE



- A** Cam Bolt Ø6 x 35 mm x4
- D** Wood Dowel Ø8 x 30 mm x4

COMPONENTS

- 5** Assembly Leg x2
- 6** Bottom Skirt x2



x 2



x 2

Step 18



HARDWARE

B Cam Lock $\varnothing 15$ mm x4

COMPONENTS

5 Assembly Leg x2


6 Bottom Skirt x2



Step 19

HARDWARE




D Wood Dowel $\varnothing 8 \times 30$ mm x8



Step 20

HARDWARE



- B** Cam Lock $\varnothing 15$ mm x10
- N** Floor Protector x4



Step 21

HARDWARE

- Q** Screw M 4.5 x 12.5 mm x4
- PM2** Mounting Plate x1





Step 22


COMPONENTS

LC16A1 Center Leg


x1




Step 23



ADVERTENCIA	ATTENTION	WARNING
<p>Los niños han muerto por descuido de muebles. Para reducir el riesgo de lesiones de muebles:</p> <p>Coloque los artículos pesados en los estantes más bajos.</p> <p>Este es un producto pesados. No pasarlo.</p>	<p>Les enfants sont morts de négligence dans les meubles. Réduisez les risques de blessures de meubles:</p> <p>Placez les objets lourds sur les étagères les plus basses.</p> <p>Ceci est un produit pesant. Ne pas passer.</p>	<p>Children have died from furniture injuries. To reduce the risk of furniture injuries:</p> <p>ALWAYS place heavy objects on the lowest shelves.</p> <p>NEVER put a TV on this product.</p> <p>NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.</p> <p>NEVER open more than one drawer at a time.</p> <p>Place heaviest items in the lowest drawers.</p> <p>This is a heavy product. Do not remove.</p>



Step 24



Great job!

Chest Of Drawers assembly is complete.


♥ CARING FOR YOUR ITEM

Indoor use only.

Not contract grade.

Clean using a non-abrasive cloth and a mild cleaner.

Never use harsh chemicals, as they could damage the finish or integrity of the item.



CONNECT WITH US!   





Tag us @modway_furniture and #modway for a chance to be featured.

TIPPING RESTRAINTS KIT INSTALLATION GUIDANCE

Different wall materials require unique wall fasteners.

The wall plugs (AA2) and screws (AA3) are designed for fixing to concrete walls only.

Please consult your local hardware store to ensure you are using the correct hardware for you wall type.



Installation Instructions :

1. Attach bracket (AA1) securely to the back top of the furniture using screw (AA4) provided. Allow 8 - 10 cm from each side.
2. Please make a hole for wall plugs position on the wall and minimum 15 mm below bracket secured to the back of unit. Attach the wall plugs (AA2).
3. Install the other bracket (AA1) on the wall over wall plugs (AA2), secure with screw (AA3). Place furniture into position so both brackets (AA1) are aligned.
4. Lace the end of the restraints strap through the larger hole in each bracket. Ensure the restraints strap with grids surface facing the inner loops. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed.
5. Make sure that the strap is securely laced & locked.