

INSTALLATION INSTRUCTION WS-1

For Wall Sconce Light Fixtures (Rev.2/08/04)

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

MOUNTING THE BACKPLATE (Fig.1)

1. Shut off the power at the circuit breaker and remove old fixture, including the crossbar.
2. Carefully unpack your new fixture and lay out all the parts on a clear area . Take care not to lose any small parts necessary for installation.
3. Attach the Crossbar to the junction box using two Junction Box Screws .The side of the Crossbar marked "GND" must face out.
4. Thread the Nipple part way into the center hole of the Crossbar.

CONNECTING THE WIRES (Fig.4)

5. As you hold the Back plate toward the wall, connect the wires as shown in Figure 4 . Be sure that all wire nuts are secured. You may have to wrap the connections with electrical tape. If your outlet has a ground wire (Green or Bare Copper), connect the fixture ground wire to it : otherwise , connect the fixture ground wire directly to the Crossbar using the green screw provided.

MOUNTING THE FIXTURE AND SHADE

6. After the wires are connected tuck them carefully inside the junction box as you place the Back plate over the Nipple. Secure the Back plate against the wall using Hex Nut or Knurled Cap.
7. Install Glass Shade by referring to Figures 1, 2, or 3. Find the one that best matches your fixture and install according to illustration.
8. Install light bulbs in accordance with fixtures specifications **DO NOT EXCEED MAXIMUM WATTAGE RATING!**
9. Your installation is now complete. Return power to the junction box and test the fixture.

Fig 1




Fig 2




Fig 3




Fig 4 FIXTURE WIRES Black or Smooth HOUSE WIRES Black (Hot)	FIXTURE WIRES White or Ribbed HOUSE WIRES White (Neutral)	FIXTURE WIRES Green or Bare Copper (Ground) HOUSE WIRES Green or Bare Copper (Ground)
--	---	---

MIN 90°C SUPPLY CONDUCTORS

