
ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0185

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.

2. READ AND SAVE THIS INSTRUCTION.




Installation Steps

Turn off the power at fuse or circuit box.

- 1. Rod Connections:
 - a. Thread the fixture wire from the fixture through the lower rod, and then secure the lower rod onto fixture using the threaded pipe.
 - b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
 - c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.
 - Note: Length adjustable from 12" to 54". Use fewer rods if shorter length is desired.
- 2. Thread the fixture wire through the canopy kit, and then secure the rod assembly to the set nipple of the canopy kit.
- 3. Attach the mounting strap to the outlet box by using two mounting screws.
- 4. Pull out the source wires from the outlet box. Make wire connections using wire nuts as follows:
 - ---Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
 - ---Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
 - ---Attach the fixture grounding wire to the mounting strap with the green grounding screw, and then connect it to the house grounding wire with a wire nut.

Carefully put the wires back into the outlet box.


- 5. Attach the canopy kit to the mounting strap by inserting the fixture mounting screws, and then secure it with two ball nuts.
- 6. Attach the glass shade to the fixture, and then secure it with the socket ring.
- 7. Install a bulb (not included). See relamping label at socket area or packaging for maximum allowed wattage.





8. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 1)

Turn on the power at fuse or circuit box.



The following parts are available for re-order if damaged or missing.

