

Hoover Dam GutterCover

PROFESSIONAL GRADE




- *Dam effect stops rainwater runoff*
- *Staggered profile design allows for airflow to clear leaves and debris from surface*
- *36 inches long - Fits all standard "K" style gutters*
- *Long lasting powder coated paint prevents rusting*

For best appearance, color blends with roofline, not the gutter



Part No. 6380



Hoover Dam GutterCover™



Easy Installation Instructions

CAUTION: Wear safety glasses and leather gloves while installing this product. Always exercise appropriate care when working from a ladder. Follow all tool and ladder manufacturer's instructions and safety recommendations.

Tools, Material & Safety Equipment Needed:


Safety glasses, leather gloves, tin snips or hacksaw, screwdriver and a ladder.

Not Included

Self-Tapping exterior grade gutter or sheet metal screws (2 screws per 3 foot section of gutter cover)


- 1 Make sure you clean your gutters and downspouts before installation of the Lock-In Gutter Guard. You should flush the entire gutter system with a hose, making sure water is flowing freely from the bottom of the downspout without any water backing up in the gutter.

Using the **Gutter Getter®** cleaning scoop (with flexible conforming tip) to make cleaning easy.




- 2 **Fits standard 4 in., 5 in. and 6 in. gutters.**


Starting at one end of the gutter, install the gutter cover by slightly lifting the shingles and sliding the gutter cover under the shingle. If the starter row of shingles are fastened to the roof deck slide the guard between the layers. (Note: Check your local building codes for any special installation requirements). Pull the front edge forward to engage with the lip of the gutter.




- 3** Using self-tapping exterior grade gutter or sheet metal screws, screw the gutter cover to the lip of the gutter through the pre-drilled holes (2 screws per 3 foot section of gutter cover).



Screw to gutter



- 4** Continue installing the gutter cover sections end to end.



- 5** For outside corners (A) or inside corners (B), mitre cut both adjoining sections. Notch the front edge of one section to create an overlap.

